

<p style="text-align: center;">Please read the instructions carefully before using this product! This product is household use only.</p> <p style="text-align: center;">English Content</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">Package Contents</td><td style="width: 10%;">1</td></tr> <tr> <td>Wireless mug warmer instructions</td><td>2</td></tr> <tr> <td>Wireless charger instructions</td><td>2</td></tr> <tr> <td>Specifications</td><td>3</td></tr> <tr> <td>Care and Cleaning</td><td>5</td></tr> <tr> <td>Troubleshooting</td><td>5</td></tr> <tr> <td>Warranty</td><td>6</td></tr> </table> <p style="text-align: center;"><b>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</b></p>	Package Contents	1	Wireless mug warmer instructions	2	Wireless charger instructions	2	Specifications	3	Care and Cleaning	5	Troubleshooting	5	Warranty	6	<p style="text-align: center;"><b>Package Contents</b></p> <p>1. Wireless charger 2. Adapter 3. Power cord 4. Ceramic cup 5. Ceramic cup cover</p> <p style="text-align: center;"><b>Important Safeguards</b></p> <ol style="list-style-type: none"> <li>1. Do not disassemble or modify this product yourself.</li> <li>2. Keep the charger and receiver away from water and other liquids.</li> <li>3. To clean the charger, make sure that no power is plugged in.</li> <li>4. The ambient temperature is maintained at 0-45 °C</li> <li>5. It is forbidden to place metal materials such as coins and keys or magnetic materials such as bank cards on the charger, which will affect normal work.</li> <li>6. The cups can only be hand washed, not for microwave/dishwasher/oven.</li> </ol> <p style="text-align: center;"><b>Specifications (1)</b></p> <p>Name: Wireless Charger Input: 12V/1.5A Output: 5V/1A CUP CAPACITY: ABOUT 350ML Keep warm: about 50 °C / 122 °F (more suitable for human drinking water) Charging efficiency: about 80%</p> <p style="text-align: center;"><b>Care and Cleaning</b></p> <p>1. Please clean the cup manually, do not use dishwasher.</p> <p>2. The cup can be dried and disinfected in 150 °C / 302 °F, but it can't be placed in a microwave oven or heated in the oven.</p> <p style="text-align: center;"><b>Specifications (2)</b></p> <p>Name: Wireless Charger Input: 12V/1.5A Output: 5V/1A CUP CAPACITY: ABOUT 350ML Keep warm: about 50 °C / 122 °F (more suitable for human drinking water) Charging efficiency: about 80%</p> <p style="text-align: center;"><b>Wireless charger instructions</b></p> <p style="text-align: center;"></p> <p>Place the phone in the middle of the wireless charger and the breathing light flashes to the charging state.</p> <p style="text-align: center;"><b>Troubleshooting</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Problem</th> <th>Possible causes</th> <th>What to do</th> </tr> </thead> <tbody> <tr> <td>No power</td> <td>The receiver is not powered</td> <td>Charge the receiver</td> </tr> <tr> <td>No power</td> <td>The power cord is not connected</td> <td>Put the power cord plug in place</td> </tr> <tr> <td>No power</td> <td>Adapter or power cord is broken</td> <td>Replace</td> </tr> <tr> <td>No power</td> <td>Charging circuit is bad</td> <td>Contact the dealer</td> </tr> <tr> <td>Flashing light</td> <td>The appliance is not in place</td> <td>Put the appliance in place</td> </tr> <tr> <td>Flashing light</td> <td>The cup is heated for more than 8 hours</td> <td>Put the cup upside down back in the case</td> </tr> </tbody> </table> <p style="text-align: center;"><b>Warranty</b></p> <p>Thank you for purchasing our product, which has been made to meet quality standards. The manufacturer's warranty covers the product for 12 months from the date of purchase against manufacturing faults.</p> <p style="text-align: center;"><b>Warranty Card</b></p> <p>Article: _____ Model: _____ Owner's Name: _____ Address: _____ Tel: _____ Purchase Date: _____ Dealer's Name &amp; Stamp: _____ Address: _____ Tel: _____</p> <p>Please fill in this table and email within 10 days from the date of purchase. Due to continuous product improvement, we reserve the right to change product specification without prior notice.</p>	Problem	Possible causes	What to do	No power	The receiver is not powered	Charge the receiver	No power	The power cord is not connected	Put the power cord plug in place	No power	Adapter or power cord is broken	Replace	No power	Charging circuit is bad	Contact the dealer	Flashing light	The appliance is not in place	Put the appliance in place	Flashing light	The cup is heated for more than 8 hours	Put the cup upside down back in the case
Package Contents	1																																			
Wireless mug warmer instructions	2																																			
Wireless charger instructions	2																																			
Specifications	3																																			
Care and Cleaning	5																																			
Troubleshooting	5																																			
Warranty	6																																			
Problem	Possible causes	What to do																																		
No power	The receiver is not powered	Charge the receiver																																		
No power	The power cord is not connected	Put the power cord plug in place																																		
No power	Adapter or power cord is broken	Replace																																		
No power	Charging circuit is bad	Contact the dealer																																		
Flashing light	The appliance is not in place	Put the appliance in place																																		
Flashing light	The cup is heated for more than 8 hours	Put the cup upside down back in the case																																		
<p style="text-align: center;">1</p>	<p style="text-align: center;">2</p>	<p style="text-align: center;">3</p>	<p style="text-align: center;">4</p>	<p style="text-align: center;">5</p>	<p style="text-align: center;">6</p>																															

FCC Warning

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.