


# 折叠后尺寸90\*63

## 产品说明书



### 规格参数

材 料：硅胶，ABS  
防水等级：IPX-7  
使用时长：>45分钟  
充电时间:<150分钟  
运行噪音：<50dB  
产品尺寸：85\*75\*50mm  
遥控尺寸：60\*20\*38mm  
按摩模式：10段变频震动  
包装内容：按摩器、遥控器、说明书、充电线

### 使用步骤

- ◆ 长按开关按键2秒开机，启动第一种震动模式。
- ◆ 短按开关按钮，切换下一种震动模式（共10种模式，依次循环）。
- ◆ 在开机状态下，单击遥控按键，切换下一种震动模式（共10种模式，依次循环）。
- ◆ 不用时，长按开关或者遥控器按钮可以关机。

使用前请充满电量（充电中指示灯闪烁，充满电指示灯长亮）

### 使用注意

- ◆ 使用前请先充电。
- ◆ 每次使用前请对产品进行消毒处理，用温水和抗菌肥皂洗净产品，并用毛巾或者软布轻轻擦干。
- ◆ 禁止将按摩油、护手霜、清洁剂、汽油或丙酮作为润滑剂使用。

### 清洁事项

- ◆ 使用完后由于有大量的分泌物及润滑油残留液果长时间不清洗的话，容易滋生细菌，使用完后请尽快着手清洗。

- ◆ 清洗时，可用温水和香皂进行擦洗，建议配合情趣玩具专用清洁剂，消毒液或者75%酒精来消毒（不推荐长期使用酒精，因为酒精会腐蚀玩具的表面，加速器具的老化）。
- ◆ 晾干：冲洗完后建议用棉布擦拭，或者优质纸巾也是不错的选择。擦拭完后自然风干，避免在太阳下暴晒。
- ◆ 保存在无尘的地方且不要接触其他材质的物品。

### 安全事宜

作为广大用户最亲密的伴侣，能够安全健康的使用此按摩器是用户和我们共同的责任。现提醒广大用户：

- ◆ 本产品为私人用品，为了您的健康，请不要多人混用。
- ◆ 此产品有不同频率的震动，供不同用户需求，若感到不适和过敏，请立即停止使用。
- ◆ 在使用产品前，有不够光滑和有尖角的情况下，请立即停止使用本品。
- ◆ 使用过程中如有感到不舒服，请立即停止使用。
- ◆ 放置按摩器和部件到小孩和宠物够不着的地方若部件被小孩和宠物吞下，请立即到附近医院就医。

### 售后服务

为确保您享有产品售后服务，购买时请保留购买小票或收据

本产品质保期为12个月。如果您在质保期内有任何质量问题，请及时与本公司取得联系，我们将竭诚为您提供高效，优质的服务。如果由于用户人为损坏，私自拆装导致的本产品无法使用，本公司无法提供质保服务。

本产品由专业成人用品研发机构设计制造，本品申请了多项国家和国外专利。



绿色环保材质



充足电量带动, 使用持久



低噪音



可作为礼物



人机工学设计



出行方便携带




IPX-7级防水

警告：  
本产品仅适合18周岁以上  
成人使用

Please read the instruction carefully before using this product.

## Vibration massager FUNCTIONS



### Specifications

Material: Silicone, ABS      Battery: Lithium battery  
Lasting time: >45min      Waterproofness: IPX7  
Product sizes:85\*75\*50mm  
Remote control size: 60\*20\*38mm  
Frequency conversion mode: 10 types  
Package contents: vibrator, remote control, manual, charger

### Steps of usage

- ◆ Long press for two seconds to turn on the product and it will start the first vibration mode.
- ◆ Short press the switch button again, it will switch next vibration mode.
- ◆ Short press the Remote control switch button , it will switch next vibration mode.
- ◆ When you need to stop it, long press on switch button, the motor will stop working.

### Using and maintenance tips

- ◆ Please aim the charger to charging hole to charge the product before using for the first time.
- ◆ It is highly recommended that the product can be used with a condom.
- ◆ Please disinfect the product before using: clean with warm water and antibacterial soap, wipe with towel or soft cloth.
- ◆ Please do not use massage oil, hand cream, detergent, petrol or acetone as lubricant.
- ◆ Please clean the product after using the product.
- ◆ Drying: suggest to wipe with cotton cloth or high quality tissue after washing and then let it dry naturally other than exposure under the sunlight.

### Cleaning matters

- ◆ After use, because there are a lot of secretions and lubricant residue, if you do not clean for a long time, easy to breed bacteria, after use, please start cleaning.

- ◆ When cleaning, can scrub with warm water and soap, it is recommended to cooperate with special cleaning agent for sex toys, disinfectant or 75% alcohol to disinfect (do not recommend long-term use of alcohol, because alcohol will corrode the surface of toys, accelerate the aging of appliances).

- ◆ Dry: Wipe with a cotton cloth after rinsing, or a good paper towel is also a good choice. Dry naturally after wiping to avoid exposure to the sun.

- ◆ Keep in a clean place and do not touch other materials.

### Safety tips

As an intimate partner of users, it's important to use this product safely and healthily. Thus, we remind our customers of that:

- ◆ This product is for personal use, please do not use with others together for your health sake.
- ◆ In order to meet different demands of different people, this product designed with different vibration frequency. Please stop using if feel any discomfort or allergy.
- ◆ Please cautious if the product is used to stimulate anus, please avoid body hurts in case it falls into anus when using. Suggest to use together with lubricant to get a better experience.
- ◆ Please stop using if the product is not smooth or with sharp corners.
- ◆ Please keep away from kids and pets.

### After sales service

Please save your receipt to insure that you can enjoy the after sales service.

We provide 12-months warranty. If you have any quality problem during this period, please contact us to get our efficient and good quality service. We do not provide quality guarantee service if the damage is caused by the users.

Warning:  
This product only for  
adult over 18 years old

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.