



Install equipment

1. Take out the lamp and accessories from the package, insert the DC plug of the adapter into the DC socket of the lamp base, and insert the other end of the adapter into the AC power supply.



2. Lightly touch the induction switch of the desk lamp to turn on or off the LED light. Long press the switch to adjust the brightness of the light, which can be infinitely dimmed.



Functional Operation Instructions

1. Adjust the lampshade: Loosen the middle shaft, adjust the angle of the lampshade, and then tighten the shaft after adjusting the angle.
2. Switch the light bulb: touch the sensor switch, the light bulb is on or off.
3. Adjust the brightness: press and hold the sensor switch, the brightness of the bulb will automatically increase or decrease the brightness.
4. Memory function: After the brightness adjustment is fixed, if the lamp is turned off and turned on again, the brightness will remain at the last brightness position. If the DC plug is unplugged and inserted again, the brightness will automatically maintain the maximum brightness 70% of brightness.
5. Wireless charging: Put the back of the phone on the wireless charging position, at this time, the charging instruction will be displayed on the screen of the phone and the charging will start.

Specifications

Product Name: Table lamps

Item model number: H-L01

Rated power: Model E14 ,7W LED bulb,
wireless charging 15W

Color Temperature: 6500 K

Rated input: 110~240 V~50/60 Hz

Light source type: LED light source

Blink level: Imperceptible level

Executive standard: GB7000.1GB/T17743,
GB7000.204

Precautions for use

1. The normal working position of the lamp: the light-emitting surface is horizontal and away from the work The distance between the faces is 350 mm.
2. Please confirm that the adapter is the original adapter before use.Using non-original adapters may damage the product to bring safety hidden danger.
3. The light source of this lamp can be replaced. If the light source reaches the end of its life, the bulb can be screwed out counter-clockwise, and it needs to be replaced with the same Specification (E14) bulbs.
4. The desk lamp will generate heat when working, please keep the surrounding empty air convection to dissipate heat.
5. Strictly prevent the product from entering water or in conditions exceeding the operating temperature and humidity work under the conditions..
6. When adjusting the angle of the lampshade, do not put your fingers into the lampshade and the support. between the rack connections, so as not to cause injury to the fingers.
7. When charging, place the mobile phone in the middle of the wireless charger to get the best charging effect.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.