

IMPORTANT SAFETY PRECAUTIONS

- Read all instructions before using your desypad with wireless charger.
- Keep away from water or any other liquid.
- Keep away from pets and children.
- Do not expose to excessive heat, flames or fire.
- Always press all buttons or switches carefully.
- Do not use in extremely dry environments.
- Do not expose to temperatures above 45°C or below 0°C.
- This unit is for indoor use only.
- If you must clean the pad, be sure power is disconnected.
- Do not operate this unit with a damaged plug.
- Do not attempt to repair this product yourself.
- Do not drop, puncture or expose to excessive trauma.
- Unplug during lightning storms.
- Keep out of direct sunlight.
- Keep distance between any implanted medical devices (cardiac pacemaker, implantable cochlea, etc.) and the desypad with wireless charger. >20cm to avoid potential interference with the medical device.

TECHNICAL SUPPORT

Please do not attempt to fix the product yourself. If you are experiencing any problems with the product please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact iWorld technical support:

iWorld LLC
24O West 37th St., 10th Floor
New York, NY 10018, USA

www.iworldnyc.com
email: support@iworldnyc.com
Please keep instructions for further reference.

© 2024 PrimeConnect
24O WEST 37TH ST. NEW YORK, NY 10018

ALL OTHER TRADEMARKS AND TRADE NAMES ARE THOSE OF THEIR RESPECTIVE OWNERS. DEVICE NOT INCLUDED. ACTUAL PRODUCT MAY DIFFER SLIGHTLY FROM IMAGE SHOWN.
MADE IN VIETNAM.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.


FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

DESKPAD WITH WIRELESS CHARGER



INSTRUCTION MANUAL

Product Diagram



INSTRUCTION MANUAL

ENGLISH

INSTRUCTION MANUAL

ENGLISH

Wireless Charger

SPECIFICATIONS

- Input : DC 5V/2A, DC 9V/2A (requires DC 5V/2A or DC 9V/2A wall charger, not included)
- Wireless Charging Output : 5W/7.5W/10W/15W (MAX)
- Charging Efficiency : ≥75%
- Working frequency: 110~205 KHZ
- Conversion efficiency: ≥70%
- Transmission distance : ≤6mm
- Product Size : 23.69 in. x 9.37 in.

COMPATIBLE DEVICES

- Devices with built-in wireless charging receiver
 - Devices with reserved wireless charging interface besides its battery
 - Devices with wireless charging receiver built-into its protective device case
- NOTE: ALL DEVICES MUST BE QI™-ENABLED.

Compatible with the following devices:

- iPhones:
iPhone 15, iPhone 15 Pro, iPhone 15 Pro Max, iPhone 15 Plus
iPhone 14, iPhone 14 Pro, iPhone 14 Pro Max, iPhone 14 Plus
iPhone 13, iPhone 13 Pro, iPhone 13 Pro Max, iPhone 13 mini
iPhone 12, iPhone 12 Pro, iPhone 12 Pro Max, iPhone 12 mini
iPhone SE (2nd/3rd generation)
iPhone 11, iPhone 11 Pro, iPhone 11 Pro Max
iPhone X, XR, XX, XS Max
iPhone 8 and 8 Plus.

- Samsung phones: Galaxy® Note : Galaxy® Note20 5G, Note20 Ultra 5G, Note10+, Note10, Note9, Note8, and Note 5.
Galaxy®S: S24 series, S23 series, S22 series, S21 series, S20 series, S10 series, S9 series, S8 series, S7 series, and S6 series.
Foldable phones: Galaxy® Z Fold, Z Fold2, Z Fold3, Z Fold4, Z Fold5, Z Flip, Z Flip 5G, Z Flip3, Z Flip4, and Z Flip5
Galaxy®S7/S7 Edge, Galaxy S8/S8+, and Galaxy®S9/S9+.

WIRELESS CHARGING

1. Insert the larger USB-A end of the cable into the USB port of a computer OR into a compatible USB DC 5V wall power adapter (not included) to charge through a standard wall outlet.
2. Insert the USB-C connector of the included power cable into the power input port of the deskpad charger. When power is successfully connected, the LED indicator lights up.
3. To charge a Qi-enabled wireless device, place on the wireless charging pad location. The LED indicator will light up when successfully charging. When the device is removed from the pad, the indicator light will turn off.