

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



正面


User Manual

stylus pen



V 2.0
Please read this instruction completely and keep it properly

Product Details



Product parameter

Model: stylus pen - P6WP
Anti touch function: Yes
Input: 5v-0.2a
Tilt pressure sense: Yes
Bluetooth: Yes
Pen head: replaceable pen head
Applicable model:
iPad (6th generation) A1893/A1954
iPad (7th generation) A2197/A2200/A2198
iPad (8th generation) A2270/A2428/A2429/A2430
iPad mini (5th generation) A2133/A2124/A2126/A2125
iPad mini (6th generation) A2567/A2568/A2569
iPad Air (3rd generation) A2152/A2123/A2153/A2154
iPad Air (4th generation) A2316/A2324/A2325/A2072
iPad Pro (11 inches) A1980/A2013/A1934/A1979
iPad Pro11 inch (2nd generation) A2228/A2068/A2230/A2231
iPad Pro12.9 inch (3rd generation) A1876/A2014/A1983
iPad Pro12.9 inch (4th generation) A2229/A2069/A2232/A2233
iPad Pro12.9 inch (5th generation) A2377/A2459/A2301/A2460
iPad Pro12.9 inch (6th generation) A2378/A2461/A2379/A2462
iPad Pro11 inch (2nd generation) A2602/A2604/A2603/A2605

Product Features


1. Fashionable and simple style, aluminum alloy material with piano baking paint, calm and luxurious, Novel and durable.
2. Replaceable pen head design, no fear of wear! The newly upgraded tilt and bold function, the larger the tilt area of the pen tip, the thicker the line.
3. The tip of the pen is made of special conductive materials and finely ground. Artificially create a smooth pen tip to prevent damage to the screen.
4. The product is compatible with iPad models after 2018 (see product parameters for specific models), which can write, draw, and record.
5. The product can be used continuously for up to 10 hours under full power, and it will stand still for 5 minutes smart power off is not used.

Magnetic model

ipad mini (6th generation) A2567/A2568/A2569
iPad Air (3rd generation) A2152/A2123/A2153/A2154
iPad Air (4th generation) A2316/A2324/A2325/A2072
iPad Pro (11 inches) A1980/A2013/A1934/A1979
iPad Pro11 inch (2nd generation) A2228/A2068/A2230/A2231
iPad Pro12.9 inch (3rd generation) A1876/A2014/A1983
iPad Pro12.9 inch (4th generation) A2229/A2069/A2232/A2233
iPad Pro12.9 inch (5th generation) A2377/A2459/A2301/A2460
iPad Pro12.9 inch (6th generation) A2378/A2461/A2379/A2462
iPad Pro11 inch (2nd generation) A2602/A2604/A2603/A2605


Instructions for use

1. The version of the iPad tablet cannot be lower than 12.2;
2. Open Settings-Memo-turn off the apple pencil doodle function;
3. Open Settings-Bluetooth, close the connection of the original Apple Pen.
(After completing the above settings, you can use this product normally.)



Bluetooth use


1. Open Settings - Bluetooth - connect pencil;
2. Slide left on the main interface - Edit - add battery components;
3. Function: click back, double-click multitask.




How to Use

How to Charge

1. Please use the type-C charging wire to charge. One end is connected to the USB interface of the stylus and the other end is connected to the USB interface of computer or tablet. (FIG 1)
2. Please connect one end of the adapter cable to the USB interface of the stylus, and plug in 5V DC at the other end Charge the source adapter. (FIG 2)



(FIG 1)




(FIG 2)




(FIG 3)

3. Directly plug the 5V mobile power supply with USB interface into the stylus for charging. Charging process in, the red charging light will light up, and the whole charging time is about 1 hour. (FIG 3)

2. It has a magnetic adsorption function, which can be adsorbed by lightly putting it, and can be adsorbed on the tablet like Apple Pencil.



3. Removable and easy to replace the pen head design, no need to worry about wear! (Twist the pen head to easily remove/install).



(Remove) (Install)

Power prompt

State	Indicator light	Battery level
work	A light is on	5%-30%
	AB light is on	30%-70%
	ABC light is on	70%-100%
Low power	A light flashes	Less than 5%
	A light flashes	5%-30%
Charge	A light is on, B light flashes	30%-70%
	ABC light is on, C light flashes	70%-99%
Full	ABC light is on	More than 90%