

Bluetooth Alarm Clock with Temperature & Humidity

PRODUCT INSTRUCTIONS


- Click Synchronization
- Bluetooth
- Temperature
- Humidity
- Dual Alarm
- Large Digits
- USB
- Speaker



Thank you so much for choosing our product,
please read the manual carefully before using the product.


SWITCHING TEMPERATURE DISPLAY UNIT

- While in clock mode, briefly press the "Time Set" button to switch between displaying temperature and time.



CLOCK SETTING


- Long press the "Time Set" button for about 2 seconds to enter the clock setting. The "12H" or "24H" will start flashing. Press the "+" or "-" button briefly to select the 12/24-hour display mode.
- Press the "Time Set" button briefly to enter the hour setting. The hour digits will start flashing. Press the "+" or "-" button briefly to adjust the hour step by step. Long press the "+" or "-" button to quickly adjust.
- Press the "Time Set" button briefly to enter the minute setting. The minute digits will start flashing. Press the "+" or "-" button briefly to adjust the minute step by step. Long press the "+" or "-" button to quickly adjust.



PRODUCT FEATURE


- Super Large Display Screen and Digits
- Automatic Clock Synchronization via Bluetooth
- Bluetooth Speaker with Bass Diaphragm
- Indoor Temperature and Humidity Monitoring
- Dual Alarm with 5 Minutes Snooze
- Temperature unit switchable between °C and °F
- Modern Design with Loud Alarm Ring

BUTTON INSTRUCTIONS




ALARM SETTING

- Press the "Q" button briefly, and then long press the "Q" button for 2 seconds to enter the Alarm 1 setting. The hour digits will start flashing. Press the "+" or "-" button briefly to adjust the hour step by step. Long press the "+" or "-" button to quickly adjust.
- Press the "Q" button briefly to enter the minute setting. The minute digits will start flashing. Press the "+" or "-" button briefly to adjust the minute step by step. Long press the "+" or "-" button to quickly adjust.
- Press the "Q" button briefly to enter the Alarm 1 volume setting. The volume value will start flashing. Press the "+" or "-" button briefly to adjust the volume step by step. Long press the "+" or "-" button to quickly adjust the volume value.
- Press the "Q" button briefly to save and exit the Alarm 1 setting.
- The method for setting Alarm 2 is the same as setting Alarm 1.




POWERING ON THE ALARM CLOCK



BLUETOOTH CONNECTION

- Long press the "BT" button (about 2 seconds) until the power-on sound is heard and the Bluetooth icon on the display flashes.




TURN ON/OFF THE ALARM

- In clock mode, press the "Q" button or "Q" button briefly to display their respective alarm times. Then, press the "Q" button or "Q" button briefly to turn on/off the alarm. The corresponding alarm icon will indicate that the alarm is turned on, or vice versa if it's turned off.




ALARM VOLUME ADJUSTING

- When the alarm goes off, the alarm icon will flash. If there is no response, the alarm will continue to ring for 60 seconds.
- During the alarm, press the "+" or "-" button briefly to adjust the alarm volume. Press and hold the button to continuously adjust the volume.



- Turn on your mobile phone Bluetooth, look for the available devices, then click on the device name to connect. After connecting, the Bluetooth permission will appear. Choose "Allow" to automatically synchronize the clock of the product with your phone.




- While playing a song, you can pause or resume the music by briefly pressing the "BT" button.




- Long press the "+" or "-" button to select the previous or next song for playback.
- Short press the "+" or "-" button to increase or decrease the volume. The display screen will show the volume level, with "00" indicating the minimum volume and "16" indicating the maximum volume.

- Click twice on the "BT" to disconnect the Bluetooth connection.




BRIGHTNESS SETTING

- When the product is powered on, the screen brightness defaults to the highest level.
- Touch the "BT" button to adjust the screen brightness.
- The screen brightness can be adjusted in 4 levels: high, standard, low, and off.



SNOOZE FUNCTION

- When the alarm goes off, pressing the "BT" button will activate the snooze mode. The alarm will pause and the icon will flash. After 5 minutes, the alarm will resume. Pressing the "BT" button during this period will cancel the snooze.
- Pressing any button on the backside during the alarm will stop the alarm without activating snooze, except for the "BT" button.



RESET ALARM CLOCK

- While in clock mode, press and hold the "+" and "-" buttons simultaneously for about 2 seconds. The screen will display all the content and then reset the alarm clock.



FC CE RoHS Made in China

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment