

## Contact our experts

# support@yelaw.net

#### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- $\operatorname{--Increase}$  the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

CR1002 FM & BLUETOOTH Clock Radio CREATE A PERFECT SLEEP ENVIRONMENT

https://www.yelaw.net






Made in P

Version 1.3

## **Chapter 1 PRODUCT DIAGRAM**



## Buttons

- 1. FM & Bluetooth Mode
- 2. Play & Scan
- 3. Previous & Hour
- 4. Next & Minute
- 5. Volume Down
- 6. Volume Up7. Dimmer & DST
- 8. Store & Pair
- 9. Recall & Sleep
- 10. Time & 12/24H
- 11. Set Alarm
- 12. Alarm ON/OFF
- 13. Snooze & Night Light


- Parts
  14. Display
- 15. Radio Antenna
- 16. Speaker
- 17. Type C Charging Port
- 18. USB Charging Port
- 19. DC IN Port

## **Chapter 2 OUTLET POWERED & BATTERY BACKUP**

1. Pull the insulator out of battery compartment to activate Cr2032 as backup battery.

NOTE: Backup battery(included) doesn't support time display, only support back up Time & Alarm setting.

2. Connect the adapter to DC jack , then plug into a 100~240V AC wall power



#### **Chapter 3 TIME SETTING**

1. Press TIME button once, display



2. Press button to set the hour and

press MIN

button to set the minute.

3. Press TIME 12/24H

button to save time or wait for another 10 seconds to

confirm automatically.

4.Hold press



button to change 12H/24H time format.

-01-

#### **Chapter 4 ALARM SETTING**

1. Press button, the alarm indicator ALM lights up, the display starts flashing.

2. Press button to set hour, press button to set minute.
 3. Press ALARM SET button to save setting or wait for another 10 seconds to

5. Press ALARM or wait for 10 seconds to save alarm setting.

NOTE: If you select wake up to FM Radio, Radio channel you listened last time will be

the default radio alarm.

In standby mode

Press and button to adjust the volume alarm ring of your preference.

Press ALARM on/OFF to turn on or turn off the most recent alarm.

## When alarm goes off

1. Alarm will ring every next 9 minutes.

2. Press ALARM on/OFF to turn off the alarm for 24 hours, the alarm indicator Still be on, alarm will be activated again after 24 hours.

3. To completely turn off the alarm, double press ALARM OFF , the indicator will turn off.

...

2. Manual Tuning Radio Channel

Chapter 5 FM RADIO

radio is turned on.

Repeat HOUR or button to tune into the desired channel.

3. Auto Scanning Radio Channel.

Press button to start auto channel scanning, radio will store available channel to P01, P02, P03.......P20.

4. Manual Store Radio Channel

Select the radio channel which you desire, press

store PAIR button, display will be stored.

store PAIR button, display will be to select or with the stored.

5. Preset Channel Recall

or button to switch preset channel, then press button to select the channel which you desire, such as PO3

RECALL then press button, radio will confirm your selection.

6. Adjust Radio Volume

Repeat () or vol. button to adjust the FM radio volume.

- 03 -

#### Chapter 6 BLUETOOTH

#### CONNECTING & DISCONNECTING

1. Repeat button until it's in Bluetooth mode.

2. Once in Bluetooth mode the indicator will flash while searching for the last connected device.

3. If the Last connected device is not found, the CR1002 will search for another available device.

4. Select CR1002 from the Bluetooth list on your device to start pairing.

5. Once pairing is successful, the indicator will stop flashing and a beep will sound for speaker.

6. Press STORE PAIR button to disconnect your device from CR1002. A beep sound to confirm the device has been disconnected successfully. CR1002 will now be in pairing mode again, allowing you to pair a new device.

## **PLAY OPERATION**

1. Repeat or button to adjust the volume.

2. Press button to play or pause the music.

3. Press button to play previous music, press button to play

the next music.

## Chapter 7 SLEEP TIMER SETTING

In Bluetooth mode or FM mode, hold press SLEEP button to set the sleep timer, fall asleep with the radio by presetting it to play for a certain amount of time.

- 05 -

#### Chapter 8 DST SWITCH

1. Hold press Button to add an hour to the current time on the display, the DST indicator will light up.

- 04 -

2. To turn off DST, hold press DIMMER DST utton again, the indicator will disappear from the display and the current time will be cut down one hour.

#### **Chapter 9 DIMMER**

Repeatedly press DIMMER button to adjust the brightness of display to your preference.

### Chapter 10 NIGHT LIGHT

1. Turn on NIGHT LIGHT

Press SNOOZE / LIGHT button then the night light will turn on.

Turn off NIGHT LIGHT

Long press SNOOZE / LIGHT button for 2 seconds or press it
repeatedly until the pight light turns off

repeatedly until the night light turns off.

3. Switch NIGHT LIGHT Color

to switch to the color as you desired.

The night light colors are as below: Oyster White, Cobalt Blue,
Sky Blue, Green, Sunrise Orange, Shocking Pink, Violet.

When the night light turns on, you can press SNOOZE / LIGHT button

- 06 -

# Chapter 11 USB CHARGING

Plug charging cable into device such as phone or tablet.

Then clock can charge your phone or tablet.

The maximum charge current is 1 Ampere.