


User Manual

YAI707W-009APP



Thank you for using our products
Please read this carefully before use

-1-


Product Description

This product has an elegant appearance and perfect touch. It has super strong vibration and multiple vibration modes. You will get vigorous sexual stimulation. Product safety and environmental protection are part of our design philosophy. We hope to provide the user with an excellent experience. It is destined to be an extraordinary product.

- 1.Material: Food-grade silicone, ABS
- 2.Max noise: ≤50db
- 3.Battery: 300mAh rechargeable lithium battery
- 4.Charge: USB 5V 300mA DC charge, Charging/Using Time: 1H/1H
- 5.Waterproof rating: IP65


※ Package: 1×Vibrator, 1xUSB charging cable, 1×User manual.

Instruction



-2-

Charging Guide



1

Put the DC charging plug into the hole in the motor part to charge. Then insert the USB charging plug into the USB port of your computer or other charger(output:5V=1A or 5V=1.5A).



2

When product is charging, the LED will be flashing.

3

When a solid light appears, charging is complete.

※When being charged, the toy must be in shutdown state and cannot be used.

-3-

Usage

I. Download and install "Love Spouse" APP

IOS system

- 1. Search for " Love Spouse" in App Store, download and install.
- 2. Scan the QR code with your mobile phone, and follow the prompts to download and install the " Love Spouse" APP.

Android system

- 1. Search for "Love Spouse" in Google Store, download and install (It is recommended to use this method for download).
- 2. Scan the QR code with your mobile phone and follow the prompts to download and install the "Love Spouse" APP.




QR code

-4-

II. Register and login


- 1. Click the " Love Spouse " icon to enter the APP, please register for the first login.
- 2. Click "New User Registration" and complete the registration with your mobile phone number or email address. When the mobile phone cannot receive the verification code, please use the email to register instead.
- 3. After registration, enter the account and password to login to the APP.



-5-

III. Device binding


- 1. The customer needs to bind the device after logging in for the first time.
- 2. Click "+", the device binding scan box will appear.
- 3. Scan the device identification code on the product packaging box or manual, and the product icon will be displayed on the APP after the scan is successful.
- 4. If the customer has purchased several products, please repeat the above 2-3 steps to complete the binding of other products.
- 5. Long press the device icon to delete the device and modify the device name.
- 6. After the device is deleted, if the customer wants to restore it, he needs to scan the device binding code again.



-6-

IV. Equipment connection


First turn on the switch of the device, and then click the device icon in the APP. If the Bluetooth of the mobile phone is not turned on at this time, a prompt box of " Love Spouse " wants to turn on the Bluetooth will appear. After clicking Allow, the mobile phone will automatically turn on the Bluetooth (iPhone Manually turn on the Bluetooth switch). At this time, the device and the phone begin to establish a connection, and enter the device control interface after the connection is successful.



-7-


V. Mode introduction

- 1. **Classic mode:** Click any icon on the APP, and the device will start the corresponding vibration frequency. At the same time, the icon on the APP will flash, click this icon again, the device will stop vibrating and enter the standby state, and the APP icon will stop flashing.



-8-

- 2. **Music mode:** Click on the music mode or slide the operation interface of the APP to enter the music mode. The APP will automatically search for the music player in the mobile phone. If you click on a music player to play music, the device will vibrate as the music changes. If you want to stop the music mode, click or slide to other control interface.




Note:

If the sound of the mobile phone playing music is too low, it may not be able to drive the device to vibrate. iPhone can only use the music player that comes with the system.

-9-


3. Delimit mode:

- Click on the swipe mode or slide the operation interface of the APP to enter the swipe mode. Tap "+", swipe your finger on the phone screen, and the device will vibrate with the change of the swipe. You can keep the vibration mode for next use.



-10-


- 4. **Shake mode:** Click on the shake mode or slide the operation interface of the APP to enter the shake mode, and the device will vibrate according to the shaking rhythm and amplitude of your phone.



-11-


5. Interactive mode:

- a. Tap the interactive mode or slide the operation interface of the APP to enter the interactive mode friend interface.
- b. Click the interactive button on the APP homepage to enter the interactive mode friend interface.
- c. Add friends.
- d. On the friend interface, click the friend button at the bottom and the friend search box will appear.



-12-

- e. Friends search can search for corresponding registered users by gender and age, and can also search accurately by ID number, nickname, mobile phone number, and mailbox.
- f. After the search results are displayed, you click the add button on the right, and the system will send the friend request information to the target user.
- g. After the other party receives the message of the friend application, click the message button to enter the message center to view the message (the red dot means: unread), agree or reject the other party's friend application, if agreed, the mutual friend addition is successful.




-13-

- h. After the friend is successfully added, long press the friend icon to comment, delete, black out, and report the friend.


- I. Click the icon of the friend you want to interact with, the system will initiate an interactive invitation, if the other party accepts your invitation, the interactive connection is successful.

Note: If the other party is not connected to the toy, your interactive interface has no control buttons at this time. The toy must be connected to the other party to have control buttons on your interactive interface. The device connection button on this interface is the Bluetooth icon in the upper right corner.



-14-

- j. After the interactive connection is successful, the video is not turned on by default. You must first invite the other party's video and the other party agrees to open the video function before opening both parties.
- Note:** When interacting, the control button is to control the other party's device, not your own device.



-15-

Attention

- 1. Please charge the product properly in a safe place.
- 2. Water-based lube is suggested as lubricant. Do not apply massage oil or hand cream to the toy surface.
- 3. Stop using the product, if you feel uncomfortable or you find it is no longer smooth or has sharp edges.
- 4. Not recommended to use it below one meter in the water.
- 5. Please clean it before and after use with warm water and soap (boiling water NOT allowed), or sometimes with detergent, disinfectant or 75% alcohol.
- 6. Keep it in cool and dry place. Avoid direct sunlight.
- 7. Keep it out of reach of children.
- 8. The product contains lithium battery. Please put it in the non-recycle bin for disposal.



Made In China

-16-

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that maycause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-17-