J9 Gift *Flip* Mini Phone
User Manual

Newest

J9 Support GSM-Iphone4 Micro-Sim Card
Intert Card Show

The Smallest Flip Mobile Phone In The World!

Made In China

1. J9 Gift Flip Mini Phone: Three Functions In One Machine. **Earphone** + **Bluetooth** + **Flip Mini Phone**. The Smallest Flip Mobile Phone In The World!

2. GSM850/900/1800/1900 Together. 2G GSM Network.

3. Support: Iphone4 Sim Card Use As a Mobile Call Phone, Message, Bluetooth, Phonebook Sync, MP3,Music, SOS, Alarm, Radio, Magice Voice Changer, ect.

4. *12* Kinds of Foreign Language.

5. *13* Kinds of Magic Voice Changer.

6. *13* Kinds of Volume Controlled Setting.

7. Can Choose Many Kinds User Profiles. Such As: General，Silent，Meeting，Indoor，Outdoor. Satisfy Different Environment.

8. Standby for 3 Days, Talking 3-4 Hours.

9. When with sim, can enter the "Setting" to choose "after 10 seconds Auto answer"!

Remarks / Warming:

■ Pls choose and set the equal volume.

■ Warming you and save your hearing.

■ Using high volume will be dangerous for your hearing.

■ Pls put the sim card when the J9 turn off. Turn on after with sim.

■ Pls make sure the sim card correct and operation method right.

■ Pls check the above sim card operation picture.

11. USB Charging

7. REC/SPK

3. Up Key

1. Left Key

5. Send Key

4. Down Key

8. Remove button lock
"Left Key"And "*"

2. Right Key

6. End Key

12. "4" "5" and "6" Key
Second menu choose Key

9. Press this key button "#"
for 3 seconds Can change to
Silence mode or General mode.

10. Reset key:
Press this key button
Will be restore factory settings.

(1)Press the Left Key operation into the interface.

(2)The factory default state is Cell Phone model.

Means: The default calling voice come from the front telephone receiver, the calling ring is from the loudspeaker.

You can enter into "Setting" to set the J9 as headset mode.

Cell phone mode: The voice is from the front of the receiver.

Headset mode: The voice is from the back loudspeaker.

＊Warming/Remarks: Pls choose and set the suitable volume. Using high volume will be dangerous for your hearing

Message

(1)Write Message:

Press "Left Key" Into selection, sure, send.

Press "Right Key" Enter exit and return to the superior directory.

Press "*" Can choose the punctuation.

Press "#" Can choose the input method.

(2)Inbox: You can read, reply, delete, and so on.

(3)Outbox: You can check the sent message.

(4)Draft box: You can check the message has not been sent.

(5)Sent box: You can check the sent message.

(6)Common phrases: System will provide some common sentences, the user can edit or delete.

Address Book

Press "Left Key" Into selection.

Press "Right Key" Enter exit and return to the superior directory.

(1) Fast Search: Input the existing contacts name or the first character name can find relevant contacts.

Put the "*" and "#"key to change the adress book view and search.

(2) Write the new address book into the phone:

◆Write the new address number→ ◆Put the left key→◆Choose "Add to contacts"→◆Put the left key →◆Choose "Add to the new contacts" → ◆Put the left key, When see the "Name", Enter the "5"key into write the name→◆Write the name ("#"key can change the write method) → ◆Sure twice the left key can keep the new address book OK.

◆Enter the Contacts, default search, you can put the "*" and "#"key to change the adress book view and search.

(3)Capacity: Check the usage of the phone book, the SIM card can save about 500 numbers, the phone can save about 500 numbers.

Call Log:

Press "Left Key" into selection function.

Press "Right Key" enter exit and return to the superior directory.

Press "Up" or "Down" keys into the directory option.

(1) Missed Call   (2) Dialed Call   (3) Received Call

(4) Refused Call   (5) Delete Call   (6) All Time

Settings

(1) Call Settings:

——Call Transfer   ——Call Waiting

——Call Darring   ——Hide this phone number

——Other Settings:

Include the IP, every minute of the voice prompt, automatic reply, any key answer, to electricity, refused then reply, on flight mode.

(Note: When with sim, can choose after 10 seconds Auto answer)

(2) Profiles:

Five modes can choose: General Mode, Silent Mode, Meeting Mode, Indoor Model, Outdoor Model.

Each mode can be set different phone ring, volume size, type, telephone voice, ring type, etc.

(3) Phone Settings

——Time and date settings

——Language: 12 languages system can choose.

①English,   ⑦Espagnol

②عربي,   ⑧ภาษาไทย

③Français,   ⑨Tiếng Việt

④चीनी,   ⑩فارسی

⑤Portuguese   ⑪Deutsch

⑥Русский язы,   ⑫Naar Nederland.

——Automatic switch machine settings: According to users needs, set up automatic on-off time.

——Power Management: You can check the power.

——Restore Factory Settings: Setting the phone to factory default setting.

(Note: The factory default PIN: 1234)

(4) Display Settings:

——Backlight screen（30 /20/15/10/5s/ normally open）

————Backlight button（30 /20/15/10/5s/night mode/close）

————Auto keylock（30 /20/15/10/5s/close）

(5) Security Settings

(6) SOS Settings

You can set 2 SOS call number and one urgent message.

FM Radio

(1) Radio Function, it can be use when J9 insert the right headphones line (5PIN headphone ports).

(2) FM radio station can support automatic search and manual input function. When the radio provide FM radio service, you can see and listen to the radio on the related stations.

(3) Use the FM radio services must be meet the following requirements:

————Radio and Internet service providers must be support this service.

——Must be defined the Internet access points to access the network operators FM radio service.

————Manual input the right rating identification code.

And you have opened the FM radio services.

(Note: Use the headsets, pls choose the suitable volume.)
(Using high volume will be dangerous for your hearing.)

Music

(1)Music Function: When the J9 Bluetooth Function had connect with mobile phone, So Music function can use.

(2)After enter into music control interface, it can operate the following steps:

————"Up" or "Down" keys can convert the songs.

————"Left key" control play/pause.

————Press "*"can reduce the volume.

————Press "#"can increase the volume.

Apply

Alarm: Three different clock can be set.

————Press the left function key operation into the interface.

----Press up or down keys　into the choice.

---- Press " 5 "　key to enter the alarm settings in detail, including time, different ring, ring mode, etc.

Bluetooth

(1) The phone device name "J9".

Users can change as you like or hobbies.

(2) Activate the Bluetooth:

The factory default "Bluetooth" set "off" status. If you want to use the "Bluetooth" function, please setting activated.

(3) Paired Device:

The "Bluetooth"pairing operation method:

→Open the "Bluetooth" function

→On the phone to search bluetooth "J9" and sure

→On the phone choice model "J9" to matching

→On the "J9" to make confirm

→Phone authorization confirmation

→The music ring come from "J9"

→Successful connection

(Note: If the J9 mini phone name you have changed, use the changed name to pairing , then according to the above methods.)

(4) Syncing the address book:

The methods to syncing the address book :

→Open the "Bluetooth" function and successful connection

→Enter into the address book main menu

→press the right function key

→Synchronize the other mobile phone number

→Successful syncing

(5) Bluetooth Dial-up:

→"Bluetooth" function and successful connection

→Can use J9 phone to control calling

→Press "Up" or "Down" keys to control the volume.

(6) Bluetooth Distance:

J9 Gift Flip Mini Phone

The Bluetooth distance call: Within about 10 meters.

The Bluetooth distance listen music: Within 10 meters.

(7)Bluetooth Prevention Function:

When the phone and J9 distance is more than 10 meters, J9 will be automatically disconnect and prompt. When the distance above 10 meters, J9 will sound a warning missing remind.

Magic Voice

(1) Activate the magic voice:

The factory default "Magic Voice" set "off" status.

If you want to use, please enter the menu open and set.

(2)Magic Voice settings:

→Press the function key operation into the interface

→Press "Up" or "Down"   keys into the choice

→ Press " 4 " or " 6 " can choose and convert the magic voice types and styles.

(3)Magic Voice Types and Styles:

→Timbre: Young, Cartoon, Old, Child, Man, Woman.

→Roles: Rap woman, Rap man, Wall.e, Eva, Robot, Donald Duck, Optimus.

→Effect: Under water, Chorus, Reverb, Wander, Echo, Metal.

→Equalizer: Speech2, Speech1, Opera, Blues, Classical, Jazz, Country, Dance, Metal, Rock, Pop, Suggest.

→Background Music: Field,   Forest,   Rain,   Wind.

◆Thank yor for your support! Hope the J9 smallest flip mobile Phone can give you the best suprises! Your satisfaction is our greatest support! Any good ideas, Please contact our online store. Thank you! ◆

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Specific Absorption Rate (SAR) information:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: This device has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the phone kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 10mm separation distance between the user's body and the back of the phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.