

**蓝牙耳机
使用说明书**




M-D8
听音乐的同时还能聆听外面的声音

• 请确认您的蓝牙耳机配有下列物品：USB充电线、蓝牙耳机和使用说明书

入门指南

耳机概述




启动蓝牙耳机

- 开机：长按多功能键约3秒，蓝灯闪3次；
- 关机：长按多功能键约5秒，红灯常亮；
- 配对：长按多功能键约5秒，红蓝灯交替闪烁，进入配对状态；
- 接听/挂断电话：单击多功能键，即可接听来电或挂断正在的通话；
- 拒接来电：长按多功能键约2秒；
- 听歌/暂停：单击多功能键暂停播放；
- 语音唤醒：唤醒Siri长按2秒；
- 来电：不亮灯，来电报电话号码；
- 重拨：双击多功能键；
- 语音切换：长按模式下同时按音量+音量按键；
- 低电量提醒：电量低
- 超出连接范围断开提醒：已断开/已连接；
- 充电时：长亮红灯；
- 充满时：长亮蓝灯；

蓝牙版本5.2 待机时间 约140小时 传输距离 10M 充电电压 DC 5V

通话时间 约 8 小时 电池容量 150mAh 充电时间 约 2 小时

耳机配对



1. 长按多功能键5秒，这时指示灯红蓝灯交替闪烁，耳机进入配对状态。

2. 打开手机上的蓝牙，搜索到对应耳机配对名(M-D8)点击配对连接。

待机过程中，双击多功能键，即可重拨最后拨打的号码。以后使用，不需要进去配对状态只要长按多功能键3秒至耳机开机(蓝灯闪3下)，就会自动回连和耳机最后一次配对成功的手机！

断开耳机与手机的连接

要断开耳机与手机的连接（例如：将手机连接至其他蓝牙设备）
请采用以下任一方式：

- 关闭耳机
- 关闭手机蓝牙
- 将耳机移至距离手机10M(约30英尺)以外的距离

耳机没有声音？

- 1. 请确保耳机已启动并完全充电。

手机与耳机连接不上？

- 1. 请确保耳机与手机配接。
- 2. 请确保手机的蓝牙装置已被启用。
- 3. 请确保耳机位于手机10米范围内，而当中并没有任何障碍物，例如墙壁或其它电子器材等。

注意：请使用原厂专配充电线，充电电压不能高于5V！

耳机佩戴

根据佩戴耳机的具体位置，对耳套相应的略作调整。

疑难排解

- 听到【咔咔】的声响？
因蓝牙的协议距离是空旷地段，无障碍情况下可以达到10M，其中人体对蓝牙耳机来讲也是一种最大的干扰障碍，我们建议您把耳机戴在手机的同一侧，以达到最佳的使用效果。

耳机没有声音？

- 1. 请确保耳机已启动并完全充电。

手机与耳机连接不上？

- 1. 请确保耳机与手机配接。
- 2. 请确保手机的蓝牙装置已被启用。
- 3. 请确保耳机位于手机10米范围内，而当中并没有任何障碍物，例如墙壁或其它电子器材等。

如以上步骤未能解决问题,请尝试以下操作:

- 重新把耳机充电。
- 重启手机。
- 启动手机蓝牙功能并且删除以往所在配对历史记录！
- 将蓝牙耳机重新与手机进行配接！

注意事项:

- 切勿把本耳机放在车内安全气袋的位置上，因为当安全气袋弹出时，可能会引起严重的伤害。
- 切勿让儿童玩耍本耳机，细小的零件可能令儿童有窒息的危险。
- 医院、爆破地点或潜在爆炸环境的地方，可能会要求用户关掉电子器材及无线电装置。当进入特定范围内请留意有关指示。
- 登机前请先把耳机关掉，在飞机内不可使用本耳机。
- 为更好的保护您的听力，请勿把音量调得太大。
- 切勿试图对本耳机作出任何修改或拆卸。
- 切勿在潮湿或雨中使用本产品。
- 当处于充电状态时，请勿清洁本耳机。应先把耳机及充电器分开，再进行清理。

* 在接受服务时必须提供此保卡，请妥善保管！

**WIRELESS Headset
user's Guide**




M-D8
Open ear design and comfortable

• Make sure your Wireless headset is equipped with the following items: USB charging cable, Wireless headset and instruction manual

Getting Started Guide

Headset overview




Open the Bluetooth headset

- Power on long press the multifunction button for about 3 seconds, and the blue light flashes for 3 times;
- Power off: long press the multifunction button for about 5 seconds, the red light is always on;
- Pairing long press the multifunction button for about 5 seconds and the red and blue lights will flash alternately to enter the pairing state;
- Answering up the call: click the multifunction button to answer an incoming call or hang up an ongoing call;
- Reject call: long press the multifunction button for about 2 seconds;
- Listen/pause: click the multifunction button to pause playing;
- Voice wake up: wake up Siri long press for 2 seconds;
- Incoming call: no light, broadcast caller number;
- Redial double click the multifunction button;
- Voice switching automatically press volume + volume - button in paired mode;
- Low power reminder low power;
- Disconnected beyond connection range reminder: disconnected/connected;
- When charging red light is on;
- Full charging blue light is on;

Wireless version:5.2 Standby time: about 140 hours Transmission distance:10M Charging voltage:DC 5V

Talk time: about 8 hours Battery capacity: 150mAh Charging time: about 2 hours

Headset pairing



1. Long press the multifunction button for 5 seconds, when the indicator light red and blue flashes alternately, and the headset enters the pairing state.

2. Open the Wireless on the mobile phone, search for the corresponding headset pairing name (M-D8) and click the pairing connection.

In the standby process, double-click the multi-funtion key, then can last number redialing.later use,only press multifunction key 3 seconds then turn on (blue light fasn 3 time), it will automtically connect with last time succeed match phone.

Disconnect the headset from the phone:

To disconnect the headset from the phone (For example, connect your phone to another Bluetooth device), use one of the following:
Turn off headphones:

- Use the phone's Wireless function to disconnect the
- Turn off Wireless function of your phone
- Move the headset to a distance of 10M (about 30 feet) away from the phone

Does the machine have no sound?

- 1. Make sure the headset is activated and fully charged.

Headset charging

The red light of Wireless headset is always on when charging, and the blue light of Wireless headset is always on when fully charged.

charging votage can not be higher than 5V!

Headphones to wear

According to the specific location of wearing headphones, the corresponding slightly adjustable ear sets.

Troubleshoot

Heard the sound of [Kaka]

- Because the Bluetooth agreement is open from the open location, accessible circumstances can reach to 10M, in which the human body is also the largest in terms of Wireless headset dry we recommend that you put your headphones on the same side of your phone to achieve the best results.

• Does the machine have no sound?

- 1. Make sure the headset is activated and fully charged.

• Phone and headset is not connected?

- 1. Make sure the headset is matched to the phone.
- 2. Make sure your phone's Bluetooth device is enabled.
- 3. Make sure the headset is within 10 meters of the phone and not any obstructions, such as walls or other electronic equipment.

• If the above steps do not resolve the issue, try the following:

- re-charge the headset.

B. restart the phone.

C. start the phone Wireless and delete the previous pairing history!

D. the Wireless headset to re-match with the phone!

Precautions:

- Do not place this headset in the position of the airbag inside the vehicle when the airbag pops up, it may cause serious injury.
- Do not let children play the headphones, small parts may make children have the risk of suffocation.
- Hospitals, blasting sites or places where potentially explosive atmospheres may be ask the user to turn off the electronic equipment and radio, when you enter a specific area please pay attention to the instructions.
- Before boarding, please turn off the headset, to the aircraft can not use the headset.
- To prevent noise hearing, do not adjust the volume too loud.
- Do not attempt to make any modifications or disassembly of this headset.
- Do not use this product in wet or rain.
- Do not clean the headphone while in the charging state, should first headphones and the charger separately, and then clean up.

Product quality Warranty card:	
ProductMode	
Originof Product	
User Phone	
Sale Location	
Sales Date	
Vendor Name	
Vendor Contact Phone	
Maintenance Records	

* Please provide this warranty card when accepting the service
please keep it safe!

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.