



Good Voice



GV-SA03

OK GoodVoice Personal Sound Amplifier
Instructions for Use



Before you begin	2
Contents	3
“OK GOOD Voice” Overview	4
Bluetooth Earphone	5
Start Using	6
Work with your Mobile Phone ...	8
Use in everyday life	10
Charging the Battery	12
Specification	14
Manufacturer	15
Warranty Card	16




Before you begin

1. Thank you for choosing "OK GoodVoice". Please read the manual before you enjoy the product
2. Please contact with your distributor If you have any questions. Modification of the device is not allowed. Otherwise, you may lose the warranty.
3. Please keep the instruction for use with you.
4. Please keep the device away from the source of electromagnetic or radiation, as these might interfere with the operation of device.
5. Do not wear the device while showering or participating in water activities.
6. Use a soft, dry cloth to clean the device. It must never be washed or immersed in water or other liquids.
7. Keep the product away from heat to avoid burning or damaging to product.
8. Avoid violent vibration or crash the product.
9. Adjust the volume from low level to an acceptable level at the first time startup.
10. The device, their parts should be kept out of reach of children and anyone who might swallow these items, or otherwise cause injury to themselves.
11. Overcharge the device might cause the deterioration of the battery.
12. Battery life may vary from the frequency of use.

Contents

If any contents are damaged or missing, please contact your distributor immediately.



▲Controller



▲Bluetooth Earphones



▲Instruction for use
(including Warranty Card)



▲External Microphone




▲2 in 1 USB charging cable
(Type-C + Micro USB)




▲USB to Type-C charging cable

“OK GOOD Voice” Overview



Bluetooth Earphone



※ The included Bluetooth earphones is exclusively designed for pairing with the controller.

Start Using



1

Turn on the Controller

- ▲ Press two power buttons to turn on the controller.

2

Turn on the Bluetooth earphones

- ▲ Press the power button of Bluetooth earphones for 3 seconds until the blue light flash to power up.
- ▲ place the controll panel on your left side.



3

Put on the Bluetooth earphones

▲ Place the controll panel on your left side.

The earphones will be automatically paired with the controller

- Searching: The blue light (of the Bluetooth earphones) flashes twice at each interval.
- Connected: The blue light flashes once at each interval. The indicator will be lighting.



4

Adjust the Volume

▲ Press "+" to volume up
▲ Press "-" to volume down

※ Audio Feedback can occur at any time, please keep the distance from the Controller to the earphones.



Working with Mobile Phone



Connecting with Bluetooth

- ▲ Press  on controller for 5 seconds until  flashes in the middle of screen.
- ▲ Turn on Bluetooth on your phone.
- ▲ Choose "OK GoodVoice" in Bluetooth setting of your phone.

- ※ When you turn off your "OK Good Voice" or mobile phone, these will no longer be connected. To connect them again, turn on your "OK Good Voice" and mobile phone. Your "OK Good Voice" will then automatically re-connect to your mobile phone.
- ※ If Bluetooth is disconnected from your phone, follow above steps to re-connect.





Answering Phone Calls

iOS

- Answer directly from device: Press  on the controller.
- Answer from your iPhone: Swipe right --> press the speaker --> choose "OK Good Voice".



Android

- Swipe your phone to answer it.
- *Do not answer the phone from device directly.



Enjoying the audio playing on your phone

- Press  to listen to music or video playing on your phone. Press the button again to return to normal mode.

Use in everyday life

When You are in a Noisy Environment

Press  to the noise-reduction mode. It will reduce the ambient noise. Press again, you will return to normal mode.



When You are Watching TV

Put the controller near to TV for better hearing.



When You are in a Meeting

Put the controller on the center of conference room table, which makes following and participating in conversations easier.




Daily Life Scenarios

Using the external microphone or placing the controller near the sound source will help you hear better.



Charging the Battery




Low Battery Red and blue lights flashes in turns
Charging Red light on (when the device is off)
Red light flashes (when the device is on)
Charging Completed Red light off

Charge with a
Type-C cable

Low Battery  displays and flashes on the screen
Charging The battery icon shows the battery level and flashes
Charging Completed Battery icon stops flashing

※ Your "OK Good Voice" is the combination of two parts, please make sure two parts are recharging separately.
※ Prepare a portable charger with you when you are going out to make sure you can recharge your "OK Good Voice" in time.



Low battery Red light flashes
Charging Red light on
Charging completed Red light off

Open the cap of the charging port, and charge with a micro USB cable.

Specification

Controller	Bluetooth Version:4.0 Bluetooth Protocol : A2DP, AVRCP, HFP, HSP Operating Range:10M Bluetooth power : CLASS 2 Bandwidth of Bluetooth : 2.40 – 2.480GHz Battery capacity : 1050mAh/3.7V Use of Time : more than 8 hours, rechargeable Charge of Time : 2~2.5 hours Charging voltage/current : 5V/400mA~650mA (Max) Maximum decibel: 120dB
Bluetooth Earphone Transmitter	Bluetooth Version:5.0 Bluetooth Protocol : A2DP, AVRCP, HFP, HSP Bluetooth power : CLASS 2 Bandwidth of Bluetooth : 2.40 – 2.480GHz Battery capacity : 280mAh/3.7V Use of Time : 8 hours, rechargeable
Bluetooth Earphone	Bluetooth Version:5.0 Bluetooth Protocol : A2DP, AVRCP, HFP, HSP Bluetooth power : CLASS 2 Bandwidth of Bluetooth : 2.40 – 2.480GHz Battery capacity : 280mAh/3.7V Use of Time : 12 hours, rechargeable

Manufacturer

OK Biotech Co., Ltd.

Address: No. 91, Sec. 2, Gongdao 5th Rd.,
Hsinchu City 30070, Taiwan (ROC)

Webseite: www.okbiotech.com

Tel: +886-3-5160258

Made in Taiwan

FCC Warning Statement



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warranty Card

Thank you for choosing "OK GoodVoice". This warranty applies for the period of 12 months from the date of purchase. Please keep the warranty card properly with you.

Name: _____

Address: _____

Phone: _____

E-mail: _____

Production Lot

Number: _____

Date of

Purchase: _____

Purchased

from (Dealer's

Name): _____

1. In the period of warranty, we warrant your new "Good Voice" against defects in material and workmanship. Repair or replacement of your "Good Voice" is subject to the restrictions and conditions described in the following paragraphs.
 - Damage resulting from misuse, abuse, accident, modification, and unsuitable physical or operating environment, natural disasters.
 - Loss, careless handling or tampering, defects or damage by unauthorized service.
2. This limited warranty does not cover accessories such as charging cable, external microphone.
3. This limited warranty is not transferable and applies only to the original purchaser.
4. Altering or removing identification label on the controller might affect your Warranty.
5. The repair or replacement cannot be performed under the warranty if you refuse to provide your information, or without the dealer stamp on the warranty card.

Dealer Stamp



GV-SA03-UG V1-JUN22