


Kathy So Smart PET FEEDER



Model: FC-D02
User Manual

NING MENG CAT

Questions or Concerns



www.ningmengmaosz.com

MANUFACTURER

Shenzhen Haobang Biological Medicine Co.,Ltd.

ADDRESS

2nd floor,building1,xiangxiang Industrial Park,
Shiyan street,Bao'an District,Shenzhen,China



Made In China

Rev_1.1_EN

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	01
EXPLORING YOUR PET FEEDER	03
USING YOUR PET FEEDER	06
CARE AND CLEANING	09
TROUBLESHOOTING	11

Thank you for choosing Kathy So Pet Feeder. Please read this User Manual thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE

When using an electrical appliance, especially when children are present, basic safety precautions

INTENDED USE

- Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with, in or around the appliance.
- Intended for use with dogs or cats only. Do not use this pet feeder with puppies, kittens, dogs or cats not able to reach the food tray or with any physical disability.
- Use the appliance only for intended household purposes as described in this User Manual.


ELECTRICITY SAFETY

- DO NOT operate the appliance if it has a damaged power cord or plug, or if it is malfunctioning or has been damaged in any manner.
- DO NOT immerse power cord, plugs, or the device base in water or other liquid or allow moisture to come into contact with these parts.
- To reduce the risk of electrical shock, do not place or store an appliance where it can fall or be pulled into a tub or sink.
- Always unplug the appliance when not in use, before putting on or taking off parts and before cleaning. Never unplug by pulling on power cord.

RELATED TO USE

- DO NOT attempt to disassemble, repair, modify or replace any part of your product. All servicing should be performed by qualified personnel only. No user serviceable parts inside.
- Only use attachments recommended or sold by the manufacturer.
- Install 4 AA batteries (not included) for back-up power in case of a power outage.
- DO NOT allow pets to chew on or swallow any parts. Cover or hide the power cord with care to prevent pets from biting.
- DO NOT lift the pet feeder by lid, hopper, bowl or bowl holder. Lift and carry feeder using both hands and hopper base, while keeping unit in upright position.
- Install or store pet feeder on a level surface against wall or in a corner to avoid tripping.
- For dry food use only. Do not use wet, canned, moist food or pet food with special shapes, holes or diameter above 16mm/0.6 inch.
- Before leaving for extended time, always replace batteries with new batteries. Check operation frequently to be sure the pet feeder is dispensing properly.
- Dispose of all packaging materials properly. Keep away from children and pets.

SAVE THESE INSTRUCTIONS



Download NING MENG MAO App

Ningmengmao to download the latest version on Apple App Store or Google Play.





SPECIFICATIONS

MODEL	FC-D02
CAPACITY	4L (about 16 cups)
APPLICABLE KIBBLE	2-16 mm / 0.08-0.6 inch dry food
POWER SUPPLY	DC 5V --- 1A Type-C 4 AA batteries (not included) for backup
CONNECTION TYPE	Bluetooth 4.2
IN THE BOX	1 x Pet Feeder, 1 x Stainless Steel Bowl, 1 x Bowl Holder, 1 x Desiccant Bag, 1 x USB-A to C Cable, 1 x Power Adapter


-1-

-2-


Exploring Your Pet Feeder



1 x Power Adapter




USB-A to C Cable



1 x Desiccant Bag
(* Replace every 30 days)

Control Buttons



Settings

- Hold for 2 seconds to enter settings.
- While setting, press once to exit.
- Hold for 10 seconds to restore to factory settings.



Increase

Press to increase time / portion or select meal plan.



Manual Feed

- Press twice to dispense one portion of food.
- When adding food for the first time or after the tank is empty, repeatedly press to dispense the first one portion.



Record

- Press once to record (Max. 10s) with loud voice towards microphone.
- To manually stop, press once again.



Decrease


Press to decrease time / portion or select meal plan.



Confirm

Press to confirm and enter next step.

LED Display



Food Stuck

System Clock / Schedule Setting

Meal Plan: 1-6

Back-up Battery Low

System Clock / Scheduled Time

PTN
Portion: 1-6

Battery Enough

Recording

Bluetooth Connected

Using Your Pet Feeder
Setup & Manual Feeding

-
- Make sure that pet feeder is properly installed before filling the food tank.
 - The pet feeder can also work when only batteries are installed.
 - It is recommended to install batteries for back-up power in case of a power outage.


1. Plug in the included USB-C cable. If desired, install 4 AA batteries (not included) in case of a power outage.	2. Plug in the included power adapter. The LED display will light up indicating the feeder is on.
3. Place the bowl in the bowl holder. Lift feeder and attach the holder to the notch.	4. Remove the lid and place the desiccant bag into the desiccant box under the lid.
5. Fill the food tank with dry pet food and cap the lid. Do not exceed the Max level.	6. Press twice to feed 1 portion manually. You can also schedule meal via buttons or APP.

Scheduling Via Buttons


Setting System Clock




1. Hold for 2 seconds. flashes indicating it enters setting mode.



3. Press or to adjust hour. Then press **ok** to confirm and move to minute setting.




2. Press **ok** once, the hour digit flashes.




4. The minute digit flashes. Press or to adjust minute. Then press **ok** to confirm.


Scheduling Meal Plan



1. Hold for 2 seconds to enter settings. Then press or to select the meal plan.



3. Press or to set the feeding time for the scheduled meal. Then press **ok** to confirm and move to portion setting.



2. flashes indicating the meal to be scheduled. Press **ok** to confirm and move to time setting.




4. Press or to set the portion for the meal. Then press **ok** to confirm. Repeat for other meals (up to 6) if desired.

Or Scheduling Via APP




- Two ways are available to schedule meals (with buttons or APP), choose any way you like.
- Make sure Bluetooth on your smart device is enabled and your device is connected to a secure network.

1.



Download **EB LinkLite App** and install.
Register or login as instructed.

2.



Tap **"Add Device"** and follow the on-screen instructions to add your pet feeder.

3.



4.



Tap **"Meal Plan"** on Homepage and follow on-screen instructions to schedule feeding time and portions.

Once connected, tap **"Done"** to complete. If connection failed, hold the Setting button for 10s to restore to factory settings and try again.


Care and Cleaning




- Always make sure the pet feeder is unplugged before cleaning. Dry all parts thoroughly and reassemble for next use.
- For body part, wipe with a soft and damp cloth only. Do not rinse or immerse in water.
- It is recommended to clean the feeder regularly for the health of your pets.

Cleaning Bowl & Holder


1. Remove the bowl and bowl holder.



2. Rinse clean and air dry thoroughly.





Cleaning Lid, Tank & Dispensing Rotor



1. Remove the lid and take out the desiccant bag.

2. Pull with force to remove the food tank.



3. Twist counterclockwise to take out the dispensing rotor.

4. Rinse clean all parts. Dry thoroughly and reassemble into place.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FC-D02 喂食器

英语说明书

尺寸：120x160mm

材质：封面128g铜版纸过哑胶
内页80g书纸

装订方式：骑马订

2022.04.08 V1.1