

Quick Start Guide

AlfredCam

Open the box, you will see...

Camera

Micro USB cable

Adapter

Alignment Sticker

3M Sticker

Screws & Anchors

Quick Start Guide

Know more about AlfredCam

Microphone
Status LED
IRLED

Reset Button
Micro SD Card Slot
Speaker/Siren
Micro USB
Mounting Stand

Let's set up the device together

01

Download AlfredCamera app on the App Store/Google Play. Launch the app, then Sign In or Create a New Account.

02

Power on the device and wait for the Status LED to slowly blink green.

03

Tap Add a Camera and follow the app instructions to set up your device.

Having trouble installing your new product? Visit AlfredCamera Help Center for further assistance.
<https://alfredcamera.zendesk.com/hc>

Mounting the camera

01

Place the alignment sticker where you would like to place the camera.

02

Use a 8mm drill bit to drill two 25mm deep holes as indicated on the alignment sticker.

03

Hammer in the plastic wall anchors to support the screws.

04

Attach your camera to the screws by sliding down.

Or place the 3M sticker on the mounting stand.

In case you have questions

What do I do when my device is not working properly?

First, reset and reinstall your device.

- Use a paper clip to press the Reset button next to SD card slot
- Wait until the LED turns solid red

Next, follow these steps during installation:

- Connect your router to the Internet and enable Wi-Fi
- Connect your mobile device to your router's 2.4G Wi-Fi
- Ensure that your AlfredCam device is in range of the same Wi-Fi network

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: this device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

US version 1.0 2022/10/28

Guía de inicio rápido

AlfredCam

Al abrir la caja, verá lo siguiente...

Cámara

Cable Micro USB

Adaptador

Cinta adhesiva de alineación

Cinta adhesiva 3M

Tornillos y tacos

Guía de inicio rápido

Más información sobre AlfredCam

Micrófono
LED de estado
LED infrarrojo

Botón de reinicio
Ranuras para tarjetas microSD
Altavoz/Alarma
Micro USB
Soporte de montaje

Configuración del dispositivo

01

Descargue la aplicación AlfredCamera en el App Store/ Google Play. Después de iniciar la aplicación, puede iniciar la sesión o bien Crear una nueva cuenta.

02

Encienda el dispositivo y espere hasta que el LED de estado empiece a parpadear en verde lentamente.

03

Toque Añadir una cámara y siga las instrucciones de la aplicación para configurar el dispositivo.

¿Problemas a la hora de instalar su nuevo producto? Visite el Centro de ayuda de AlfredCamera para obtener asistencia.
<https://alfredcamera.zendesk.com/hc>

Montaje de la cámara

01

Coloque la cinta adhesiva de alineación en el lugar donde desee ubicar la cámara.

02

Use una broca de 8 mm para hacer dos agujeros de 25 mm de profundidad tal y como se indica en la cinta.

03

Con la ayuda de un martillo, coloque los tacos de plástico para sujetar los tornillos.

04

Destlice su cámara hasta que quede sujeta por los tornillos.

Como alternativa, también se puede colocar la cinta adhesiva 3M en el soporte de montaje

En caso de preguntas

¿Qué debo hacer si mi dispositivo no funciona correctamente?

En primer lugar, reinicie y restablezca su dispositivo:

- Use un clip de papel para pulsar el botón de reinicio, que se encuentra al lado de la ranura para tarjetas SD
- Espera hasta que el LED se ilumine de color rojo fijo

A continuación, siga los siguientes pasos durante la instalación:

- Conecte el módem a Internet y active la wifi
- Conecte el módem a la wifi 2.4G de su router
- Asegúrese de que su dispositivo AlfredCam esté en el rango de alcance de la misma wifi

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: this device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.