





Internal Photos**M19000 Pic 1****M19000 Pic 2**

Figure 1 shows the disassembly of the device. The image displays the internal components, including the battery compartment, circuit board, and various electronic components. A ruler is placed below the components for scale.


M19000 Pic 5




M19000 Pic 6




M19000 Pic 7



M19000 Pic 8





Building B and Building E, No. 372-7, Sec. 4, Zhongxing Rd., Zhudong Township, Hsinchu County, Taiwan
Telephone :+886-2-7737-3000
Facsimile (FAX) :+886-3-583-7948

M19000 Pic 11



M19000 Pic 12



M19000 Pic 13




M19000 Pic 14






M19000 Pic 15




M19000 Pic 16






M19000 Pic 17




M19000 Pic 18






M19000 Pic 19



M19000 Pic 20



RF ANTENNA_A

RF ANTENNA_B

Underwriters Laboratories Taiwan Co., Ltd.

Building B and Building E, No. 372-7, Sec. 4, Zhongxing Rd., Zhudong Township, Hsinchu County, Taiwan

Telephone : +886-2-7737-3000

Facsimile (FAX) : +886-3-583-7948