


4-in-1 Wireless Charging Speaker

Instruction Manual

Item Number: MU03045



Contents:

- 1(One) 4-in-1 Wireless Charging Speaker
- 1(One) USB Type-C Charging Cable
- 1(One) Instruction Manual

Product Specification:

Bluetooth® Version: 5.3
Bluetooth® Range: 32 feet
Driver Diameter: 52mm
Power: 5 Watt
Impedance: 3 Ohms
FM Radio Mode
Alarm Clock
Night Light With Brightness Adjustment
Color-changing Light
Charging Input: 5V --- 3A/9V --- 2A
Wireless Charger Output: 5W/7.5W/10W
Power supply by USB-C cable
USB Type-C Charging Cable Included
USB Type-C Charging Cable Rating 3.0A Max
FCC ID:2A6QJMU03045



• Clock setting

• Previous song/TWS/ Volume down

• Next song/Volume up

• Mode/Play/Pause

• ON/OFF/Light control

How To Use:

- **Power on/off:** Connect the speaker to the power adapter using the supplied Type-C charging cable.
Please use power adaptor in 15W or above to boost the speaker.
Press and hold " " to turn on / off the unit.
- **Bluetooth Mode / FM Mode Changing:** Press " " twice to switch between Bluetooth and FM mode.
- **Connect to Bluetooth:**
 - Switch to Bluetooth mode.
 - Search the pairing name "4-in-1 Speaker" from the list of Bluetooth® devices found. Pair the speaker with your phone.
 - You will hear a prompt sound when it is successfully paired.
- **Bluetooth® Music Playback:**
 - Press " " once to play / pause the music.
 - Press " " once to play the previous song. Press and hold " " to reduce the volume.
 - Press " " once to play the next song. Press and hold " " to increase the volume.
- **FM Radio Mode:**
 - Switch to FM radio mode by pressing the " " button twice.
 - Press " " button to scan and save the radio stations with strong signals. The first scanned station will then be played.
 - Press " " button to play the next station. Press " " button to play the previous station.

• Light Setting:

- Warm white light will be lit up as night light when the speaker turns on. Press " " once to adjust the brightness of the warm white light.
- Press " " twice to enter RGB light mode. Press " " once to change to different light colors.
- Press " " twice to turn on/off the light mode.

• Clock Setting:

- Press and hold the "clock setting button" once to enter the clock adjustment mode. The hour display will start flashing. Use the volume button to gradually set the desired hour; Press and hold the button for quicker adjustment.
- Press " clock setting button " once again to enter the minute setting, then use the volume button to gradually set the desired minute; Press and hold the button for quicker adjustment.
- Finally, press " clock setting button " once to complete the clock setting.
- Press and hold " " to turn on/off the display.

• Alarm Mode:

- Press "clock setting button" twice to enter the alarm adjustment mode. The hour display will start flashing. Use the volume button to gradually set the desired hour; Press and hold the button for quicker adjustment.
- Press "clock setting button" once again to enter the minute setting, then use the volume button to gradually set the desired minute; Press and hold the button for quicker adjustment.
- Press "clock setting button" three times to turn on/off the alarm.

Finally, press "clock setting button" once to complete the alarm setting.

- When the alarm rings, press random button to turn it off.

• TWS function:(Need 2 Speakers)

Prepare 2 speakers and turn on, press either " " twice of the 2 speakers to connect TWS. When you hear the tone, that means the TWS connection is successful.

At this time, your phone will only show one Bluetooth name, pair it, then you can hear two speakers playing music at the same time. Press " " twice again to disconnect TWS.

• Use of Wireless Charger

Put the mobile phone that supports wireless charging function on the wireless charging area to charge.

Front

⚠ WARNING:

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker.
- Do not drop, place heavy weight or allow heavy impact to the speaker.
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire.

RF warning statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

Tips: Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

-WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 18 of the FCC Rules.

-NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Bluetooth®

The Bluetooth word mark and logos are owned by the Bluetooth SIG. All other trademarks appearing herein are the property of their respective owners.

¹Depends upon third party device compatibility.

⚠ WARNING: This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

⚠ CAUTION: FOR YOUR SAFETY, the charging cable included with this item is intended for use with this product only.

Distributed By: 1616 Holdings, Inc
701 Market Street, Suite 200,
Philadelphia,PA 19106
Made in China

Back