


BL100

User Manual



I. LED Indicator Description

| | |
|---------------------|--|
| Power On | Blue light on for 3 seconds |
| Pairing Status | Red and blue lights flash alternately |
| Paired Successfully | Blue light flashes every 5 seconds |
| Play Status | Blue light flashes every 5 seconds |
| Power Off | Red and blue light flashes alternately three times |
| Wired Mode Status | No light |
| Battery Low | Red light flashes every 5 seconds |
| Charging Status | Red light is always on, and turns off when fully charged |

II. Button Function Description

1. **○/M** Function description of power key
 - a. In the power-off state, press and hold this key for 3 seconds, LED indicator will change from blue light always on to red and blue flashing alternately, and the headset will enter the pairing mode; turn on the Bluetooth on your device, search for the device name: BL100, click the device name to enter the connection, after connecting successfully, the LED indicator turns blue, and flashes once every 5 seconds;
 - b. After connecting the Bluetooth successfully, short press this key to play/pause the music;
 - c. When coming call, long press this key for 2 seconds to reject the call, and short press to answer the call;
 - d. During a call, short press this key to hang up the call;
 - e. After the call is over, press this key twice in a row to automatically call back to the last group of outgoing calls recorded on the phone.
2. **MM/V+**Function description of the last key
 - a. In music mode, short press to this key increase the volume;
 - b. In the power-on state, long press this key to play last song.
3. **MM/V-** Function description of the next key
 - a. In music mode, short press this key to decrease the volume;
 - b. In the power-on state, long press to play next song.
4. **MIC** Function description of Microphone bottom
 - a. In the power-on state, short press this key to turn on/off the Microphone (with tone);
 - b. In the connected state, long press this key to switch between 2.4GHZ wireless mode and Bluetooth mode.
5. **Light** Function description of the light button
 - a. In the power-on state, short press this key to turn on / off the light;
 - b. In powered-on state, press this key and hold for 10 seconds to clear the connection record of all devices and headset.

III. Jack Function Description

6. Plug in the microphone to make a call, but the microphone switch must be turned on.
7. Plug in the audio cable to headset and plug in audio to device, enter into wired headphone mode, wireless mode powered off automatically.

IV. Switch between a Bluetooth connection

- a. Connect the headphone to the Bluetooth device;
- b. long press the Microphone button, the headset will disconnect the current connection (with tone), and automatically connect to the Bluetooth device, with a prompt tone after the connection is successful.

V. Package

- BL100 wireless headset*1
- Audio cable*1
- Charging cable*1
- User manual*1

VI. Function Parameters

| | |
|------------------|---------|
| Working Distance | >10m |
| Battery Capacity | 1500MA |
| Working Current | 20-50MA |
| Speaker Diameter | 50MM |

| | |
|------------------|-------------|
| Charging Voltage | DC5V |
| Working Voltage | 3.7V |
| Working Time | >24 hours |
| Standby Time | >1500 hours |

Ⅷ. Cautions

- a, Use a 5V 1A/5V 2A charger to charge the headset. The headset charged with over-voltage charging equipment may be damaged;
- b, Please fully charge the headset before use;
- c, Please charge the headset once every 3 months to extend the battery life if it is not used for a long time;
- d, Please do not place the headset in a high-temperature environment, near the fire source, including direct sunlight;
- e, Please do not place the headset in a humid environment or submerged it in liquid, and keep the headset dry;
- f, Please do not disassemble the headset. Attempt to repair or behavior to modify the headset are prohibited;
- g, Please do not excessively drop, impact, scratch the headset, or do other behaviors that affect the function of the headset;
- h, Please do not use the headset at high volume for a long time, for such behavior may cause damage to your hearing;
- i, This product is not children's toys, so children under 14 years old need to be accompanied by parents to use.

Product Warranty Card

| | | | |
|----------------------|--|------------------|--|
| Product Model: | | Product Color: | |
| Purchase Date: | | Purchase Method: | |
| Reason for Warranty: | | User Name: | |
| Contact Information: | | | |

Warranty Description

- 1, Please carefully retain the warranty card and valid proof of purchase, and present them together when the product is sent for repair. If you cannot provide the warranty card or related documents, the product warranty period will be calculated based on the ex-factory date of the product;
- 2, For quality failures within three months from the purchase of the product, the company will repair the product free of charge if it is confirmed by our technical staff that such failure occurs under normal use;
- 3, For quality issues due to the following reasons, the Company will charge the cost of parts when repairing:
 - a, Due to excessive drops, impacts, abrasions, or other acts that affect the function of the headset;
 - b, Due to incorrect operation, negligent use affecting the use of headset;
 - c, Due to high temperature, high humidity, or other irresistible reasons affecting the use of headset;
 - d, Beyond the warranty period;
 - e, The accessories, gifts, packaging parts, decorative items, etc. sold along with the product.

Product Certificate

After inspection, the product meets the technical standards and is allowed to leave the factory.

QC
PASS
TESTED

■ Contact us

Please contact us if you have any questions related to the use, maintenance and safety of your headset, or if you experience a bug/failure with your device. Our professional after-sales maintenance personnel will assist you to solve your problems.

Please have your order number on hand when contacting



Learn more news about the Gikking game headset?

Scan Gikking QR Code to get it soon

E-mail Service for Gikking : gikkingheadset@outlook.com

IX. Video Instruction

Gikking is not responsible for damage caused by unreasonable use, please watch instruction video of Gikking wireless headset before use.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment