

Star Projector

User Manual



English ----- 1

Deutsch ----- 7

English

NOTICE

- Do not look directly into the light source, may cause damage to eyes;
- Please shut off the power immediately When danger occurs;
- Please refer to the respective manual for the projection lamp used;
- The products commonly limited to used in the indoor environment, especially suitable for use indoors at night;
- The brightness of the stars (ie the brightness of the laser), which is affected by the temperature of the use environment and the use time. When the ambient temperature is hot or the boot time is longer, the laser brightness will decrease due to heat. At this time, it can be shut down for heat dissipation (the heat dissipation time usually takes more than 15 minutes). The brightness of the stars can be restored by turning it on again;
- A lot of heat is generated when the circuit is working. It will cause the shell to heat up, which is normal;

BLUETOOTH FUNCTION


- Bluetooth is not turned on by default after booting. Short press the "play/pause" button to turn on Bluetooth, and the Bluetooth name is "SKY-Lamp";
- Insert the TF card when the Bluetooth is turned on, the product will directly play TF card music;
- In the state of playing TF card music, if you need to switch to Bluetooth playback mode, please short press the "Play/Pause" button, and then long press the "Play/Pause" button to switch to Bluetooth mode and turn on Bluetooth.

-1-

PRODUCT PARAMETERS

Material	ABS/PC
Laser Wavelength	532nm
LED Power	< 5W
Control Mode	Remote control
Remote Control Range	< 5meters(Best distance)
Power Supply	100-240V~50/60Hz 0.4A
Work Input	5V=1A
Product Size	150*152*102mm
Applicable Environment	Indoor (Best in a dark environment)
Working Temperature	-10°~45°C
Power cord length	1.2M

Host Key Operation Instructions



-2-

Audio input interface: You can access external audio sources to play music. For example: play music on your phone.

Switch: Short press the switch to turn on the projection lamp. Nebulae and stars will appear when the lights are turned on. Short press the button again to shut down.

Nebula switch: Each time you press the button after powering on, the Nebula will switch a color(A total of 8 modes). The nebula changes back to its default color after a cycle. Long press the button to close the Nebula, and short press the button after closing the Nebula to reopen the Nebula.

Stars switch: The stars have three display modes: The first is the stars always bright mode, The second is the breathing rate 1 mode of the stars (the default mode at power-on). The third is the breathing rate 2 mode of the stars (slightly faster). Each time you press, the star display will switch to a mode. Long press to turn off the stars. Short press after closing to turn on the stars again (default mode).

Previous song/Volume -: Short press the function to enter the previous song to play the song. Long press the button to decrease the volume.


Play/Pause: Short press the button to play/pause.

Next song/Volume+: Short press the function to play the song and enter the next song. Long press the button to increase the volume.

TF card socket: automatically start playing music after inserting the TF card.

-3-

Remote Control Instructions



Switch: Short press the switch to turn on the projection lamp. Nebulae and stars will appear when the lights are turned on. Short press the button again to shut down.

Stars switch: The stars have three display modes: The first is the stars always bright mode, The second is the breathing rate 1 mode of the stars (the default mode at power-on). The third is the breathing rate 2 mode of the stars (slightly faster). Each time you press, the star display will switch to a mode. Long press to turn off the stars. Short press after closing to turn on the stars again (default mode).

Nebula Brightness+: There are 5 levels of nebula brightness. The default brightness is the middle level. Each time you press it, the brightness will increase by one level.

-4-

Nebula change speed-: The nebula change speed is divided into five gears 0-1-2-3-4. Level 0 means that the nebula is stationary. The 4th gear is the fastest changing speed of Nebula. The default gear is 2 gears. Each time you press it, the speed of the nebula will decrease by one level until it reaches level 0.

Nebula color switching: Each time you press the button, the nebula switches a color(A total of 8 modes). Return to the default color after one cycle. Long press the button to turn off Nebula. After closing Nebula, short press the button to re-open Nebula.

Nebula change speed+: The speed of Nebula changes every time you press it by one level, up to level 4.

Nebula Brightness-: There are 5 levels of nebula brightness. The default brightness is the middle level. Each time you press it, the brightness will decrease by one level.

Timing function: The timing function is divided into two levels, namely 45 minutes and 90 minutes. Press the timing button "45", the timing indicator light will light up in blue and accompanied by a beep to enter the 45-minute timing; press the timing button "90", the timing indicator will light up in red, and accompanied by two beeps, enter the 90-minute timing; In the timing state, the timing indicator light is on; long press to cancel the timing, and the timing indicator light is off after cancellation

Play/Pause: Short press the button to play/pause.

Previous song/Volume -: Short press the function to enter the previous song to play the song. Long press the button to decrease the volume.

Next song/Volume+: Short press the function to play the song and enter the next song. Long press the button to increase the volume.

-5-

Guarantee and support

Thank you for your order and great support on us. We sincerely hope that you would give us a chance to our product(s) and service.

Of course , if you have any better suggestions or advice for our product. We are open to hear any suggestions.

If you have any concerns about our product(s), it would be appreciated that you would give us a chance to contact us via Email (support@canpeikit.com), we will get back to you within 24 hours.

Deutsch

TIPPS

- Blicken Sie nicht direkt in die Lichtquelle , um Augenschäden zu vermeiden;
- Bitte schalten Sie den Strom sofort aus, wenn Gefahr auftritt;
- Bitte beachten Sie zum Gebrauch die Bedienungsanleitung.
- Die Produkte beschränken sich üblicherweise auf Innenräumen, insbesondere geeignet für den Gebrauch in Innenräumen nachts;
- Die Helligkeit der Sterne (in die Helligkeit des Lasers) hängt von der Temperatur der Nutzungsumgebung und der Nutzungszeit ab. Wenn die Umgebungstemperatur hoch ist oder die Bootzeit länger dauert, wird die Laserhelligkeit aufgrund der Hitze schwächer. Zu diesem Zeitpunkt lässt es sich zur Wärmeableitung abschalten, (die Wärmeableitung kostet normalerweise mehr als 15 Minuten). Danach ist die Helligkeit der Sterne durch Neustart wiederherzustellen;
- Beim Betrieb des Kreislaufs wird viel Wärme erzeugt, was die Schale in der Regel erwärmt.

BLUETOOTH-FUNKTION

- Bluetooth schaltet sich nach dem Booten standardmäßig nicht ein. Drücken Sie kurz die "Play/Pause"-Taste zum Starten.Und der Bluetooth-Name ist "SKY-Lamp";
- Legen Sie die TF-Karte mit Einschaltung von Bluetooth ein,dann spielt sich TF-Kartenmusik direkt ab.
- Falls Sie beim Laufen von TF-Kartenmusik in den Bluetooth-Wiedergabemodus zu wechseln brauchen, drücken Sie bitte kurz die Taste „Play/Pause“ zuerst und dann lange die Taste „ Play/Pause“, um den Bluetooth-Modus zu starten .

-7-

PRODUKTPARAMETER

Material	ABS/PC
Laserswellenlänge	532nm
LED-Leistung	< 5W
Steuerungsmodus	Fernbedienung
Reichweite der Fernbedienung	< 5 Meter (beste Entfernung)
Stromversorgung	100-240V~50/60Hz 0.4A
Arbeitseingang	5V = 1A
Produktgröße	150*152*102mm
Passende Umgebung	Innen
Betriebstemperatur	-10°~45°C
Länge des Netzkabels	1.2M

Anweisungen zur Bedienung der Host-Taste



-8-

Audioeingangsschnittstelle: Sie können mit externen Audioquellen verbinden, um Musik abzuspielen. Beispiel: Spielen Sie Musik auf Ihrem Telefon ab.

Schalter: Drücken Sie kurz auf den Schalter, um die Projektionslampe einzuschalten. Nebel und Sterne erscheinen mit der Einschaltung der Lampe. Mit erneutem kurzem Drücken wird das Gerät ausgeschaltet.

Nebelschalter: Immer wenn Sie die Taste nach dem Einschalten drücken, wechselt der Nebel eine Farbe (insgesamt 8 Modi). Der Nebel wechselt nach einem Zyklus wieder in seine Standardfarbe. Mit langem Drücken schließen Sie den Nebel , und dann drücken Sie die Taste zum Öffnen wieder kurz.

Sternschalter: Die Sterne haben drei Anzeigemodi: Der erste ist der Immer-Hell-Modus. Der zweite ist der Atemfrequenz 1 Modus (der Standardmodus beim Einschalten). Der dritte ist der Atemfrequenz 2 Modus (etwas schneller). Bei jedem Drücken wechselt die Sternanzeige in einen Modus. Mit langem Drücken sind die Sterne auszuschalten. Nach dem Schließen kann die Sterne durch kurzen Drücken erstarten(Standardmodus).

Vorheriges Lied/Volume-: Drücken Sie kurz auf die Funktionstaste um das vorherige Lied abzuspielen. Drücken Sie länger auf die Taste, um die Lautstärke zu verringern.


Play/Pause: Drücken Sie kurz die Taste, zu starten oder zu stoppen

Nächstes Lied/Volume+: Drücken Sie kurz die Funktion zum nächsten Lied . Drücken Sie lange auf die Taste zur Erhöhung der Lautstärke .

Steckplatz der TF-Karten: Die Musikwiedergabe spielt sich automatisch nach dem Einsetzen der TF-Karte.

-9-

Anleitung zur Fernbedienung



Schalter: Drücken Sie kurz auf den Schalter, um die Projektionslampe einzuschalten. Nebel und Sterne erscheinen mit der Einschaltung der Lampe. Mit erneutem kurzem Drücken wird das Gerät ausgeschaltet.

Sternschalter: Die Sterne haben drei Anzeigemodi: Der erste ist der Immer-Hell-Modus. Der zweite ist der Atemfrequenz 1 Modus (der Standardmodus beim Einschalten). Der dritte ist der Atemfrequenz 2 Modus (etwas schneller). Bei jedem Drücken wechselt die Sternanzeige in einen Modus. Mit langem Drücken sind die Sterne auszuschalten. Nach dem Schließen kann die Sterne durch kurzes Drücken erstarten(Standardmodus).

Nebelhelligkeit+: Es gibt 5 Stufen von der Nebelhelligkeit. Die Standardhelligkeit gehört zu der mittleren Stufe. Bei jedem Drücken wird sich die Helligkeit um eine Stufe erhöhen.

-10-

Nebelwechselgeschwindigkeit-: Die Nebelwechselgeschwindigkeit ist in fünf Gänge 0-1-2-3-4 eingeteilt. Stufe 0 bedeutet, dass der Nebel stationär ist. Der 4. Gang ist die am schnellsten wechselnde Geschwindigkeit. Der Standardgang ist der 2. Gang. Bei jedem Drücken verlangsamt sich die Geschwindigkeit des Nebels um eine Stufe, bis er Stufe 0 erreicht.

Nebelartwechsel: Immer wenn Sie die Taste drücken, wechselt der Nebel eine Farbe (insgesamt 8 Modi). Kehren die Standardfarbe nach einem Zyklus zurück. Drücken Sie lange auf die Taste zum Ausschalten. Und danach drücken Sie kurz wieder zum Öffnen.

Nebeländerungsgeschwindigkeit+: Die Geschwindigkeit von Nebel ändert sich , wenn Sie ihn um eine Stufe drücken, höchstens bis Stufe 4.

Nebelhelligkeit-: 5 Helligkeitsstufen des Nebels stellen zur Verfügung. Die Standardhelligkeit zählt der mittleren Stufe. Bei jedem Drücken nimmt die Helligkeit um eine Stufe ab .

Timing: Diese Funktion ist in zwei Zeitdauer eingeteilt, nämlich 45 Minuten und 90 Minuten. Drücken Sie die Zeitsmesstaste "45", wird die Zeitsmesstaste blau aufleuchten und mit einer Stimmung wirkt die 45-Minuten-Zeitmessung ; Drücken Sie die Timing-Taste "90", dann leuchtet die Timing-Anzeige rot , und insgesamt mit zwei Pieptönen funktioniert das 90-Minuten-Timing; Im Timing-Status bleiben die Timing-Kontrollleuchte hell halten; Zum Abbrechen des Timings wird die Anzeigeleuchte durch langes Drücken ausgeschaltet.

Play/Pause: Drücken Sie kurz die Taste, zu starten oder zu stoppen

Vorheriges Lied/Volume -: Drücken Sie kurz auf die Funktionstaste, um das vorherige Lied abzuspielen. Drücken Sie länger , um die Lautstärke zu verringern.

Nächstes Lied/Volume+: Drücken Sie kurz die Funktion zum nächsten Lied . Drücken Sie lange auf die Taste zur Erhöhung der Lautstärke .

-11-

Garantie und Support

Vielen Dank für Ihre Bestellung und die große Unterstützung für uns. Wir hoffen aufrichtig, dass Sie mit unseren Produkten und unserem Service zufrieden sind.

Natürlich sind wir offen, wenn Sie bessere Vorschläge oder Ratschläge für unser Produkt haben.

Wenn Sie Bedenken bezüglich unserer Produkte haben, würden wir uns freuen, wenn Sie uns die Möglichkeit geben, uns per E-Mail (support@canpeikit.com) zu kontaktieren. Wir werden uns innerhalb von 24 Stunden bei Ihnen melden.

Nochmals vielen Dank, dass Sie unser geschätzter Kunde werden !

-12-

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile device:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Made in PRC
Do not look directly into the laser
Not a toy.