

**WEIBU**

# Startup Guide

User's Manual

Personal Computer

**P116G**

## Supplied User's Manuals

Congratulations on purchasing your WEIBU computer! Your WEIBU computer comes with the following user's manuals:

- **Startup Guide (this user's manual)**

Please read this user's manual first. You can find basic information, including connecting accessories to your WEIBU computer, setting up Windows, and connecting your WEIBU computer to the Internet.

- **Safety Guide/Recovery and Troubleshooting Guide**

Please be sure to read this user's manual. You can find information that helps you use your WEIBU computer safely, including troubleshooting FAQs as well as instructions on recovering your WEIBU computer and creating recovery media.

### !Notes

- Features and apps mentioned in these user's manuals may not be available or preinstalled, depending on the model of your WEIBU computer.
- With the latest Windows updates applied to your WEIBU computer, the operation procedures described in the user's manuals may vary from the actual ones.
- The visual contents, such as illustrations, photos, and screenshots, used in the manuals may look different from what you actually see on your WEIBU computer.

## WEIBU Support Website

You can find the latest WEIBU support information. When you need any help for using your WEIBU computer, visit our WEIBU support website first.

<https://www.weibu.com>

## 1 .Supplied Items

- AC adapter
- Pen
- Startup Guide
- Warranty Book
- Safety Guide/Recovery and Troubleshooting Guide

### !Notes





- Keep the shipping box of your WEIBU computer until you make sure that you have all the supplied items. If you find anything missing or damaged, contact our Support experts via the website or your dealer before you dispose of the box.
- The supplied accessories were tested and found functional solely with your computer.



### CAUTION Hot surface


To avoid burn, do not use the computer on your lap for a long time.

## 2.Locating Parts and Controls



01 Dual microphones  
02 Camera LED Indicator  
03 Camera  
04 Camera Shutter  
05 Touch Pad

06 Pen tray  
07 LCD screen/Touch screen  
08 Stereo speakers  
09 Power button  
10 Keyboard



### 3. Setting Up

#### 1 Connect to a Power Outlet

Plug the AC adapter to the AC charging port on the computer and connect the AC adapter and a power outlet with the supplied power cord. Even when you do not intend to use your computer for an extended period of time, connect it to a power outlet at least every three months and charge the battery to around 50% of capacity. If the computer is kept unplugged from a power outlet for an extended period of time, the battery voltage will drop due to self-discharge to trigger the safety function and the battery may become unavailable for use. The time period before the safety function is triggered varies depending on the ambient temperature.

#### 2 Turn On Your Computer

Lift the LCD screen lid and press the  power button on the computer.

#### !Notes

- When lifting the LCD screen lid, do not grasp the area around the camera as it will cause malfunctions.
- Do not turn off your computer before the Windows Setup window appears.

#### 3 Set Up Windows (Initial Setup)

Follow the instructions displayed on the Windows Setup window to make initial settings.

#### Note

Please refer to Windows Help or Microsoft's website for more details.

#### Tips

#### Connect to the Internet

With your computer, you can connect to the Internet via a Wi-Fi (wireless LAN). Before connecting to the Internet, you need to select a connection service, make a contract with an Internet service provider accordingly, and make the Internet connection settings on the computer. For detailed information on the Internet connection settings and required network devices, refer to the manual from your service provider and the manual that came with your device. Establishing a successful connection to the Internet completes Windows license authentication.

### **Connecting via a Wi-Fi network**

1. Select (start), (Settings), Network & Internet, and Wi-Fi, and then set Wi-Fi to On.
2. Select Show available networks.
3. Select the desired Wi-Fi access point, and then select Connect.

## **Get Ready to Use Your WEIBU Computer**

### **Running Windows Update**

1 Select (start), (Settings), and Windows Update, and then follow the on-screen instructions to update the Windows.

### **Updating WEIBU original software**

To update WEIBU original software, visit our WEIBU support website at the following URL, download update programs, and then install them on your WEIBU computer.

<https://www.weibu.com/>

### **Creating your own recovery media**

Your WEIBU computer does not come with any recovery media. Be sure to create your own recovery media with a USB flash drive before you first use the computer following your purchase. For more information, refer to the **Safety Guide/ Recovery and Troubleshooting Guide**.

#### **!Note**

Always be sure to use the AC adapter to connect your WEIBU computer to a power outlet before doing a recovery.

### **Turning off or placing your WEIBU computer into Sleep mode**

Upon completion of the Windows setup, select (start), (Power), and then Shut down or Sleep.

### **FCC regulatory conformance:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

**NOTE:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

#### **RF Exposure**

The SAR limit adopted by FCC is 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported to the FCC for this device type complies with this limit. The highest SAR value reported to the FCC for this device type when using in portable exposure conditions is 1.04 W/kg.