

BL-35 INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK

Folded Size: 3.2" (w) x 4" (h)

DIELINE:

FOLDING LINE:

OUTSIDE

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



iHip 19 Progress St.
Edison, NJ 08820
www.iHip.com



#iHip



iHip: Portable Entertainment


© 2023 iHip is a trademark, registered in the U.S. and other countries. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Apple, iPod, iPhone, iPad and Siri are registered trademarks of Apple Inc. Android is a trademark of Google LLC. All other trademarks and trade names are those of their respective owners.

The illustrated product and specifications may differ slightly from that supplied. For ages 12+up. This is not a toy. Designed by iHip in the U.S.A. Manufactured in China.

Limited One Year Warranty. Please visit www.iHip.com for warranty information, to register this product, and to activate your product warranty.

Important Information:

Protect the environment by responsibly disposing of your product. The wheelie bin symbol indicates that the product must not be disposed in the domestic waste as it may contain substances that could be harmful to the environment and health. Please use proper recycling facilities when disposing of the item.



INSIDE

Features:

- 5 RGB Light Settings
- 2000mAh Rechargeable Battery
- True-Wireless Pairing
- FM Radio Mode
- USB and TF Card Modes

Package Contents:

- (1) Portable Wireless Speaker
- (1) USB Charging Cable
- (1) User Manual

Specifications:

PRODUCT: iHip LU Speaker
Model No: BL-35
Weight: 260g
SNR: > 80dB
Basic functions: Bluetooth, FM, USB, TF, LED flashing
TWS: 1+1 couple function
Running time: 3-4 hours

Volume of one piece: 0.096m
Product size: 101x50x155mm
Speaker size: 57mm
Output power: 5W*1 (built-in boost)
Rated Voltage: DC 3.7V
Frequency response range: 2402-2480MHz
Battery model: 18650
protection plate

Charging Instructions:

For best results, fully charge the speaker before use.

1. Connect the USB cord (included) to the charging port of the speaker and insert the other end into a port on your computer or similar suitable power source.
2. The red LED turns on, indicating that the battery is being charged. Once it is fully charged, the red LED will turn off. It takes about 2-3 hours to charge the speaker fully.

Turning ON/OFF Speaker

Move the "ON/OFF" switch to the left to turn the speaker ON and to the right to turn the speaker OFF.

LED Light Controls:

When you turn on the speaker, the RGB Light will be auto power on.

- Long press the button to cycle through the light modes.
- Long press the a fifth time to turn off the light.
- Then long press the to turn the light back on.

Bluetooth® Wireless Connection:

Your speaker can wirelessly stream audio from any Bluetooth® enabled device within 30 Feet. Simply follow the steps below:

1. Turn ON the speaker. You will then hear the indication tone.
2. Activate the Bluetooth on your mobile phone, tablet, or computer. It will search for various devices. The pairing name of this speaker is "iHip LU Speaker." Pair it with this device.
3. Once paired successfully, you would hear an indication tone. (If you fail to pair it within the time frame or you want to pair it with a new device please repeat steps 1-4)
4. Select your favorite song on your device and music will now stream through the Bluetooth speaker.

NOTE: The speaker will automatically pair with previously paired devices.

FM Mode:

Press **M** button to switch FM mode / Bluetooth mode.

When in FM mode, press the button to automatically select the station

USB Port & TF Card Port

Use the USB port to connect USB devices. Use the TF card port to connect to TF input. This speaker can play MP3 and WAV music files using the USB disk or the TF card port.

Music Controls:

Please ensure that your device (Smartphone, tablet, or computer) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

- Pause (Playing music): Short press the button once to pause the music
- Play (Paused music): Short press the button once to resume the music
- Previous track (Playing music): Short press the button to play the previous track
- Next track (Playing music): Short press the button to play the next track
- Increase Volume (Playing music): Long press the button to increase the volume
- Decrease Volume (Playing music): Long press the button to decrease the volume

Phone Call Controls:

Please ensure that your cell phone is paired with the speaker to use the below functions.

- Answer Incoming Call - Short press the button once to answer an incoming call.
- End Call - After your phone conversation, short press the button to end the call.
- Volume Decrease (During a call) - Long press the button to decrease the volume
- Volume Increase (During a call) - Long press the button to increase the volume
- Redial last number (Standby mode & connected to a device) - Short press the button twice