

# WIRELESS SPEAKER DIFFUSER INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK


PAIRING NAME: "SPEAKER DIFFUSER"

Dieline —————

Scoring Lines - - - - -

406x89mm

## FOLDING INSTRUCTIONS



 **Wireless Speaker Diffuser**  
INSTRUCTION MANUAL





**READ CAREFULLY AND SAVE THIS MANUAL FOR FUTURE REFERENCE**

**CAUTION**

To ensure safe and proper use, read all safety information before using this device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- This device is not a toy, do not allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not submerge in water.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Low power may cause poor Bluetooth® connection or sound distortion.
- Do not allow the USB Ports, power jack or other inputs of the device to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.
- Do not allow any oil to get inside of the speaker.
- Make sure this device is always placed on a sturdy and level surface.
- Do not add too much essential oil, as it might leak from the sponge and drip inside the speaker.
- Do not insert the sponge into the speaker or place anywhere that it could get stuck.

**LOCATION OF CONTROLS**

Bluetooth LED Indicator, Charging LED Indicator, Power Switch, Fan Switch, Micro-USB Charging Port.

**LED INDICATOR**

Quick Flashing BLUE	Speaker is ready to pair
Slowly Flashing BLUE	Speaker is paired
Solid RED	Speaker is charging

**Charging the Speaker**

Attach the small connector to the supplied micro-USB cable to the USB charging port on the back of the speaker. Attach the large connector to the USB port on a computer, a USB charging device, or a 5V USB adapter (*not included*) and plug into an electrical outlet.

The charging LED indicator will turn RED while charging and turn off when fully charged. When low on power, a tone will be heard, indicating that the speaker should be charged.

**Using the Speaker**

- Slide the (Power) switch to middle position to power the speaker ON. Slide to the Left to Power the speaker and lights ON.
- Slide the (Power) switch to the right position to power the speaker and lights OFF.
- Slide the (Fan) switch to the right position to power the fan ON. Slide to the left position to Power the fan Off.

**Using the Aromatherapy Fan**

- Add ~ 1-2 drops of essential oil to one of the supplied scent pad. Rub the pad and let the oil permeate.
- Remove the fan cover from the speaker and carefully place the sponge onto the platform.
- Replace the cover and power the fan ON. The speaker will emit the aroma of the essential oil.

**Note:** Quality of aroma can differ based on the amount of essential oil used, the brand of essential oil, and the environment (temperature, humidity, wind conditions, etc.)



**Bluetooth Pairing**

- Power the speaker ON. A tone will be heard and the Bluetooth LED indicator will quickly flash Blue.
- Set your mobile device to search for Bluetooth devices. When it appears, select "Speaker Diffuser" from the list of found devices.
- Once successfully paired, a tone will be heard and the Bluetooth LED indicator will turn **Slowly flash BLUE**.

When power ON, the speaker will automatically reconnect to the device it was most recently paired to, so long as that device is enabled.

**Playing Music**

To listen to music on your speaker, make sure it is paired to a Bluetooth-enabled device. For more on pairing the speaker to your device, please consult the **Bluetooth Pairing** section of this instruction manual.

Once paired, you can control media playback and volume adjustment with the control on your paired device.



**Package Includes:**

- Wireless Speaker Diffuser (x1)
- Charging Cable (x1)
- Scent Pad (x3)
- User Manual (x1)
- Lavender Scented Oil (x1)

**FCC STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

 19 Progress St  
Edison, NJ 08820  
www.iHip.com

 #iHip

 Find us on Facebook.  
Keyword: iHip: Portable Entertainment