



Picture Light User Manual



REMOTE CONTROL



Power buttons:

- 1.ON: Turn on the picture light;
- 2.OFF: Turn off the picture light.

Brightness adjustment :

Three brightness levels: 40% 70% 100%

Timing function:

Press to set timing, the lights will flash once.

3 Light colors:

Warm White; Natural white; Cold white

Slightly remove the transparent film before use the remote


Transparent film

Rechargeable Battery

When charging, the indicator light is red.

After being fully charged, the indicator light stays on green.


What's in the box ?




metal hook



magnetic ball



screw accessories



remote control




Type-C charging cable




picture light


Installation




1. Tighten the magnetic ball and metal hook.




2. Draw 2pcs Φ6mm holes on the wall.



3. Install the anchors to the hole.



4. Install the screws in the anchors.




5. Connect the magnetic ball with picture light.


Recommend that the distance between the metal hook and the picture frame > 2 Inch.

Cautions:

1. Please choose the right wall rivets according to different wall surfaces



Suitable for concrete/brick walls



Suitable for drywall walls




Suitable for wood panels walls

OPERATIONS

1. Touch and hold the  button to turn ON/OFF.

2. Click the  button to switch lighting color:
warm white natural white cold white



Dear Customer

Thank you very much for purchasing our product. If you have any questions about installation or use, please contact us by email.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.