


Receiver function description

MICROPHONE

Model: E6 / E7 / E8

USER'S MANUAL

Please read this manual carefully before use



- ① 6.35mm audio plug: connect all kinds of speaker karaoke input
- ② Power switch: toggle up and down to control the power of the receiver
- ③ Charging power indicator: Charging, flashing when booting
- ④ USB charging port: DC5V power input
- ⑤ Receive indicator light: flashing when using the microphone

Handheld Microphone Transmitter Function Description



- ① Pickup: for microphone reception, suitable for all kinds of sound source input
- ② HD LED display: for viewing microphone data
- ③ Power switch: toggle left and right to control the power of the microphone
- ④ Power indicator: low voltage power indicator
- ⑤ Battery compartment: open the tail pipe and install the special battery No. 5.
- ⑥ Tail tube plastic head: different colors, used to distinguish frequency points

— 1 —

— 2 —

— 3 —



- ① HD LED display
- ② 3.5mm threaded interface
- ③ Power switch
- ④ Work indicator
- ⑤ 3.5mm threaded plug
- ⑥ Capacitor head

Basic parameters

1. Frequency range: 175.1MHZ-215.9MHZ
2. Carrier frequency: 200KHZ
3. Receiving distance: 50M
4. Frequency response: 50HZ-18KHZ
5. Signal to noise ratio: >90db
6. Modulation method: VHF modulation
7. Pickup method: moving coil
8. Output level: 200MV ± 5MV
9. Power: 2th battery

Precautions

- 1: When using the microphone, avoid placing dead corners to keep the signal receiving well.
- 2: Do not throw, drop, throw, etc. when using the handheld microphone to avoid serious damage.
- 3: The body is not waterproof, should avoid water droplets directly into the fuselage or sun or rain.
- 4: Try to stay away from the electromagnetic sound field, high-voltage transmission network, and large metal objects.
- 5: If the receiver does not work for a long time, turn off the power.

After-sales service warranty description

- 1: All accessories except microphones, receivers and transmitters do not have a warranty.
- 2: The mic and receiver (all) batteries do not have a warranty.
- 3: Man-made damage or wear and aging does not include warranty.
- 4: The electrical performance warranty is 1 year.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

Warranty Card

Product number	Date of purchase	Malfunction	Remarks

— 4 —

— 5 —

— 6 —