

Remote controller

Operating Instructions Manual



E09

Special tips:

1. Before installation and operation, please read this operation manual carefully.
2. Please save this manual for future reference.
3. Product may vary slightly from the item pictures due to model upgrades.

REMOTE CONTROL FUNCTIONS:

When you open the carton, you will find the below spare part——remote control:



The remote controller is connected with the treadmill to realize the operation of switching the treadmill START/STOP and adjusting the speed.

If the remote control has no response or you change a new one, the remote control and treadmill need to re-establish communication.

Re-establish communication method: Restart the treadmill, at the same time press and hold the start/ stop button on the remote control for 5 seconds, hearing the sound of "Beep", that means matching is successful.

Note:

The remote control has no response, may be the battery is out of power.

1. START/STOP BUTTON: Press the START button, this machine will start to work. 0.5MPH is the default start speed. During the running, you also can press this button to stop the machine.

2. SPEED +/- BUTTONS: Press the +/- buttons to increase or decrease the speed in increments of 0.1 MPH. Pressing and holding either of these buttons for a duration of over 1/2 a second will increase or decrease the speed continually.

WARRANTY

MANUFACTURER'S LIMITED WARRANTY

The supplier warrants to the original purchaser that this product is free from any defect in materials and/or workmanship, provided that the product is properly installed, properly operated and used for the intended purpose (for home use ONLY). This limited warranty is extended ONLY to the original purchaser, and only covers products purchased as new.

The supplier's obligations under this warranty applies to the following:

Frame - 1 year from date of purchase

All Other Parts - 90 days from date of purchase

Exclusions from warranty:

The supplier does not warrant against and is not responsible for, and no implied warranty shall be deemed to cover, any product failure, product malfunction, or damages attributable to:

1. Improper installation and/or failure to abide by the installation guidelines.
2. Use of this product beyond normal home use, or in an application for which it was not designed.
3. Cosmetic items such as scratches, dents or discolorations.
4. Damage caused by normal wear and tear, vandalism, accidental or by animals.
5. Any act of Nature (such as fire, flooding, snow, ice, hurricane, earthquake, lightning or other natural disaster), environmental condition (such as air pollution, mold, mildew, etc.), or staining from foreign substances(such as dirt, grease, oil, etc.).
6. Normal weathering due to exposure to sunlight, weather and atmosphere which can cause colored surfaces to among other things, flake, chalk, accumulate dirt or stains.
7. Improper operation, alteration, handling, storage, abuse or neglect of the products.

The supplier, using its sole discretion, will either repair or replace free of charge any part(s) proven to be defective under normal home use. Any repair or replacement shall provide no new warranty coverage, but shall retain only the remaining portion of the original product's warranty. This warranty is offered only to the original purchaser and is not transferable. Proof of original purchase is required.

If you have any problem, please be free to contact us at our customer service e-mail address: **customerservice@therun.info**

Replacement parts also can be ordered by emailing our customer service department. When ordering replacement parts please include the following information in the email:

- 1.Order details, including order number, distributor/seller name and date of purchase
- 2.Description of the part, like part number, part name or photo of the part
- 3.Description of the issue, if needed, include pic or video

Before the confirmation of our customer service, please do not send the products to our company, and send them back without permission. Our company does not bear any cost.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.