

Product number: WTC24183 REMOTE

Product name: WTC Remote

<b>Overview</b>	Simple and easy to use.			
<b>Product Pictures</b>		<b>size</b>		
<b>Product Control Panel Operating Instructions</b>		<ol style="list-style-type: none"><li>1. Load the CR2032 coin cell battery before use</li><li>2. Tap: Tap the remote control on key, and the product is switched in a ten-frequency cycle. (In the product boot state)</li><li>3. Long press: Long press the 2S remote control to open the key, the product enters the standby state, and then tap the remote control to open the key, and the product is switched in ten</li><li>4. Charging method: Replace the battery</li></ol>		
<p><b>Warning:</b> This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"><li>- Reorient or relocate the receiving antenna.</li><li>- Increase the separation between the equipment and receiver.</li><li>- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>- Consult the dealer or an experienced radio/TV technician for help.</li></ul>				