







11AX20SISO-Ant1-2462-15000~17000-PASS




11AX20SISO-Ant1-2462-17000~19000-PASS




11AX20SISO-Ant1-2462-19000~21000-PASS




11AX20SISO-Ant1-2462-21000~23000-PASS




11AX20SISO-Ant1-2462-23000~25000-PASS




11AX40SISO-Ant1-2422-30~1000-PASS




11AX40SISO-Ant1-2422-1000~3000-PASS




11AX40SISO-Ant1-2422-3000~5000-PASS




11AX40SISO-Ant1-2422-5000-7000-PASS




11AX40SISO-Ant1-2422-7000-9000-PASS




11AX40SISO-Ant1-2422-9000~11000-PASS




11AX40SISO-Ant1-2422-11000~13000-PASS




11AX40SISO-Ant1-2422-13000~15000-PASS




11AX40SISO-Ant1-2422-15000~17000-PASS




11AX40SISO-Ant1-2422-17000-19000-PASS




11AX40SISO-Ant1-2422-19000-21000-PASS




11AX40SISO-Ant1-2422-21000~23000-PASS




11AX40SISO-Ant1-2422-23000~25000-PASS




11AX40SISO-Ant1-2437-30~1000-PASS




11AX40SISO-Ant1-2437-1000~3000-PASS




11AX40SISO-Ant1-2437-3000-5000-PASS




11AX40SISO-Ant1-2437-5000-7000-PASS




11AX40SISO-Ant1-2437-7000-9000-PASS




11AX40SISO-Ant1-2437-9000-11000-PASS



11AX40SISO-Ant1-2437-11000~13000-PASS




11AX40SISO-Ant1-2437-13000~15000-PASS




11AX40SISO-Ant1-2437-15000~17000-PASS




11AX40SISO-Ant1-2437-17000~19000-PASS




11AX40SISO-Ant1-2437-19000~21000-PASS




11AX40SISO-Ant1-2437-21000~23000-PASS




11AX40SISO-Ant1-2437-23000~25000-PASS




11AX40SISO-Ant1-2452-30~1000-PASS




11AX40SISO-Ant1-2452-1000~3000-PASS




11AX40SISO-Ant1-2452-3000~5000-PASS




11AX40SISO-Ant1-2452-5000-7000-PASS




11AX40SISO-Ant1-2452-7000-9000-PASS




11AX40SISO-Ant1-2452-9000~11000-PASS




11AX40SISO-Ant1-2452-11000~13000-PASS




11AX40SISO-Ant1-2452-13000-15000-PASS




11AX40SISO-Ant1-2452-15000-17000-PASS




11AX40SISO-Ant1-2452-17000~19000-PASS



11AX40SISO-Ant1-2452-19000~21000-PASS




11AX40SISO-Ant1-2452-21000~23000-PASS




11AX40SISO-Ant1-2452-23000~25000-PASS

Appendix G: Duty Cycle


TestMode	Antenna	Frequency[MHz]	Transmission Duration [ms]	Transmission Period [ms]	Duty Cycle [%]	Factor
11B	Ant1	2412	8.18	8.68	94.24	0.26
11B	Ant1	2437	8.19	8.68	94.35	0.25
11B	Ant1	2462	8.20	8.70	94.25	0.26
11G	Ant1	2412	1.36	1.87	72.73	1.38
11G	Ant1	2437	1.35	1.86	72.58	1.39
11G	Ant1	2462	1.36	1.87	72.73	1.38
11N20SISO	Ant1	2412	1.27	1.78	71.35	1.47
11N20SISO	Ant1	2437	1.27	1.78	71.35	1.47
11N20SISO	Ant1	2462	1.27	1.78	71.35	1.47
11N40SISO	Ant1	2422	0.63	1.14	55.26	2.58
11N40SISO	Ant1	2437	0.63	1.14	55.26	2.58
11N40SISO	Ant1	2452	0.63	1.14	55.26	2.58
11AX20SISO	Ant1	2412	1.17	1.67	70.06	1.55
11AX20SISO	Ant1	2437	1.16	1.67	69.46	1.58
11AX20SISO	Ant1	2462	1.17	1.67	70.06	1.55
11AX40SISO	Ant1	2422	0.61	1.12	54.46	2.64
11AX40SISO	Ant1	2437	0.61	1.12	54.46	2.64
11AX40SISO	Ant1	2452	0.61	1.12	54.46	2.64




NTNV-11B-Ant1-2412




NTNV-11B-Ant1-2437




NTNV-11B-Ant1-2462




NTNV-11G-Ant1-2412




NTNV-11G-Ant1-2437




NTNV-11G-Ant1-2462




NTNV-11N20SISO-Ant1-2412




NTNV-11N20SISO-Ant1-2437




NTNV-11N20SISO-Ant1-2462




NTNV-11N40SISO-Ant1-2422




NTNV-11N40SISO-Ant1-2437




NTNV-11N40SISO-Ant1-2452



NTNV-11AX20SISO-Ant1-2412



NTNV-11AX20SISO-Ant1-2437



NTNV-11AX20SISO-Ant1-2462