



INSTRUCTION MANUAL

Model: HMAW-2SUS

Ultrasonic Humidifier

READ AND SAVE THESE INSTRUCTIONS

PAIRING YOUR DEVICE WITH THE ECO SMART APP

What you need:
A Wi-Fi router supporting the 2.4GHz and 802.11 b/gn bands. 5GHz is not supported.

- Download the Eco Smart app from the App Store (iOS devices) or Google Play (Android devices).
- Entering the register, then turn on mobile Wi-Fi and Bluetooth.
- Press the Irregular network distribution button for 5 seconds until the atmosphere light is on, and then release it. After the light is on for 10 seconds, it enters flash mode. (Press the Irregular network mode button to exit the network mode)
- Log in to the Eco Smart account, add devices, enter the "Small Home Appliances" category, and select "humidifier (WiFi)".
- Enter a valid Wi-Fi network in the space where the humidifier is located and enter your Wi-Fi account and password to connect to the humidifier.
- After a humidifier is added, change the name of the humidifier to an easily recognizable name.
- Enter the APP operation interface for normal operation;

DOWNLOAD THE ECO SMART APP

NAMES OF PARTS

- Water Tank
- Timer Button
- Light Button
- Mist Button
- Power Button & Indicator Lights
- Mist Outlet
- Top Cover
- Air Pump
- Air Outlet
- Max Water Level Line
- Water Level Detection
- Ceramic Disc
- Air Inlet
- Power Cord

BEFORE USING THE HUMIDIFIER

- Always disconnect from a power source by pulling out the plug when not in use.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this humidifier.

- Please always keep the humidifier out of reach of patients' children & pet.
- Please always place the unit on a smooth, flat, fire-free, non-metallic, waterproof and level surface and keep it away from direct sunlight.
- Always place the unit 24 inches (60 cm) above the floor, 12 inches (30 cm) away from the wall, other appliances or wooden furniture.

WHEN USING THE HUMIDIFIER

- DO NOT place the humidifier on an inclined surface.
- DO NOT direct the mist nozzle towards the wall.
- DO NOT use your hand or any other object to cover the nozzle while the unit is on to avoid damaging the product or causing injury.

- DO NOT clean the unit while it is connected to a power source or while it is on.
- DO NOT move the humidifier obliquely.

FUNCTION CHARACTERISTICS

Essential Oil Diffuser and Cool Mist Humidifier:
Add essential oil directly to the water and enjoy therapeutic benefits.

- Water Capacity: 2.5L.
- Four buttons: power button, light button, mist button and timer button.
- Continuous run time:
 - *High Mist Intensity: Up to 8 hours;
 - *Low Mist Intensity: Up to 24 hours;
 - *Run time will vary depending on humidity levels and other external factors;
- Light mode: RGB light, specific lights or off.
- Light mode: RGB light, specific lights or off.
- Automatic safety shut-off when water at low level;

When plugging the power cord into an electrical wall outlet, all indicator lights keep on for 1 second, and then off: the unit enters into standby state.

Power Button:
1st Touch: turn on humidifier in low mist, "I" and power indicator lights keep on;
2nd Touch: turn off humidifier.
Note: If water at very low level, the unit will not work, and power indicator light keeps blinking for 10 seconds.

Mist Button:
1st Touch: continuous diffusion on medium mist intensity with "II" indicator light.
2nd Touch: continuous diffusion on high mist intensity with "III" indicator light.
3rd Touch: continuous diffusion on low mist intensity with "I" indicator light.
Cyclic control.
Note: Long touch Mist Button to enter into sleep mode with all lights turn off except the power indicator light. Short touch again to exit sleep mode, the unit will start diffusion in low mist intensity.

OPERATIONS GUIDE

Place unit on a flat, water-resistant surface as moisture may cause damage to carpet, finished floor, furniture, or walls.

- Remove the Top Cover from the Water Tank.
- Fill the Water Tank with tap water up to the Max Water Level Line. Do not overfill. Add approximately 10 drops of essential oil per 1 liter of water into the Water Tank.

3. Replace Top Cover onto the Water Tank.
4. Plug the Power Cord into an electrical wall outlet. It will take a few minutes for the essential oil to blend with the water before fragrance begins diffusing.

- If tap water is too hard, it is recommended to use filtered or distilled water to avoid white dust.
- DO NOT add water with temperature exceeds 50 degree Celsius.
- DO NOT add water into the air outlet or empty water from the air outlet.
- DO NOT fill the humidifier while the water tank is filled with water to avoid leakage and water into the air outlet.

CARE & MAINTENANCE

Only use the power cord supplied with the unit.
Always unplug the power cord from electrical outlet before filling.
Essential oil should not come in contact with the exterior surface of unit.
Do not submerge unit into water to avoid risk of electric shock.
Do not attempt to adjust or repair the unit.
Do not touch the water while unit is operating.
Do not place the unit near heat source or direct sunlight.
Use two hands when moving your humidifier.
Use this unit only as intended as described in this manual.
DO NOT:
- Empty water from the Water Tank away from the Air Outlet.
- The Ceramic Disc should not come in contact with any hard or sharp objects.
- To remove possible clogging, rinse with a warm vinegar and water solution.
Dry thoroughly with a soft cloth. Do not use strong cleaning agents.

AFTER USING THE HUMIDIFIER

Model: HMAW-2SUS

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

PRODUCT SPECIFICATIONS AND PARTS

SPECIFICATION

Model No	HMAW-2SUS
Operating Voltage	AC 120V 60Hz
Rated Power	30W
Water Tank Capacity	2.5L
Working Time	8h
Mist Output	200±50ml/h
Mist Modes	High/Medium/Low
Timer Setting	2h/4h/8h

AFTER-SALES SUPPORT
If your device fails to work or your experience with this product is less than satisfactory in any way, please do not hesitate to contact us.

✉ service@esemil.net 🌐 www.esemil.net

WARRANTY SERVICE
Please scan the following QR code to activate your warranty service and more support information

