## **TROUBLESHOOTING MERKURY** Recharge your Bluetooth® Speaker using the included micro USB cable. Try using a different cable. Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected using Bluetooth®. Restart the speaker to reconnect to your Bluetooth® enabled device. Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap "MERKURY S300B" and select "Forget". Now follow the steps to pair your device again.

### **SPECS**

Speaker Specifications: Output Power: 5W x 2 Frequency Range: 20 Hz — 20 kHz Driver Size: 102 mm

No power

over Bluetoo

Music is not playing

Bluetooth® device will

not reconnect with

the speaker

Additional Connection Sources: Audio: Mic Input Port, USB Drive, microSD Card Power Source: Built-in rechargeable Lithium-ion

Charging time: 4 hours Bluetooth® Information

Bluetooth® Version: 5.0 Operating Distance: 30 ft. System Requirements: Bluetooth® enabled device

Power Information: Input: DC5V Battery Capacity: 3.7V, 2400mAH Music play time: 3 hours\*

\*Depends on individual use and may be slightly more or less than the time specified.

### Technical Support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you purchased it from. You can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

Merkury Innovations 45 Broadway, 3rd Floor New York, New York 10006 www.merkuryinnovations.com

battery or USB cable.

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

This device may not cause harmful interference.

 This device must accept any interference received, including interference that may cause undesired operation.

## ©2022 Merkury Innovations, LLC. To explore our full selection of products, visit us at:

www.merkuryinnovations.com

· Charging time is approximately 4 hours.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners. Made in China



## CHARGE

· Plug the micro USB cable into the micro USB port on the top of the speaker, and connect the other end of the cable to any compatible USB charger or USB A/C Wall Adapter.

• When charging, the small LED indicator will glow red. When fully charged, the LED indicator will turn off.

**TURN ON & OFF** 

· Slide the ON/OFF switch to the ON position to power the speaker ON; a tone will be heard and the speaker will enter Bluetooth® mode.

• Slide the ON/OFF switch to the OFF position to power OFF.

 Make sure the speaker is turned off and your device's Bluetooth® setting is enabled.
 Turn the speaker on; after a few seconds it will automatically enter pairing mode and the LED light will flash.
 On your Bluetooth® enabled device, navigate to the Bluetooth® settings menu, turn on the Bluetooth® feature, and search for new devices. • Wait a few seconds and select "MERKURY S300B". The speaker will emit a tone when successfully paired.

**PAIR & CONNECT** 

NOTE: If your device's Bluetooth® version is below version 2.1, you may need to enter the password "0000." NOTE: Insert a USB thumb drive or microSD card for direct music playback.


## PLAY

- Connect your device to the speaker via Bluetooth® (see "Pair & Connect with a New Device").
  Open your favorite music app and press play.
  Control the music, track and volume from your device, or control them with the controls on the speaker.
  Adjusting Volume: Adjust the volume using the volume button on the speaker or through your device.
  Press the " | I " button to play/pause music.
- Press the " ◄ " or "▶ " button to skip to the next/previous track  $\bullet \ \textbf{All} \ \ \textbf{audio, including music, games, videos, and notifications will be played through the speaker. }$

# **RECONNECT TO BLUETOOTH®**

- You only need to pair your Bluetooth® enabled device with the speaker once.
   With your previously paired device's Bluetooth® enabled and in range, power on the speaker.
   The speaker will automatically reconnect to the last Bluetooth® device it was connected to.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device, turn on the Bluetooth® feature, and select "MERKURY S300B" from your list of paired Bluetooth® devices and select "Forget." Repeat Pair & Connect steps stated above.

## **CONTROL AND INPUT PORTS (TOP OF SPEAKER)**



1. Power ON/OFF switch

2. Micro USB charging input port

3. MicroSD/TF card port

4. USB input port 5. MIC input port

6. LED indicator 7. LED light effects 8. Mode select:

Bluetooth, MicroSD/TF card, USB, FM

9. Volume down, Press & hold: Previous track/FM Station

10. Pause and play audio

11. Volume up,

Press & hold: Next track/FM Station 12. Bass mode

# FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.