




User Manual

Automatic pet feeder

(Supports 2.4GHz WiFi Only)



uHome+



Products will be upgraded from time to time (including APP), please refer to the actual product!

Safety Instructions



Dispose of all packaging materials properly. Some items may be packed in plastic bags; these bags could cause suffocation. Keep them away from children and pets.



Do not immerse the base part in water at any time as it may damage electronic components like the control panel.



Suggest following the instruction in this user manual to assemble or disassemble the feeder.



Only use accessories recommended or sold by the manufacturer. The use of accessories not recommended or sold by the manufacturer may cause an unsafe condition.



Examine the feeder after installation. Do not plug in if there is water on the power cable or plug.



This product uses built-in battery as a backup power supply. We recommend to use double power supply to ensure the normal use of the product.



If the product is not used for an extended period, please fully charge the battery to reduce the rate of natural discharge.



Do not put your fingers into the food outlet or let your fingers touch the rotor.



Keep the feeder close to your router, make sure the network signal is good, it is ideal to make it within 5 meters without obstacles and walls. (Depending on the coverage of the router you are using)



Please do not use wet, canned or moist food; only put dry food into the food tank prevent from abnormal conditions even may including pet safety problems.

Warranty

◆1-Year Warranty


◆Lifetime Support

For guidance on product use and warranty extension, please contact our brand after-sales staff via email: [\[service@papifeed.cn\]](mailto:service@papifeed.cn) or call us at **(1) 877-290-0617** (From Monday to Friday: 8 a.m.-5 p.m.)(PST)
If any questions related to orders, please contact the seller through the shopping platform.

Specifications

Product Name	Automatic pet feeder
Suit For	Cat, Dog, Rabbit, Squirrel, Small Pets
Rated Voltage	5V 1A
Product Power	5W
Power Supply	DC 5V1A Power Adapter/ Chargeable Built-in Battery
Product Size	200x200x336mm/7.87x7.87x13.23inches
Product Weight	1.5KG/ 3.36Lb
Product Capacity	6.5L /27Cups
Pet Food	Recommended to use 5-12mm/0.2-0.47in dry, non-sticky pet food
Portion Size	About 10G/0.35OZ (Varies due to density of pet food)
Support	2.4G WiFi Only/Not Supports 5G

In the Box



Food Tank x1



USB Cable x1



Adapter x1




Stainless
Steel Feeding Bowl x1



Fixing Bracket x2



Bowl Tray x1




Feeder Base x1

Cannot be cleaned



Manual Instruction x1

Product Overview




Warning: Please keep the feeder base dry and do not wash it!

Installation


STEP 1 Connecting Power

1



- Check the bottom of the device and plug in the USB cable.

2




- Turn on the power switch at the bottom of the feeder.

Note: Be sure to turn on the power switch before use. Please maintain dual power supply, batteries are for backup power only


STEP 2 Assemble or Disassemble

3



- When installing the food impeller: Please pay attention to the impeller direction.


4



- Pay attention to the direction of the impeller; the impeller should not be placed in the center.


STEP 3 Assembling the Food Tray

5




- First, install the fixing brackets from the bottom.

6



- Align the bulging of the bowl tray and the holes in the feeder base, and push up ward to connect the two. Pu on the stainless steel feeding bowl

7



The food tank can be installed only in Unlock Position

Lock ←





→ Unlock

- Slide the buckle to Unlock position, then insert the food tank into the feeder base, and then slide the buckle to the locked position.

STEP 4 Fill With Food


8



Note: It is recommended to use round or oval-shaped pet food, as long strips or irregular shapes such as polygons are prone to getting stuck.

- Pour in dry pet food. Put on the lid.

Description of Buttons and Indicators



Indicator Light Descriptions

Indicator	Status
 Blue light blinking	Waiting for connection.
 Blue light solid	Connection successful.
 Green light solid	Connection timed out.
 Red light blinking	Indicates low battery (when using battery power only).

Note: If the connection times out, press and hold the + button for about 10 seconds to reset the device to the blue blinking light state for reconnection.

Tutorial Video

■ You can scan the **Tutorial Video** QR code to watch how to connect.



Tutorial Video

Install the APP & Log In

■ App Installation

Download and install the "uHome+" App by scanning the QR code, or searching it on Google Play (Android)/ App Store (ios).




uHome+


■ Sign up and log in

After opening the app, if you don't have an account, please register one. If you have already have, please log in directly.


Connect to APP (only support 2.4GHz network, not 5GHz)




1. Open the APP homepage
- Add device




2. Add



3. Select 2.4G WiFi and enter
a good password. Next step



4. Wait for connection




5. Connection
successfully




6. Click to finish


Feeding plan settings




1. Choose a feeding plan




2. Add a feeding plan




3. Select time
(note the difference between AM and PM)



4. Select the week
(if you don't select the next time, you will not be able to deliver the food. Be sure to check the week)




5. Select the number of feeding portions and click Save




6. Slow feeding
(on to the right, close to the left): After opening, each serving of food will be 1 minute apart

Note: It does not affect manual grain delivery


Device Sharing




1. Open the device in the APP and click on the upper right corner




2. Select device to share



3. Add share



4. Select the sharing mode




5. Copy the link to send to the other party



Cleaning & Care

We recommend to clean the feeder regularly for the health of your pet. The washable parts of the feeder are as follows: safety lock, lid, desiccant compartment, bowl tray, stainless steel feeding bowl.


Washable Parts



Do Not Wash



When disassembling the food tank, please pour out all the food before disassembling it to avoid spilling.



Charging Method

1



● Turn on the battery switch.

2




● Connect to the power supply.

3



● While charging:
The red light remains solid.

4



● When fully charged:
The green light stays solid.


Problem	Solution
Can't connect the feeder to WiFi	1) Keep the feeder and your phone close to your router, make sure the network signal is good.
	2) Restart the feeder.
	3) Follow the APP's instructions or our tutorial videos to add the feeder. There are more than one adding methods to choose from.
	4) Contact our after-sales team via email for help.
WiFi connection is sporadic	1) Keep the feeder close to your router, make sure the network signal is good, it is ideal to make it within 5 meters without obstacles and walls.(Depending on the coverage of the router you are using).
	2) Make sure the power cord is properly at this point.
	3) Reset the feeder and reconnect.
The indicators are off	1) Check whether the electricity is cut off.
	2) Check whether the indicator function is off on the App.
Why feed on the APP but no food dispensing from the feeder?	1) To check if the food tank got enough food.
	2) If the impellers have been rotated normally. (You can judge from the sound).
	3) Suggest to feed again for few more times to avoid the signal delay(Internet delay) cause for the troubles.

Problem	Solution
Timed tasks are not executed correctly	1) Make sure the feeder is not reset or powered off.
	2) Check if the feeder is offline, when normally connected, the feeder indicator is always on blue.
	3) Check whether the effective period of the timing task is set correctly.
	4) Check whether the time zone of the device is the same as your time zone. Online status, click -  Settings , check the time zone of the device.
	5) Reset the feeder and reconnect.
The feeder has disappeared from the home page	1) Make sure the feeder is successfully networked, the indicator light should be blue.
	2) Make sure the feeder is not connected by someone else, it is recommended to reset the feeder and connect it.

Reference for Meal & Portion Settings

▲Note:

- Below is the recommended amount of food your pet needs by each meal.
- One portion of this feeder is about 15g/0.03lb.



If the pet fail to eat up the previous programmde meal, please reduce the next meal portion.

- CAT -

Age (Months)	1-2	2-4	4-6	6-8	8-12
Suggested Feed	20-30g	30-50g	50-70g	70-80g	80-90g
Weight (Months)	2-3kg	3-5kg	5-7kg	Pregnancy	Lactation Period
Suggested Feed	25-35g	35-55g	55-85g	70-110g	120-190g

- DOG -

Dog Weight	Normal Activity	Increased Activity	Dog weight	Normal Activity	Increased Activity	Vigorous Activity
2kg	39g	45g	22kg	250g	290g	329g
4kg	66g	76g	24kg	267g	309g	351g
6kg	89g	104g	26kg	274g	318g	361g
8kg	111g	128g	28kg	290g	336g	381g
10kg	131g	152g	30kg	305g	353g	402g
12kg	150g	174g	32kg	320g	371g	422g
14kg	178g	206g	34kg	335g	388g	441g
16kg	197g	228g	36kg	350g	405g	461g
18kg	197g	228g	38kg	364g	422g	480g
20kg	233g	270g	40kg	379g	439g	496g

100% After Sales Service

We provide one year warranty for this appliance.

Please email our support team at [service@papifeed.cn], if you have any questions, attach your order number and describe the problem you met in your email. We will get back to you within 24 hours.

Also you can call us at **(1) 877-290-0617**

(From Monday to Friday: 8 a.m.-5 p.m.)(PST)



Scan for more details
WWW.papifeedpet.com

THANK YOU FOR YOUR PREFERENCE FOR PAPIFEED

If you have any problems with our product, please feel free to contact us.

 Tel: **(1) 877-290-0617** (From Monday to Friday: 8 a.m.-5 p.m.)(PST)
 Email: **service@papifeed.cn**

FC CE RoHS



Made in China

深圳市创智乐智能科技有限公司

品 名

PA-AMZ 魔方喂食器 WiFi款 英文说明书

规 格

尺寸：100*140mm

材 质

80g书纸

印 刷

黑色字体

字 体

思源黑体

日 期

2025.5.23

修改

星星

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.