

R30Pro Smart Watch

Please refer to the following figures, disassemble the watchband by rotating its pin button and lifting the watchband to remove it, and then release the pin button. And you can assemble a new watchband by operating in reverse procedures.







Battery capacity: 280 mAh Battery life: 5-6 days Waterproof: 10M

Bluetooth version: BLE5.2 Screen material: BOE Glass

Control Your Watch

Power Button

Press

Wake the screen
Return to the home screen
Enter the menu interface

⊘ Sport Button

1 Touch Screen

Hold the home screen to change the watch face
 Swipe to go to different interfaces
 Tap to enter the function
 Swipe the screen to the right to return to the previo

The distance between the mobile phone and the watch shall be kept less than 10 meters please. And please refresh the

Using Your Watch

1 Charging

Before using your R30Pro for the first time, charge the batter

its full capacity. It is recommended to use a conventional charger above 5V for charging, not the USB interface at the computer terminal.

While your watch is charging, the screen will show its progr



Install Da Fit App on your smartphone

You can download Da Fit App from Apple Store/Google Play or scan the QR codes Right to download

Device Binding







Select the MAC address corresponding to the watch for connection

Select "pair" for pairing, and bind successfully















Settings

You can set the brightness of the watch

You can set up the so

③ Dial switching You can set up the dial display subject to

your preferences. There are 6 built-in dial options in total (of course, you can also

customize the dial on the app).

 View of master menu
You can set up the display style of the master menu subject to your preference

There are 8 options in total available. Screen-on switch with wrist turning
 You can choose to turn wrist and wake

You can choose to restart your watch.
② shut down .Vibrate & Ring

① Vibration only You can choose to set up the alarm mode for any notification to vibration only, and return to the previous interface to set up the vibration level. (3) Restore factory

2 Vibrate & ring

You can choose to set up the alarm mode for any notification to vibration & ringing, and return to the previous interface to set up

the vibration level.

OND Mode
You can choose to enable the No-disturb mode, which will disable notifications of message and incoming-calls.

① restart

-Phone Reset You can choose to reset up the watch call logs and contacts

You can choose to turn off your watch

your data and settings will be deleted.

(2) App download QR code

device name, Bluetooth name and version.

Scan the QR code to download the Da Fit app.

You will find all information related to the device here, including