




ZHUOYUE**USER MANUAL**Wireless Charging Music Lamp
PX-02**PRODUCT INTRODUCTION**

Please read the user manual carefully before using this product

HOW TO CHARGE**Product Charging**


1. Connect the complimentary power adapter cable to the product Type-C interface for charging.
2. When the product is powered on, the red indicator light will be on, indicating that it is charging. The green indicator light will be on when the product is fully charged.
3. When the product is powered on, USB can charge the phone.

**Wireless Charging of Mobile Phone**


4. After plugging in the main power, place the wireless charging device that needs to be charged in the charging indicator area of this product to start charging.

BLUETOOTH CONNECTION (Device Name: PCXC 5002)**Bluetooth Pairing**


① Press and hold the M button, Bluetooth pairing and resetting, and there will be a prompt tone.

**Successful Connection**


② Then turn on the Bluetooth function of your mobile phone and select "PCXC5002" from the list of Bluetooth devices. It will automatically pair. After the pairing is successful, there will be a prompt tone.

**MUSIC AND AMBIENT LIGHT OPERATION****Playing Music**


- Press and hold the power button to turn on/off the device, and there will be a prompt tone.
- Long press the volume up button to play the previous track. Long press the volume down button to decrease the volume.
- With a beeping sound indicating when the volume has reached its maximum.

**Volume Up Button +**

- Briefly press the volume up button to play the next track.
- Briefly press the volume up button to increase the volume.
- With a beeping sound indicating when the volume has reached its maximum.

**BUTTON FUNCTION****Power Button**

- Press and hold the power button to turn on/off the device, and there will be a prompt tone.
- Briefly press the power button to play/pause music.
- Briefly press the power button to play/pause music.

**Volume Down Button -**

- Briefly press the volume down button to play the previous track.
- Long press the volume down button to decrease the volume.

**BASIC PARAMETER**

Model: PX-02	Dimension: 8.66x4.35x1.99 (inch)
Electric Current: 2A	Input Voltage: DC 9V
Rated Power: 8W	Material: ABS/Silica/PCBA/C
Wireless Power: 10W	Compliance: GB4945.1-2005 GB4945.1-2020
Speaker Power: 5W*1	Origin: Shenzhen, China

ATTENTION POINTS

- The Pro model only supports horizontal and vertical charging of mobile phones.
- The normal model supports horizontal charging and vertical charging for phones larger than 6.4 inches, and vertical charging for phones smaller than 6.4 inches.
- To use wireless charging, make sure your phone has wireless charging capabilities.
- Use the Q.C.0 adapter for best results.
- Please avoid thick cases (>0.7 inches) and other accessories when charging your device.
- Mobile phones below iPhone 5S do not support wireless charging, such as iPhone 5, 5S, 6, 6S, and 7.
- Do not use or store the product in direct sunlight or high temperature places for a long time.
- Do not charge in places too close to magnetic cards, magnetic recording media, and precision instruments.
- Do not disassemble or modify this product.
- Keep this product away from water or other liquids.
- If you want to clean the product, please disconnect the power.

PACKAGE

Wireless Charging Music Lamp	x 1
Power Adapter	x 1
Power Cord	x 1
User Manual	x 1

CE RCM
MADE IN CHINA

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For Bluetooth

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

For WPT

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.