








NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
0.009-0.15-PASS

NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
30-1000-PASS

NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
1000-3000-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
3000-6000-PASS


NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
6000-20000-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-BPSK-Edge_1RB_Left-
20000-40000-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
0.009-0.15-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
30-1000-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
1000-3000-PASS



NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
3000-6000-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
6000-20000-PASS




NTNV-n77(3450-3550)-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-
20000-40000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-1000-3000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-6000-20000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-BPSK-Edge_1RB_Left
-20000-40000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-1000-3000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-6000-20000-PASS




NTNV-n77(3450-3550)-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left
-20000-40000-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
1000-3000-PASS



NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
6000-20000-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-20000-40000-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-1000-3000-PASS





NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-3000-6000-PASS



NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-6000-20000-PASS





NTNV-n77(3450-3550)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-20000-40000-PASS





NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
0.009-0.15-PASS

NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
0.15-30-PASS




NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
30-1000-PASS

NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
1000-3000-PASS




NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
3000-6000-PASS


NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
6000-20000-PASS




NTNV-n77(3450-3550)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
20000-40000-PASS




NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
0.009-0.15-PASS




NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
0.15-30-PASS





NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
30-1000-PASS



NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
1000-3000-PASS




NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
3000-6000-PASS





NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left- 6000-20000-PASS

NTNV-n77(3450-3550)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left- 20000-40000-PASS



NTNV-n77(3450-3550)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left -0.009-0.15-PASS

NTNV-n77(3450-3550)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left -0.15-30-PASS



NTNV-n77(3450-3550)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left -30-1000-PASS

NTNV-n77(3450-3550)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left -1000-3000-PASS