







NTNV-n78(3700-3800)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-BPSK-Edge_1RB_Left
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-BPSK-Edge_1RB_Left-
26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-
26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-BPSK-Edge_1RB_Left
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-50-M-DFT-QPSK-Edge_1RB_Left
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-BPSK-Edge_1RB_Left
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-60-L-DFT-BPSK-Edge_1RB_Left-
0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-60-L-DFT-BPSK-Edge_1RB_Left-
0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-60-L-DFT-BPSK-Edge_1RB_Left-
30-1000-PASS



NTNV-n78(3700-3800)-PC3-30-60-L-DFT-BPSK-Edge_1RB_Left-
1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-60-L-DFT-BPSK-Edge_1RB_Left-
3000-6000-PASS



NTNV-n78(3700-3800)-PC3-30-60-L-DFT-BPSK-Edge_1RB_Left-
6000-26000-PASS