






NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-BPSK-Edge\_1RB\_Left-  
26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-90-L-DFT-QPSK-Edge\_1RB\_Left-  
26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-BPSK-Edge\_1RB\_Left  
-26000-40000-PASS





NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-0.15-30-PASS





NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-1000-3000-PASS

NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-3000-6000-PASS



NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-6000-26000-PASS


NTNV-n78(3700-3800)-PC3-30-90-M-DFT-QPSK-Edge\_1RB\_Left  
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
-0.009-0.15-PASS

NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
0.15-30-PASS







NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-BPSK-Edge\_1RB\_Left  
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-90-H-DFT-QPSK-Edge\_1RB\_Left  
-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Lef  
t-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Left  
-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Lef  
t-30-1000-PASS



NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Left  
-1000-3000-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Lef  
t-3000-6000-PASS



NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Left  
-6000-26000-PASS







NTNV-n78(3700-3800)-PC3-30-100-L-DFT-BPSK-Edge\_1RB\_Lef  
t-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-0.15-30-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-30-1000-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-1000-3000-PASS



NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-3000-6000-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-6000-26000-PASS




NTNV-n78(3700-3800)-PC3-30-100-L-DFT-QPSK-Edge\_1RB\_Lef  
t-26000-40000-PASS




NTNV-n78(3700-3800)-PC3-30-100-M-DFT-BPSK-Edge\_1RB\_Le  
ft-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC3-30-100-M-DFT-BPSK-Edge\_1RB\_Lef  
t-0.15-30-PASS



NTNV-n78(3700-3800)-PC3-30-100-M-DFT-BPSK-Edge\_1RB\_Le  
ft-30-1000-PASS



NTNV-n78(3700-3800)-PC3-30-100-M-DFT-BPSK-Edge\_1RB\_Lef  
t-1000-3000-PASS