

# SP10

User Manual

## CHARGING

1. Fully dry off the earbuds and the USB-C charging port before charging.
2. Connect the charging case to a power supply by using the provided USB-C charging cable.

## CONTROL

	Take out from the case/press and hold the L/R Multi-function buttons for 2s
	Put into the case/press and hold the L/R for 6s
	Double-click L/R
	Click L/R
	Press and hold for L/R 2s
	Double-click L/R
	Press and hold for 2s
	Triple-click L/R

## LED INDICATORS

Power on	White indicator stays on for 1 second and then turns off
Power off	Blue indicator stays on for 2 second and then turns off
Pairing	Main earphone white indicator is pulsating, sub-earphone flashes a white light every 3s
Connected	Light off

## Specifications

Model	SP10
Profile	HFP/HSP/AVRCP/A2DP
Range	Up to 10 meters / 33 feet
Frequency Range	20-20KHz
Playtime (earbuds)	Up to 14 Hours of Playtime (Varied by volume level & audio content)
Earbuds charging time	2 hours
Charging case charging time	2 hours

## Package Content

## Product Overview

## PAIRING

1. For first-time use, remove the insulation stickers on the earbuds.
2. Return earbuds to the charging case.
3. Take out the earbuds or hold the Multi-function buttons for 2 seconds to turn them on.
4. Once paired automatically, The main earphone white indicator is pulsating. The sub-earphone flashes a white light every 3s. A voice prompt will say "Pairing".
5. Select "SP10" on your phone to connect from the Bluetooth list. Once connected, the indicators will be off. A voice prompt will say "connected".

**Note:** Earbuds will turn off automatically after 5 minutes if they have not been paired with any device.

## RESET

1. Delete "SP10" in the Bluetooth list and turn off the Bluetooth function of your phone.
2. If both ears are off, hold down both ears for 10s, and the blue headphone indicator blinks three times, the reset is successful.
3. If it fails, repeat the above three steps.

## WEARING

1. Pick up the earbuds

2. Rotate the earhooks along the auricle of your ear to achieve proper positioning.

3. Dust, earwax or other debris will accumulate in the earplugs. In order to maintain the best sound quality, please gently clean the earplugs with a cotton swab regularly.

**FCC Warning:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

MODEL: SP10  
FCC ID: 2A7GB-SP10  
MADE IN CHINA

CE FC