300g轻写板 双面单黑白标 打版

[cyan]	[cyan]	[cyan]	[cyan]	[cyan]
[cyan]	[cyan]	[cyan]	[cyan]	[cyan]
[cyan]	[cyan]	[cyan]	[cyan]	[cyan]
[cyan]	[cyan]	[cyan]	[cyan]	[cyan]
[cyan]	[cyan]	[cyan]	[cyan]	[cyan]
[cyan]	[cyan]	[cyan]	[cyan]	[cyan]
[cyan]	[cyan]	[cyan]	[cyan]	[cyan]

Pro1600 Power Station Manual

USER GUIDE

封面

Introduction

About this manual

This manual contains important safety and operating instructions that should be read and understood before using the Pro1600 Power Station. Please keep this manual for future reference.

About the Pro1600 Power Station

The Pro1600 Power Station is a portable power station that can be used to charge and power a wide range of devices. It is equipped with a lithium iron phosphate battery, which is safer and more durable than traditional lithium-ion batteries. The Pro1600 Power Station has a variety of output ports, including AC outlets, USB ports, and a DC port. It also has a built-in LED light.

Safety use instructions

Safety use instructions

- Do not expose the Pro1600 Power Station to water or other liquids. Do not use the Pro1600 Power Station if it has been dropped or damaged.
- Do not disassemble or modify the Pro1600 Power Station. Do not attempt to repair the Pro1600 Power Station yourself. Contact customer service for repairs.
- Do not use the Pro1600 Power Station in extreme temperatures. The Pro1600 Power Station should be used in a temperature range of 0°C to 40°C (32°F to 104°F).
- Do not use the Pro1600 Power Station near flammable materials. Keep the Pro1600 Power Station away from heat sources, such as fireplaces and stoves.
- Do not overload the Pro1600 Power Station. The Pro1600 Power Station has a maximum output of 1600W. Do not exceed this limit.
- Do not use the Pro1600 Power Station to charge devices that are not compatible with it. Check the compatibility of your devices before charging them.
- Do not leave the Pro1600 Power Station unattended while it is charging. Monitor the Pro1600 Power Station while it is charging and unplug it when it is fully charged.
- Do not use the Pro1600 Power Station if it is making unusual noises or emitting smoke. Unplug the Pro1600 Power Station immediately and contact customer service.
- Keep the Pro1600 Power Station out of the reach of children.
- Do not use the Pro1600 Power Station for any purpose other than those described in this manual.
- Do not use the Pro1600 Power Station if it has been exposed to salt water or other corrosive substances.
- Do not use the Pro1600 Power Station if it has been exposed to extreme humidity or condensation.
- Do not use the Pro1600 Power Station if it has been exposed to direct sunlight for extended periods of time.
- Do not use the Pro1600 Power Station if it has been exposed to dust or other contaminants.
- Do not use the Pro1600 Power Station if it has been exposed to vibration or shock.
- Do not use the Pro1600 Power Station if it has been exposed to electromagnetic interference.
- Do not use the Pro1600 Power Station if it has been exposed to radiation.
- Do not use the Pro1600 Power Station if it has been exposed to any other environmental hazards.

Product specifications

Product specifications

Product model: Pro1600 **Rated power:** 1600W

Battery type: LiFePO4 **Battery capacity:** 1024Wh / 1600Wh

Input voltage: 110V **Output voltage:** 110V/12V/5V

Input current: 15A **Output current:** 15A/10A/3A

Charging time: 8 hours (with AC charger) **Weight:** 15kg

Dimensions: 400mm x 300mm x 200mm

Certifications: CE, FCC, RoHS, UL, ETL, CSA, PSE, KC, CB, IEC62133, UN38.3

AC Ports: Three-pronged outlets (110V, 1600W peak) with GFCI protection, Pass-through charging capability, Surge protection, Overload protection, Short circuit protection

DC Ports: 12V/10A cigarette lighter port, 12V/10A DC5521 port

USB Ports: 2 x USB-A (5V/3A), 1 x USB-C (5V/3A, 9V/2A, 12V/1.5A)

Built-in LED light: 3 brightness levels (high, medium, low), SOS mode

Input charging: AC wall outlet (110V), DC car charger (12V/10A), Solar panel (12V/10A)

Recommended solar panel: 100W-200W solar panel

Packing list

Pro1600 Power Station

AC Charger

Car Charger

Solar Panel Connector

User Manual

Port Input Description

AC Input(Black) : 110-120V/15A/1800W Max

DC Input(Blue) : 12V/10A/120W Max

Solar Input(Blue) : 12V/10A/120W Max

Port Output Description

AC Output(Black) : 110-120V/15A/1800W Max

DC Output(Blue) : 12V/10A/120W Max

USB-A Output(Blue) : 5V/3A/15W Max

USB-C Output(Blue) : 5V/3A, 9V/2A, 12V/1.5A/60W Max

Type-C Input&Output(Blue) : 5V/3A, 9V/2A, 12V/1.5A/60W Max

Description of product features

Front view

Rear view

Description of product features

Top view

Side view

Socket specification description

Europe

United States

United Kingdom

Note: Please choose the appropriate socket according to your local standard.

Key operation

Key operation

- Press the switch on and hold down for 3-5 seconds, all lights flash, the machine boots up successfully, and the machine shuts down in the same way.
- Short press the switch to turn on the LED light, short press again to turn off the LED light, and long press to switch the LED light to SOS mode.
- Short press the switch to view the current power level.

Charging using mains electricity

Connect the AC charger to the AC input port on the side of the machine, and then connect the other end to a standard AC power outlet. The machine will begin charging automatically. The charging time depends on the battery level and the power of the AC charger.

Charging using solar panels

Connect the solar panel to the DC input port on the side of the machine. Make sure the solar panel is facing the sun directly for optimal charging efficiency.

Charging using a car charger

Connect the car charger to the DC input port on the side of the machine, and then plug the other end into a 12V car cigarette lighter socket. The machine will begin charging while the car is running.

Charging using multiple methods

You can charge the machine using multiple methods at the same time to reduce charging time.

Precautions

- When using the machine to charge mobile phones, tablets and other electronic devices, please ensure that the power is sufficient.
- Please do not overload the machine, and the total power of the connected devices should not exceed the rated power of the machine.
- Please keep the machine away from heat sources and flammable materials to avoid fire hazards.
- Please do not disassemble or repair the machine yourself, and contact professionals if any malfunctions occur.
- Please keep the machine away from children to avoid accidental touching or misuse.

Display function description

Charge/discharge indicator description

The charge/discharge indicator is located on the front panel of the machine. It displays the current charge/discharge status of the machine.

- Solid green: The machine is fully charged.
- Flashing green: The machine is charging.
- Solid red: The machine is discharging.
- Flashing red: The machine is low on battery and needs to be charged.

Battery level indicator description

The battery level indicator is located on the front panel of the machine. It displays the current battery level of the machine.

- 4 solid green LEDs: The battery is fully charged.
- 3 solid green LEDs: The battery is at 75% capacity.
- 2 solid green LEDs: The battery is at 50% capacity.
- 1 solid green LED: The battery is at 25% capacity.
- 1 flashing red LED: The battery is low and needs to be charged.

Display function description

Port indicator description

AC Output	Solid green: AC output is on. Off: AC output is off.
DC Output	Solid green: DC output is on. Off: DC output is off.
USB Output	Solid green: USB output is on. Off: USB output is off.
AC Input	Solid green: AC input is connected. Off: AC input is disconnected.
Solar Input	Solid green: Solar input is connected. Off: Solar input is disconnected.

Digital tube display description

Battery Level	Displays the current battery level as a percentage.
Input Power	Displays the current input power in watts.
Output Power	Displays the current output power in watts.
Time Remaining	Displays the estimated time remaining until the battery is fully charged or discharged.

Protection prompt description

Overload protection	Overload protection will be triggered when the total power of the connected devices exceeds the rated power of the machine. The machine will automatically cut off the output power to protect the internal circuits.	Please reduce the number of connected devices or the power of the devices to ensure that the total power does not exceed the rated power of the machine.
Short circuit protection	Short circuit protection will be triggered when a short circuit occurs in the output circuit. The machine will automatically cut off the output power to protect the internal circuits.	Please check the output circuit for any short circuits and repair them before restarting the machine.
Overheat protection	Overheat protection will be triggered when the internal temperature of the machine exceeds the safe operating temperature. The machine will automatically cut off the output power to protect the internal components.	Please ensure that the machine is placed in a well-ventilated area and avoid direct sunlight. Wait for the machine to cool down before restarting it.
Low battery protection	Low battery protection will be triggered when the battery level is too low. The machine will automatically cut off the output power to prevent over-discharge.	Please charge the machine as soon as possible to avoid damage to the battery.

Operating diagram

Note: The above diagram is for reference only. Please refer to the actual product for the correct operation.

Charging the product

AC Charging

To charge the Pro1600 using the included AC charger, follow these steps:

1. Plug the AC charger into a standard AC outlet (110V).
2. Connect the other end of the AC charger to the AC input port on the Pro1600.
3. The Pro1600 will begin charging automatically. The charging time will depend on the battery level and the power of the AC charger.

Car Charging

To charge the Pro1600 using the included car charger, follow these steps:

1. Plug the car charger into a 12V car cigarette lighter socket.
2. Connect the other end of the car charger to the DC input port on the Pro1600.
3. The Pro1600 will begin charging while the car is running.

Solar Charging

To charge the Pro1600 using solar panels, follow these steps:

1. Connect the solar panels to the solar charge controller.
2. Connect the solar charge controller to the DC input port on the Pro1600.
3. Place the solar panels in a location where they will receive direct sunlight.
4. The Pro1600 will begin charging when the solar panels are receiving enough sunlight.

Multiple Charging

You can charge the Pro1600 using multiple methods at the same time to reduce charging time.

Charging the product

Solar Charging

To charge the Pro1600 using solar panels, follow these steps:

1. Connect the solar panels to the solar charge controller.
2. Connect the solar charge controller to the DC input port on the Pro1600.
3. Place the solar panels in a location where they will receive direct sunlight.
4. The Pro1600 will begin charging when the solar panels are receiving enough sunlight.

Multiple Charging

You can charge the Pro1600 using multiple methods at the same time to reduce charging time.

Car Emergency Charging Operation

Car Emergency Charging Operation

To charge the Pro1600 in an emergency using your car, follow these steps:

1. Locate the DC input port on the Pro1600.
2. Connect the car charger to the DC input port on the Pro1600.
3. Plug the car charger into a 12V car cigarette lighter socket.
4. The Pro1600 will begin charging while the car is running.

Precautions

- Do not overload the car charger or the Pro1600. Make sure that the total power of the devices you are charging does not exceed the rated power of the car charger or the Pro1600.
- Do not use the car charger or the Pro1600 in extreme temperatures. The car charger and the Pro1600 should be used in a temperature range of 0°C to 40°C (32°F to 104°F).
- Do not use the car charger or the Pro1600 if it is damaged. If the car charger or the Pro1600 is damaged, do not use it and contact customer service for repairs.
- Do not leave the car charger or the Pro1600 unattended while it is charging. Monitor the car charger and the Pro1600 while they are charging and unplug them when they are fully charged.

Frequently Asked Questions

Frequently Asked Questions

Q: How long does it take to charge the Pro1600?

A: The charging time depends on the battery level and the power of the charger. It typically takes 8 hours to fully charge the Pro1600 using the AC charger, 12 hours using the car charger, and 24 hours using solar panels.

Q: How many devices can I charge at once?

A: The Pro1600 has a maximum output of 1600W. You can charge multiple devices at once as long as the total power does not exceed this limit.

Q: Can I use the Pro1600 in the rain?

A: No, the Pro1600 is not waterproof. Do not expose it to water or other liquids.

Q: What should I do if the Pro1600 is not working properly?

A: If the Pro1600 is not working properly, please contact customer service for assistance.

Basic description of battery

Basic description of battery

The Pro1600 uses a lithium iron phosphate battery, which is safer and more durable than traditional lithium-ion batteries. The battery has a capacity of 1600Wh.

Battery life

The battery life of the Pro1600 depends on the power of the devices you are charging and the frequency of use. With typical use, the battery can last for several years.

Battery replacement

The battery in the Pro1600 is not user-replaceable. If the battery needs to be replaced, please contact customer service.

Battery maintenance

To maintain the battery, please follow these guidelines:

- Do not expose the battery to extreme temperatures.
- Do not leave the battery fully discharged for extended periods of time.
- Charge the battery at least once every six months, even if you are not using it.

Battery disposal

Please dispose of the battery properly according to local regulations. Do not throw the battery in the trash or incinerate it.

Warranty Card

Warranty Card

We warrant that each of the products is in sample, which is sent equal from the user of the product, and the product is free from defects in materials and workmanship.

Warranty Policy

If the product is found to be defective during the warranty period, we will replace it with a new one at no charge to you.

Warranty Exclusions

The warranty does not cover damage caused by:

- Accidents, misuse, or abuse of the product.
- Unauthorized repairs or modifications to the product.
- Failure to follow the instructions provided in the manual.
- Normal wear and tear, including but not limited to scratches, dents, and discoloration.

How to Make a Warranty Claim

To make a warranty claim, please contact our customer service department at [insert contact information]. You will be required to provide proof of purchase and a description of the problem you are experiencing.

Limitation of Liability

Our liability under this warranty is limited to the repair or replacement of the product. We shall not be liable for any indirect, incidental, or consequential damages arising from the use of the product.

Governing Law

This warranty shall be governed by and construed in accordance with the laws of [insert jurisdiction].

FCC Warning

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Declaration of basic and hazardous substances in electronic information products

Toxic or hazardous substances and elements					
Part name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Body	O	O	O	O	O	O
Battery	O	O	O	O	O	O
Charger	O	O	O	O	O	O
Cable	O	O	O	O	O	O

O: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in SJ/T 11363-2006.

X: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirement specified in SJ/T 11363-2006.

Please note that the environment-friendly use period (EFUP) of this product is 10 years. The hazardous substances contained in the product will not leak or mutate under normal use conditions, and the use of the product will not cause serious environmental pollution or damage to personal or property.

Product qualification certificate

Inspector: [illegible]

Inspection date: [illegible]

Return Registration Form

Product model: _____

Serial No.: _____

Purchase date: _____

Name of the buyer: _____

Reason for return: _____

Please fill in the above information and send it to the following address: [illegible]

封底