



Intelligent recording pen User Manual

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1

Tips:
1. Before using the recording pen for the first time, please fully charge it.
2. You can connect to the network through WiFi/mobile hotspot. Tip: The recording pen is connected to the network and does not support secondary recognition WiFi, such as airport WiFi and public WiFi.
3. When the recording pen is in low battery mode or the WiFi hotspot signal is poor, it may displayRecording timeout, it is recommended to replace the WiFi hotspot link on your phone and try again.
4. Please carefully refer to this manual, which will provide you with detailed instructions on the operation of the product. Wishing you a pleasant recording journey.

2

1. Product packaging content



3

II. Key introduction
Charging interface
Power switch
Touch screen
Open key
Phonetic a key
Quick recording key
Phonetic b key
return key
Volume key+
Volume key-

Due to system updates may cause differences between the picture language and the real thing, please prevail in kind.

4

III. Operation guide
1. Start or restart the device
Power on: Press and hold the power button for 3 seconds to start the device.
Shutdown/Restart: Press and hold the power button for 3 seconds, select Shutdown/restart. Unlock/Lock Screen: Slide the screen in any direction/click the unlock button.

5

IV. Real-time transcription
1. Recording operation guide
The device supports standard recording/speech recording/voice transcription/real-time transcription.
2. How to connect to the Internet?
Connect to WiFi or mobile hotspot to connect.
3. If I don't have a WiFi, how can we record?
Offline recording currently supports recording 6 languages: Chinese, English, Japanese, Korean, French, Spanish.
4. What are the advantages of recording pen over a mobile phone?
Not only does it support recording, but it also supports standard recording/speech recording/real-time transcription. Supports offline Chinese, English, Japanese, Korean, French, Spanish.
5. How to use the hand-held recording pen?
The recording pen uses a 100mAh polymer lithium battery and can be used for about 5 hours under normal operation. Charging only takes about 3 hours and can be reused repeatedly.
Note: The translation machine is not suitable for networks that require secondary authentication, such as airport WiFi and public WiFi.

6

V. Settings
1. Recording transcription
Support online/offline Chinese, English, Japanese, Korean, French, Spanish click standard transcription icon to enter the recording interface, click the recording button at the bottom of the screen to start recording and transcribe in real-time. Click the "stop" button to stop recording and save the recording. Click the "Power Off" icon to save the recording, click the "Power Off" icon in the top right corner and select the text that needs to be removed. Finally, click the "Delete" icon to delete the transcription recording of the file.
2. Connect to the Internet (WiFi/Hot-spot)
Click on the settings button: Select and click on the WiFi icon to enter the WLAN interface, open the WAN button, and select the WiFi icon. After clicking, enter the WiFi password and click on the top right corner to join the WiFi. If the WiFi display is blue, it indicates a successful connection to the network network.
3. Spec translation
Support online/offline Chinese, English, Japanese, Korean, French, Spanish click to spec translation icon and follow the operating instructions.
4. Local music
Place the audio file below the specified directory for playback.
Note: Connect local music to computer and upload it directly.
5. How to use the hand-held recording pen?
The recording pen uses a 100mAh polymer lithium battery and can be used for about 5 hours under normal operation. Charging only takes about 3 hours and can be reused repeatedly.
Note: The translation machine is not suitable for networks that require secondary authentication, such as airport WiFi and public WiFi.

7

VI. FAQ
1. How does the recording record?
Power on: Press and hold the power button for 3 seconds to start the device.
Shutdown/Restart: Press and hold the power button for 3 seconds, select Shutdown/restart. Unlock/Lock Screen: Slide the screen in any direction/click the unlock button.
2. Why can't the recording record when the screen is locked?
Only 13 languages, click on the "voice transcription" icon to enter the transcription interface. Click language A or language icon, select the language to be translated. Press and hold down the power button for 10 seconds to forcibly restart the device. After restarting, it can be used normally.
3. Why does the recording record when the screen is locked?
Note: Recording transcription and transliteration require network status.
4. Exchange rate
Support currency conversion for various countries.
Recording in our WiFi network signal is poor. It is recommended to replace with a strong WiFi or connect to a hotspot. Click the "language" icon. Unrecognized: The recording pen cannot recognize language. Try to speak into the microphone as possible and increase the volume.

8

VII. Conclusion
Thank you for using our product. If you have any questions or need further assistance, please feel free to contact us. We will do our best to provide you with timely and helpful support.

9