




W01

Quick Guide
Open ear Wireless Headphone


Customer Service

Email: woinnmm2023@outlook.com



FCC ID : 2A7IT-W01


Package Contents



Charging Case * 1PC



Earbuds * 1 Pair




Type-C Charging
Cable* 1PC



User Manual * 1 PC

01

Product Overview



02

Product Specifications

- Model: W01
- Bluetooth version: V5.3+EDR
- Range: > 33FT (10M)
- Support: HSP/HFP/A2DP/AVRCP
- Frequency response: 20Hz-20KHz
- Talk time: > 8 hours
- Music time: > 8 hours
- Earbud charging time: 1.5 hours
- Earbud weight: 10g
- Charging case weight: 58g
- Charging case size: 112 x 62 x 27mm
- Earbud battery: 3.7V/40mAh
- Charging case battery: 3.7V/400mAh
- Charging case input voltage: DC 5V/500mA

Get Start

Activate the WOINNMM OWS Earbud:

Take the wireless earbuds out of the charging case first, then put earbuds back into the case. The case battery LED display will light up and the red indicator light of the earbud lights up as well.


03

Note:

when you put the earbuds back into the charging case, and the case battery LED display is on, then the earbud is activated and in charging mode. If the case LED display is off, please charge for the case via the USB-C cable. (More pairing details please refer to the below instructions).


Headphone Paring

Step 1: Take out WOINNMM ows earbuds from the case, the ows earbud will power on automatically, following with voice prompt "power on", then both Left(L) earbud and Right(R) earbud will auto- connect each other and you will hear voice prompt "du", now the ows earbuds in the pairing mode.



04

Step 2: Please search and connect the WOINNMM OWS bluetooth device name "W01" from bluetooth list via your phone or pad, you will hear the voice prompt "connected". Now the ows earbuds pairing successfully.



05

Note :

While connecting the W01 with your phone, Please check whether you can't hear the voice prompt "du" from the L/R earbud or you will see two the same device name "W01" from bluetooth list, that all need re-pairing as above steps.

Attention

1. Auto-reconnect :

The ows earbuds will auto reconnect while the earbuds disconnected with the mobile phone due to some objective factors, you also will hear the voice prompt "connected" after reconnect succeeded.

2. Nano mode re-connect :

when you take out only one side earbud for second use, the earbud also will auto-connect with your phone, it will also enter in pairing mode if failed auto-connect with your phone, please manual connect in this situation (select the device name from your phone by manually).

3. Auto-connect between Left (L) and Right (R) earbud

Normally the Left and Right earbud will auto-connect after they're out from the case, and you will hearing the voice prompt "du". In case the L and R earbuds failed auto-connect, please put them back in the case, then take them out for connect it again.

4. Auto Power off

when you take out ows earbuds from the case and does not any connection, the earbuds will power off automatically in 5 minutes.

06

Charging

a. Charge for OWS earbuds


put the ows earbud in the charging case and charge for the earbud. The earbuds flash red light while charging

Low Battery Prompt:

If the earbud battery life is less than 3.2V, a low battery prompt with "dudu" and it will remind with each 30 seconds, till the earbud automatically power off as the battery life under 3V

b. Charge the Charging case

- Charging way : USB-C cable
- Battery display: digital LED display (DC 5V/400mA)



Touch Control

Take out the earbud from the case power on

Press the touch area and Hold 5 seconds or Put the earbud back in the case power off

07

one tap either earbud answer/hang up

press either earbud and hold for 2 seconds reject call

one tap either earbud Play/Pause

Tap three times (R) earbud volume up

Tap three times (L) earbud Volume down

Double tap (R) earphone Next Track

08

Double tap (L) earphone Previous Track

press either earbud and hold for 2 seconds Siri/Voice assistant

FCC Radiation Exposure Statement:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

09

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WOINNMM CE FCC
POWER:DC 5V(AC Adapter)
FCC ID: 2A7IT-W01
MADE IN CHINA
After-sell: woinnmm2023@outlook.com

10

WARRANTY CARD

Warranty period:

The warranty period of this product is 12 months from the date of purchase (non-human damage).

Quality Assurance Service:

(1) This product is in the period of warranty, any defective caused by the quality of the product (only limited to non-human damage).

please use this warranty card to get in touch with the dealer to enjoy the warranty service.

(2) Our warranty service does not include the freight of repair products and door-to-door service.

The user not entitled to quality assurance service as below clauses:

- 1.No warranty card or product repair label was damaged;
- 2.Damage caused by user's disassembly;
- 3.Man-made damage caused by serious falls, water inflow etc....
- 4:Failure or damage caused by force majeure.

Customer Service Information

Name	
Phone	
Address	
Model	
Malfunction	
Date of purchase	
Maintenance date	

11