



FLOITTYU Bluetooth Speaker Alarm Clock

User Guide

Please read me before using


SAFETY INFORMATION

- * Please read and keep this User Guide, and pay attention to the below warnings.
- * Please put this speaker alarm clock in a stable place, to avoid any damage caused by accident.
- * Please keep this speaker alarm clock away from any liquid or fire.
- * Please don't leave this speaker alarm clock in high temperature, or high moist environment for long time.
- * Please don't insulate this speaker alarm clock.
- * The charging voltage is DC 5V. The speaker alarm clock internal chip will be burned out and couldn't work normally if using higher charger.

PACKING LIST

- 1 pcs Speaker Alarm Clock
- 1 pcs Charging Cable
- 1 pcs Gift Bag
- 1 pcs User Guide

OVERVIEW AND INSTRUCTION FOR USE



Function Introductions:

LED light
Blue LED: lighting when charging and light off when full charged.
Blue LED: flashing fast when to search BT signal or scan FM signal and long time lighting after pairing.
Flashing slow when BT/AM/FM working and long time lighting when paused.
1. (① ②) Long press these two keys at the same time so you can turn off the speaker and then turn on the speaker and search FM, and then match the speaker to the mobile phone. There will be a prompt sound after connection succeeded.
(Note: There is a memory function for the Bluetooth speaker. Turn off the Bluetooth of the phone, then turn on the speaker, and then turn on the phone, then search the speaker to the mobile phone. There will be a little temperature deviation since the temperature sensor is built in.
3.The screen will go back to the darkest brightness after 20 minutes of any setup.
4.When charging and the time is lighting on, the speaker will power off within 2 hours automatic. When TF/Aux/FM mode, and to power off it paused within 30mins.

① OPERATION INSTRUCTIONS:

Clock/Alarm Setting Instructions:
Clock/Alarm and speaker are two independent modes.
Press (① ②) for 3 seconds to turn off the speaker mode, short press (①) once or twice again, to get into the clock/alarm mode for setup, and the numbers will start to scroll.
Press (③ ④) to shift forward and backward in order to set the following: clock's hours/minutes, 10 hours/minutes/rings, AL2 hours/minutes/rings.
Press (⑤ ⑥) to set the time, and then press (⑦ ⑧) to set the alarm's hours/minutes, the type of the rings (6 rings available; see notes below), the ON/OFF of the rings.
Press (⑨ ⑩) to confirm each setup value, every time (time setting need to confirm, alarm setting need to confirm). The settings will fail if they haven't got confirmation.

② How to connect the mobile phone by Bluetooth?
1.Long press (① ②) button for 3 seconds to turn on the speaker, the small BT icon will flash in the left down-corner of the screen.
2.Wireless search mode: long press (③ ④) to search FM and search FM, and then match the speaker to the mobile phone. There will be a prompt sound after connection succeeded.
(Note: There is a memory function for the Bluetooth speaker. Turn off the Bluetooth of the phone, then turn on the speaker, and then turn on the phone, then search the speaker to the mobile phone. There will be a little temperature deviation since the temperature sensor is built in.
3.The screen will go back to the darkest brightness after 20 minutes of any setup.
4.When charging and the time is lighting on, the speaker will power off within 2 hours automatic. When TF/Aux/FM mode, and to power off it paused within 30mins.

How to connect the mobile phone by Aux?

1.Long press (① ②) button for 3 seconds to turn on the speaker, the small BT icon will flash in the left down-corner of the screen.
2.Wireless search mode: long press (③ ④) to search FM and search FM, and then match the speaker to the mobile phone. There will be a prompt sound after connection succeeded.
(Note: There is a memory function for the Bluetooth speaker. Turn off the Bluetooth of the phone, then turn on the speaker, and then turn on the phone, then search the speaker to the mobile phone. There will be a little temperature deviation since the temperature sensor is built in.
3.The screen will go back to the darkest brightness after 20 minutes of any setup.
4.When charging and the time is lighting on, the speaker will power off within 2 hours automatic. When TF/Aux/FM mode, and to power off it paused within 30mins.

How to use Micro SD/TF Card?

Insert the Micro SD/TF Card into the TF slot of speaker, there will be a prompt sound, and then the speaker will get into the TF mode when the card is under the TF card mode.
It supports the following formats: MP3, WAV.
It supports maximum 32GB TF card.

How to use FM radio?

Press (① ②) to turn into FM mode, and insert the antenna to the Aux slot.
Long press M button and the speaker will get into FM channels searching mode automatically. When the red indicator will be on and blue, will flash quickly. The speaker will search for the radio station, and the search time depends on the circumstances and signal. Radio will be good and with strong signal when there is less interference, will not be good and with weak signal when there is much interference.

How to use Aux?

1.There will be one or two (① ②) displaying on the screen if the alarm is set up successfully. Otherwise the alarm setting will fail.
2.Short press (③ ④) to set the alarm when it starts, press any other buttons to get into snooze status. The alarm will ring 5 times, 10 minutes' interval each time in snooze status. The ring lasts about 1 minute each time.

3.The speaker can play the audio files from the TF card, and the TF card audio source also could be used as alarms rings. The TF card has to be put into the speaker and the audio files from the TF card can be used. The rings will play the audio files in turns, as the speaker works in TF card mode. The alarm will play the first built-in ring if there is no card in the speaker; even if TF card has been set as the ring source for the alarm.

③ Bluetooth Speaker Instruction:

Two Modes Instruction:
The speaker is with Bluetooth Speaker Mode.
Bluetooth Speaker Mode: long press (① ②) button to turn on, the speaker is in the pairing mode, and the speaker can't be set.
Clock/Alarm Setting Mode: long press (① ②) button to turn off the speaker and shift to clock/alarm mode, while Bluetooth speaker is not functional. Short press (① ②) to clock/alarm mode, and the number will flash, and then the clock and alarm can be set up.
The speaker mode will be off automatically after 2 hours with Bluetooth disabled or without any operations.

F&Q

1.It cannot be matched with the device by Bluetooth. (1) Turn off the speaker and mobile phone, and then turn on both. Rematch. (2) If there are too many Bluetooth devices around, turn off the other Bluetooth devices in order to connect to one device.
2.Sound is too small or distortion is too much: (1) Maybe the battery runs out. Please charge it. (2) Turn up the volume of the mobile phone.
3.Sound goes off: Check the range between the speaker and the device is more than 10 meters. Or check if there are any barriers between the speaker and the device.

DISPOSAL OF ELECTRICAL AND ELECTRONIC EQUIPMENT

 This symbol on the product or packaging means that the product should not be treated as household waste. Do not throw garbage at the end of its life, but take it to a collection center for recycling. In this way you will help to protect the environment and be able to prevent any negative consequences that it could have on the environment and human health.

We hope you never have such need, but if you do, our friendly and hassle-free service will work hard to put a smile back on your face. We hope that our after-sales service can make you satisfied.

Notice: As Amazon separates customer orders and product review, we CAN'T find your order ID and email address depend on product reviews. Please contact us directly via the email below.

 Support@fabulouscool.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction