



Phigolf2

PHG-200

Product Quick Manual

Contents language –

English	2
---------------	---

Precautions

Read this manual and the following instructions carefully before using the product.



Warning

Safety warning

- This product contains a lithium-polymer battery. Do not give an impact or damage the product.
- Do not expose the product to the temperature of 60°C (140°F) or higher.
- Do not disassemble the product, break into pieces, make holes or put in fire or water.
- Do not touch the product or the charger while charging the product.

Precautions before use

- This product may malfunction near an object containing a magnet.
- This product needs a device with the Phigolf application.
- The figures shown in this manual can be different with the actual product.
This manual is subject to change without a prior notice for improvement of performance.

Precautions

[WARNING]

· This product contains a lithium-polymer battery. Do not expose the product to a temperature of 60°C (140°F) or higher. Stop using the product immediately if it emits smoke or a strange smell, or otherwise behaves abnormally. Do not disassemble the product or break it into pieces. Avoid contact with liquid, and do not allow liquids or foreign objects inside. Do not touch the product or the charger while charging the product. Store this equipment out of the reach of children and infants. Proper periodic maintenance is required as a malfunction of this product could result in serious damage to the system or injury to personnel. Keep at least 2M distance from people or objects (e.g. TV, Furniture, etc.) around. Do not apply excessive force when installing a sensor. Make sure that the head, strap, and grip are properly assembled. Do not use in any explosive, flammable, corrosive, humid environments or wet conditions nor near to such materials.

[LIMITATION OF LIABILITY AND ASSUMPTION OF RISKS]

· I have reviewed the instruction and that I freely accept and fully assume all risks, dangers, and hazards associated with the use of the equipment. I am aware using this product involves many risks, dangers and hazards including, but not limited to slips and falls; being hit by the disassembled products; causing property destruction by disassembled products; and negligence of other persons. I am familiar with the proper use of the equipment and I accept full responsibility for the care of the product. The product may not be modified, copied, or reproduced. This product may not be used for unlawful purposes and that use is expressly prohibited under the terms and conditions of its use.

Contents of the package



Phigolf 2 Sensor





USB C charge cable



Quick manual

Names and functions of the parts



How to use

How to mount

Insert the product into the grip end hole of the swing stick or club.
Push the club insert to the end.

※Your swing stick or club may have no or smaller hole in the grip end.



Power on



Press and hold the power button for at least 1 second.

How to charge the battery

Remove the USB cover, connect the USB cable, and connect the other end of the USB cable into a computer or an charger adapter. Charge the battery fully before first use of the product.
Do not use an auxiliary battery to recharge the device. The device may not be recharged depending on the model no.

PHIGOLF Installing the application

Supporting environment

Android 5.0 / iOS 9 or later version



Google play



iOS

Downloading and installing the application

1. Search PHIGOLF in Google Play or Apple Appstore.
2. Download and install the app.
3. When installation is completed, a PHIGOLF icon appears on the screen of the mobile device.



Other Apps


Connecting the product with the application

Before connecting the application with the mobile device, check if the mobile device supports the Bluetooth communication.
[Bluetooth ver. 4.1 or higher]

1. Switch on the Bluetooth function of the mobile device with the app.
2. Start the PHIGOLF app.
3. Push the power button on the product.
4. The product is automatically recognized by the menu screen of the app.
5. Touch the OK button to approve the product, and you can use all the functions of the app.

How to swing

1. On the swing standby screen, take the address with a club or swing stick with the device mounted on it.



2. Hold the address position until the Ready sign appears on the app.
3. Swing the club when the Ready sign appears. The Ready sign appears on the app screen with a tone, and the status LED of the product maintains the On position.
(During Ready, even a small practice swing can be recognized as an actual swing.)
4. If the device fails to sense your swing, a failure message appears on the app screen. Take the address, and swing the club following the Ready sign.

Warranty

The warranty period is 1 year from the date of purchase of the product. No warranty is provided for a damage caused by the user, whether such damage is intentional or not, or force majeure.

To use the warranty service, send us the defective product with the receipt issued by the original seller by mail. For the defect within the category of warranty, the product will be repaired, replaced or refunded.

If you cannot contact the original seller, you can visit the website of Phigolf Networks (www.phigolf.com) to receive the warranty service.

DA14585/6	ROM128kBytes OTP 64KBytes RAM 96kBytes FLASH 2Mbit (586)	14 25	WL-CSP34 size 2.4x2.6x0.4mm, pitch 0.4mm QFN40 size 5x5x0.9mm, pitch 0.4mm Pin to pin compatibility to DA14580/1/3 in QFN40	Bluetooth 5.0 Core • Cortex M0 application processor • Power supply 0.9-3.6V (585) • Single pin RF I/O • Rich set of analog and digital peripherals • 8 simultaneous connections • Optimized boot time	Beacon & proximity Health, Fitness & HID Smart Home Smart Cards Automotive Voice command RCU Wireless charging
-----------	--	----------	---	--	--

FCC compliance information

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer may void the user's authority to operate the equipment under FCC rules.



www.phigolf.com



PHINETWORKS