











Band41-10MHz-QPSK-40620-1RB#49-0.009~0.15-PASS




Band41-10MHz-QPSK-40620-1RB#49-0.15~30-PASS




Band41-10MHz-QPSK-40620-1RB#49-30~1000-PASS




Band41-10MHz-QPSK-40620-1RB#49-1000~3000-PASS



Band41-10MHz-QPSK-40620-1RB#49-3000~18000-PASS




Band41-10MHz-QPSK-40620-1RB#49-18000~27000-PASS




Band41-10MHz-QPSK-40620-50RB#0-0.009~0.15-PASS




Band41-10MHz-QPSK-40620-50RB#0-0.15~30-PASS




Band41-10MHz-QPSK-40620-50RB#0-30~1000-PASS




Band41-10MHz-QPSK-40620-50RB#0-1000~3000-PASS



Band41-10MHz-QPSK-40620-50RB#0-3000~18000-PASS




Band41-10MHz-QPSK-40620-50RB#0-18000~27000-PASS



Band41-10MHz-16QAM-40620-1RB#0-0.009~0.15-PASS




Band41-10MHz-16QAM-40620-1RB#0-0.15~30-PASS




Band41-10MHz-16QAM-40620-1RB#0-30~1000-PASS




Band41-10MHz-16QAM-40620-1RB#0-1000~3000-PASS




Band41-10MHz-16QAM-40620-1RB#0-3000~18000-PASS



Band41-10MHz-16QAM-40620-1RB#0-18000~27000-PASS







Band41-10MHz-16QAM-40620-50RB#0-0.009~0.15-PASS




Band41-10MHz-16QAM-40620-50RB#0-0.15~30-PASS




Band41-10MHz-16QAM-40620-50RB#0-30~100-0-PASS




Band41-10MHz-16QAM-40620-50RB#0-1000~3000-PASS




Band41-10MHz-16QAM-40620-50RB#0-3000~18000-PASS



Band41-10MHz-16QAM-40620-50RB#0-18000~27000-PASS







Band41-10MHz-QPSK-41540-1RB#49-0.009~0.15-PASS




Band41-10MHz-QPSK-41540-1RB#49-0.15~30-PASS




Band41-10MHz-QPSK-41540-1RB#49-30~1000-PASS




Band41-10MHz-QPSK-41540-1RB#49-1000~3000-PASS



Band41-10MHz-QPSK-41540-1RB#49-3000~18000-PASS




Band41-10MHz-QPSK-41540-1RB#49-18000~27000-PASS




Band41-10MHz-QPSK-41540-50RB#0-0.009~0.15-PASS




Band41-10MHz-QPSK-41540-50RB#0-0.15~30-PASS




Band41-10MHz-QPSK-41540-50RB#0-30~1000-PASS




Band41-10MHz-QPSK-41540-50RB#0-1000~3000-PASS



Band41-10MHz-QPSK-41540-50RB#0-3000~18000-PASS




Band41-10MHz-QPSK-41540-50RB#0-18000~27000-PASS




Band41-10MHz-16QAM-41540-1RB#0-0.009~0.15-PASS




Band41-10MHz-16QAM-41540-1RB#0-0.15~30-PASS




Band41-10MHz-16QAM-41540-1RB#0-30~1000-PASS




Band41-10MHz-16QAM-41540-1RB#0-1000~3000-PASS





Band41-10MHz-16QAM-41540-1RB#0-3000~18000-PASS




Band41-10MHz-16QAM-41540-1RB#0-18000~27000-PASS










Band41-15MHz-QPSK-39725-1RB#74-0.009~0.15-PASS




Band41-15MHz-QPSK-39725-1RB#74-0.15~30-PASS




Band41-15MHz-QPSK-39725-1RB#74-30~1000-PASS




Band41-15MHz-QPSK-39725-1RB#74-1000~3000-PASS



Band41-15MHz-QPSK-39725-1RB#74-3000~18000-PASS




Band41-15MHz-QPSK-39725-1RB#74-18000~27000-PASS




Band41-15MHz-QPSK-39725-75RB#0-0.009~0.15-PASS




Band41-15MHz-QPSK-39725-75RB#0-0.15~30-PASS




Band41-15MHz-QPSK-39725-75RB#0-30~1000-PASS




Band41-15MHz-QPSK-39725-75RB#0-1000~3000-PASS




Band41-15MHz-QPSK-39725-75RB#0-3000~18000-PASS




Band41-15MHz-QPSK-39725-75RB#0-18000~27000-PASS







Band41-15MHz-16QAM-39725-1RB#74-0.009~0.15-PASS




Band41-15MHz-16QAM-39725-1RB#74-0.15~30-PASS




Band41-15MHz-16QAM-39725-1RB#74-30~100-0-PASS




Band41-15MHz-16QAM-39725-1RB#74-1000~3000-PASS



Band41-15MHz-16QAM-39725-1RB#74-3000~18000-PASS




Band41-15MHz-16QAM-39725-1RB#74-18000~27000-PASS



Band41-15MHz-16QAM-39725-75RB#0-0.009~0.15-PASS



Band41-15MHz-16QAM-39725-75RB#0-0.15~30-PASS




Band41-15MHz-16QAM-39725-75RB#0-30~100-PASS




Band41-15MHz-16QAM-39725-75RB#0-1000~3000-PASS




Band41-15MHz-16QAM-39725-75RB#0-3000~18000-PASS



Band41-15MHz-16QAM-39725-75RB#0-18000~27000-PASS






Band41-15MHz-QPSK-40620-1RB#74-0.009~0.15-PASS




Band41-15MHz-QPSK-40620-1RB#74-0.15~30-PASS




Band41-15MHz-QPSK-40620-1RB#74-30~1000-PASS




Band41-15MHz-QPSK-40620-1RB#74-1000~3000-PASS





Band41-15MHz-QPSK-40620-1RB#74-3000~18000-PASS



Band41-15MHz-QPSK-40620-1RB#74-18000~27000-PASS









Band41-15MHz-16QAM-40620-1RB#74-0.009~0.15-PASS




Band41-15MHz-16QAM-40620-1RB#74-0.15~30-PASS




Band41-15MHz-16QAM-40620-1RB#74-30~100-0-PASS




Band41-15MHz-16QAM-40620-1RB#74-1000~3000-PASS





Band41-15MHz-16QAM-40620-1RB#74-3000~18000-PASS





Band41-15MHz-16QAM-40620-1RB#74-18000~27000-PASS



















Band41-15MHz-16QAM-41515-75RB#0-0.009~0.15-PASS



Band41-15MHz-16QAM-41515-75RB#0-0.15~30-PASS




Band41-15MHz-16QAM-41515-75RB#0-30~100-PASS




Band41-15MHz-16QAM-41515-75RB#0-1000~3000-PASS




Band41-15MHz-16QAM-41515-75RB#0-3000~18000-PASS



Band41-15MHz-16QAM-41515-75RB#0-18000~27000-PASS







Band41-20MHz-QPSK-39750-1RB#99-0.009~0.15-PASS




Band41-20MHz-QPSK-39750-1RB#99-0.15~30-PASS




Band41-20MHz-QPSK-39750-1RB#99-30~1000-PASS




Band41-20MHz-QPSK-39750-1RB#99-1000~3000-PASS





Band41-20MHz-QPSK-39750-1RB#99-3000~18000-PASS





Band41-20MHz-QPSK-39750-1RB#99-18000~27000-PASS
















Band41-20MHz-QPSK-40620-1RB#99-0.009~0.15-PASS




Band41-20MHz-QPSK-40620-1RB#99-0.15~30-PASS




Band41-20MHz-QPSK-40620-1RB#99-30~1000-PASS




Band41-20MHz-QPSK-40620-1RB#99-1000~3000-PASS




Band41-20MHz-QPSK-40620-1RB#99-3000~18000-PASS




Band41-20MHz-QPSK-40620-1RB#99-18000~27000-PASS




Band41-20MHz-QPSK-40620-100RB#0-0.009~0.15-PASS




Band41-20MHz-QPSK-40620-100RB#0-0.15~30-PASS




Band41-20MHz-QPSK-40620-100RB#0-30~100-PASS




Band41-20MHz-QPSK-40620-100RB#0-1000~3000-PASS





Band41-20MHz-QPSK-40620-100RB#0-3000~18000-PASS





Band41-20MHz-QPSK-40620-100RB#0-18000~27000-PASS



















Band41-20MHz-16QAM-41490-1RB#0-0.009~0.15-PASS




Band41-20MHz-16QAM-41490-1RB#0-0.15~30-PASS




Band41-20MHz-16QAM-41490-1RB#0-30~1000-PASS




Band41-20MHz-16QAM-41490-1RB#0-1000~3000-PASS




Band41-20MHz-16QAM-41490-1RB#0-3000~18000-PASS



Band41-20MHz-16QAM-41490-1RB#0-18000~27000-PASS





Appendix F: Frequency Stability VS Voltage measurement

Test Result

Voltage										
Band	Bandwidth	Modulation	Channel	RB Configure	Voltage [Vdc]	Temperature (°C)	FL (MHz)	FH (MHz)	Limit (MHz)	Verdict
Band41	5MHz	QPSK	39675	25RB#0	VN	NT	2496.25886	2500.73266	2496-2690	PASS
Band41	5MHz	QPSK	39675	25RB#0	VL	NT	2496.27186	2500.72826	2496-2690	PASS
Band41	5MHz	QPSK	39675	25RB#0	VH	NT	2496.2669	2500.7284	2496-2690	PASS
Band41	5MHz	16QAM	39675	25RB#0	VN	NT	2496.26595	2500.72985	2496-2690	PASS
Band41	5MHz	16QAM	39675	25RB#0	VL	NT	2496.27205	2500.72735	2496-2690	PASS
Band41	5MHz	16QAM	39675	25RB#0	VH	NT	2496.27043	2500.72743	2496-2690	PASS
Band41	5MHz	QPSK	40620	25RB#0	VN	NT	2590.76287	2595.22817	2496-2690	PASS
Band41	5MHz	QPSK	40620	25RB#0	VL	NT	2590.76379	2595.23159	2496-2690	PASS
Band41	5MHz	QPSK	40620	25RB#0	VH	NT	2590.76079	2595.23639	2496-2690	PASS
Band41	5MHz	16QAM	40620	25RB#0	VN	NT	2590.76466	2595.22456	2496-2690	PASS
Band41	5MHz	16QAM	40620	25RB#0	VL	NT	2590.76182	2595.22372	2496-2690	PASS
Band41	5MHz	16QAM	40620	25RB#0	VH	NT	2590.7622	2595.2271	2496-2690	PASS
Band41	5MHz	QPSK	41565	25RB#0	VN	NT	2685.27099	2689.72929	2496-2690	PASS
Band41	5MHz	QPSK	41565	25RB#0	VL	NT	2685.27262	2689.73042	2496-2690	PASS
Band41	5MHz	QPSK	41565	25RB#0	VH	NT	2685.26538	2689.72668	2496-2690	PASS
Band41	5MHz	16QAM	41565	25RB#0	VN	NT	2685.26792	2689.72672	2496-2690	PASS
Band41	5MHz	16QAM	41565	25RB#0	VL	NT	2685.26933	2689.72493	2496-2690	PASS
Band41	5MHz	16QAM	41565	25RB#0	VH	NT	2685.26	2689.72	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

							404	674	90	
Band41	10MHz	QPSK	39700	50RB#0	VN	NT	2496.54 871	2505.45 451	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	VL	NT	2496.54 822	2505.45 402	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	VH	NT	2496.54 859	2505.45 439	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	VN	NT	2496.55 293	2505.45 593	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	VL	NT	2496.55 282	2505.45 702	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	VH	NT	2496.55 36	2505.45 61	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	VN	NT	2588.52 034	2597.44 564	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	VL	NT	2588.52 033	2597.44 583	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	VH	NT	2588.52 006	2597.44 526	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	VN	NT	2588.54 2	2597.44 3	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	VL	NT	2588.54 32	2597.44 31	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	VH	NT	2588.54 279	2597.44 269	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	VN	NT	2680.54 947	2689.45 737	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	VL	NT	2680.54 949	2689.45 769	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	VH	NT	2680.54 974	2689.45 694	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	VN	NT	2680.55 239	2689.45 759	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	VL	NT	2680.55 416	2689.45 866	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	VH	NT	2680.55 282	2689.45 792	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	VN	NT	2496.82 408	2510.18 608	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	VL	NT	2496.82 878	2510.17 578	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	VH	NT	2496.81	2510.18	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							583	183	90	
Band41	15MHz	16QAM	39725	75RB#0	VN	NT	2496.80 934	2510.17 634	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	VL	NT	2496.77 653	2510.19 553	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	VH	NT	2496.80 256	2510.18 556	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	VN	NT	2586.32 55	2599.68 65	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	VL	NT	2586.30 632	2599.68 932	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	VH	NT	2586.31 048	2599.66 648	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	VN	NT	2586.29 704	2599.69 704	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	VL	NT	2586.31 794	2599.69 394	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	VH	NT	2586.30 502	2599.69 302	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	VN	NT	2675.81 129	2689.20 229	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	VL	NT	2675.82 399	2689.19 999	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	VH	NT	2675.80 219	2689.18 419	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	VN	NT	2675.80 961	2689.18 561	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	VL	NT	2675.79 412	2689.19 612	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	VH	NT	2675.80 403	2689.19 603	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	VN	NT	2497.10 812	2514.89 112	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	VL	NT	2497.10 838	2514.89 238	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	VH	NT	2497.10 898	2514.89 198	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	VN	NT	2497.12 597	2514.87 797	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	VL	NT	2497.12 563	2514.87 863	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB#	VH	NT	2497.12	2514.87	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel: (86) 0755-26066440 Email: service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

				0			576	976	90	
Band41	20MHz	QPSK	40620	100RB# 0	VN	NT	2584.09 867	2601.88 967	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	VL	NT	2584.09 872	2601.88 972	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	VH	NT	2584.09 832	2601.88 932	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	VN	NT	2584.08 155	2601.91 255	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	VL	NT	2584.08 211	2601.91 311	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	VH	NT	2584.08 18	2601.91 28	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	VN	NT	2671.10 164	2688.90 464	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	VL	NT	2671.10 171	2688.90 971	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	VH	NT	2671.10 154	2688.90 854	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	VN	NT	2671.08 963	2688.92 963	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	VL	NT	2671.09 077	2688.92 977	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	VH	NT	2671.09 059	2688.92 959	2496-26 90	PASS

Appendix G: Frequency Stability VS Temperature measurement

Test Result

Temperature										
Band	Bandwidth	Modulation	Channel	RB Configuration	Voltage [Vdc]	Temperature (°C)	FL (MHz)	FH (MHz)	Limit (MHz)	Verdict
Band41	5MHz	QPSK	39675	25RB#0	NV	-30	2496.26 69	2500.72 63	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	-20	2496.25 991	2500.73 131	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	-10	2496.26 542	2500.73 092	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	0	2496.27	2500.72	2496-26	PASS

							121	741	90	
Band41	5MHz	QPSK	39675	25RB#0	NV	10	2496.27 245	2500.73 065	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	20	2496.26 4	2500.72 83	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	30	2496.27 077	2500.73 027	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	40	2496.26 223	2500.72 943	2496-26 90	PASS
Band41	5MHz	QPSK	39675	25RB#0	NV	50	2496.26 546	2500.73 126	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	-30	2496.25 901	2500.72 541	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	-20	2496.26 291	2500.72 961	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	-10	2496.25 858	2500.72 778	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	0	2496.26 809	2500.72 379	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	10	2496.26 369	2500.72 729	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	20	2496.26 851	2500.72 591	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	30	2496.26 425	2500.72 375	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	40	2496.26 33	2500.72 78	2496-26 90	PASS
Band41	5MHz	16QAM	39675	25RB#0	NV	50	2496.26 427	2500.72 407	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	-30	2590.76 599	2595.22 329	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	-20	2590.75 978	2595.22 618	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	-10	2590.75 929	2595.22 589	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	0	2590.76 397	2595.22 597	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	10	2590.76 946	2595.23 016	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	20	2590.76 472	2595.22 832	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	30	2590.76	2595.22	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							592	972	90	
Band41	5MHz	QPSK	40620	25RB#0	NV	40	2590.76 3	2595.22 73	2496-26 90	PASS
Band41	5MHz	QPSK	40620	25RB#0	NV	50	2590.76 804	2595.22 914	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	-30	2590.76 484	2595.22 424	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	-20	2590.76 085	2595.22 495	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	-10	2590.76 185	2595.22 075	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	0	2590.75 99	2595.22 49	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	10	2590.76 082	2595.22 822	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	20	2590.77 271	2595.22 241	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	30	2590.75 959	2595.22 639	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	40	2590.76 483	2595.22 543	2496-26 90	PASS
Band41	5MHz	16QAM	40620	25RB#0	NV	50	2590.76 114	2595.22 344	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	-30	2685.26 69	2689.73 1	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	-20	2685.26 511	2689.72 831	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	-10	2685.26 785	2689.72 595	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	0	2685.26 015	2689.72 615	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	10	2685.26 904	2689.72 414	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	20	2685.26 378	2689.72 728	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	30	2685.26 571	2689.72 581	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	40	2685.26 466	2689.72 936	2496-26 90	PASS
Band41	5MHz	QPSK	41565	25RB#0	NV	50	2685.27 093	2689.72 503	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	-30	2685.26	2689.72	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							627	767	90	
Band41	5MHz	16QAM	41565	25RB#0	NV	-20	2685.26 284	2689.72 364	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	-10	2685.26 601	2689.72 351	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	0	2685.26 472	2689.72 752	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	10	2685.26 953	2689.72 753	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	20	2685.27 031	2689.72 341	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	30	2685.26 391	2689.72 751	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	40	2685.26 287	2689.72 427	2496-26 90	PASS
Band41	5MHz	16QAM	41565	25RB#0	NV	50	2685.26 436	2689.72 686	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	-30	2496.54 831	2505.45 461	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	-20	2496.54 89	2505.45 45	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	-10	2496.54 867	2505.45 477	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	0	2496.54 858	2505.45 428	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	10	2496.54 846	2505.45 436	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	20	2496.54 877	2505.45 447	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	30	2496.54 871	2505.45 451	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	40	2496.54 911	2505.45 461	2496-26 90	PASS
Band41	10MHz	QPSK	39700	50RB#0	NV	50	2496.54 886	2505.45 446	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	-30	2496.55 287	2505.45 687	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	-20	2496.55 3	2505.45 61	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	-10	2496.55 353	2505.45 573	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	0	2496.55	2505.45	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							337	597	90	
Band41	10MHz	16QAM	39700	50RB#0	NV	10	2496.55 335	2505.45 615	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	20	2496.55 272	2505.45 652	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	30	2496.55 327	2505.45 627	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	40	2496.55 297	2505.45 707	2496-26 90	PASS
Band41	10MHz	16QAM	39700	50RB#0	NV	50	2496.55 361	2505.45 631	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	-30	2588.52 002	2597.44 582	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	-20	2588.52	2597.44 56	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	-10	2588.51 962	2597.44 542	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	0	2588.51 99	2597.44 54	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	10	2588.52 001	2597.44 581	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	20	2588.52 002	2597.44 562	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	30	2588.51 964	2597.44 574	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	40	2588.52 031	2597.44 571	2496-26 90	PASS
Band41	10MHz	QPSK	40620	50RB#0	NV	50	2588.52 008	2597.44 548	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	-30	2588.54 327	2597.44 257	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	-20	2588.54 442	2597.44 242	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	-10	2588.54 363	2597.44 313	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	0	2588.54 455	2597.44 285	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	10	2588.54 315	2597.44 305	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	20	2588.54 385	2597.44 285	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	30	2588.54	2597.44	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel: (86) 0755-26066440 Email: service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							203	283	90	
Band41	10MHz	16QAM	40620	50RB#0	NV	40	2588.54 361	2597.44 301	2496-26 90	PASS
Band41	10MHz	16QAM	40620	50RB#0	NV	50	2588.54 392	2597.44 242	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	-30	2680.54 999	2689.45 739	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	-20	2680.54 979	2689.45 819	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	-10	2680.55 011	2689.45 771	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	0	2680.55 025	2689.45 765	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	10	2680.55 058	2689.45 778	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	20	2680.54 994	2689.45 794	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	30	2680.55 016	2689.45 786	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	40	2680.54 976	2689.45 796	2496-26 90	PASS
Band41	10MHz	QPSK	41540	50RB#0	NV	50	2680.55 031	2689.45 801	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	-30	2680.55 282	2689.45 842	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	-20	2680.55 294	2689.45 834	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	-10	2680.55 313	2689.45 733	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	0	2680.55 318	2689.45 788	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	10	2680.55 314	2689.45 724	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	20	2680.55 308	2689.45 848	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	30	2680.55 316	2689.45 886	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	40	2680.55 288	2689.45 878	2496-26 90	PASS
Band41	10MHz	16QAM	41540	50RB#0	NV	50	2680.55 289	2689.45 809	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	-30	2496.81	2510.18	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							16	76	90	
Band41	15MHz	QPSK	39725	75RB#0	NV	-20	2496.81 99	2510.18 49	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	-10	2496.81 377	2510.19 577	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	0	2496.82 906	2510.17 706	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	10	2496.82 322	2510.19 122	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	20	2496.80 875	2510.17 175	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	30	2496.81 806	2510.17 506	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	40	2496.82 787	2510.17 587	2496-26 90	PASS
Band41	15MHz	QPSK	39725	75RB#0	NV	50	2496.82 71	2510.18 21	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	-30	2496.81 661	2510.18 661	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	-20	2496.79 511	2510.18 311	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	-10	2496.79 804	2510.18 504	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	0	2496.79 295	2510.18 995	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	10	2496.80 906	2510.18 006	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	20	2496.80 737	2510.17 837	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	30	2496.82 385	2510.17 485	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	40	2496.80 062	2510.17 462	2496-26 90	PASS
Band41	15MHz	16QAM	39725	75RB#0	NV	50	2496.80 543	2510.18 743	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	-30	2586.30 486	2599.67 186	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	-20	2586.29 776	2599.66 976	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	-10	2586.31 185	2599.67 485	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	0	2586.31	2599.68	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							71	21	90	
Band41	15MHz	QPSK	40620	75RB#0	NV	10	2586.31 831	2599.68 831	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	20	2586.31 934	2599.68 734	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	30	2586.31 556	2599.67 556	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	40	2586.31 734	2599.68 534	2496-26 90	PASS
Band41	15MHz	QPSK	40620	75RB#0	NV	50	2586.29 088	2599.69 088	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	-30	2586.30 868	2599.70 568	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	-20	2586.30 339	2599.69 739	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	-10	2586.31 371	2599.68 871	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	0	2586.30 687	2599.69 487	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	10	2586.30 318	2599.68 818	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	20	2586.33 538	2599.66 438	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	30	2586.29 264	2599.70 064	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	40	2586.32 059	2599.68 959	2496-26 90	PASS
Band41	15MHz	16QAM	40620	75RB#0	NV	50	2586.28 785	2599.68 885	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	-30	2675.80 01	2689.19 41	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	-20	2675.82 04	2689.21 74	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	-10	2675.81 46	2689.20 36	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	0	2675.80 483	2689.20 883	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	10	2675.82 461	2689.19 161	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	20	2675.81 83	2689.19 73	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	30	2675.82	2689.20	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

							065	565	90	
Band41	15MHz	QPSK	41515	75RB#0	NV	40	2675.80 762	2689.21 962	2496-26 90	PASS
Band41	15MHz	QPSK	41515	75RB#0	NV	50	2675.82 639	2689.19 839	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	-30	2675.80 767	2689.18 967	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	-20	2675.80 519	2689.19 219	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	-10	2675.79 994	2689.18 894	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	0	2675.80 825	2689.20 025	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	10	2675.82 898	2689.18 898	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	20	2675.80 533	2689.19 133	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	30	2675.79 808	2689.18 808	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	40	2675.80 26	2689.18 56	2496-26 90	PASS
Band41	15MHz	16QAM	41515	75RB#0	NV	50	2675.79 397	2689.18 797	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	-30	2497.10 908	2514.89 208	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	-20	2497.10 854	2514.89 254	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	-10	2497.10 885	2514.89 285	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	0	2497.10 871	2514.89 271	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	10	2497.10 929	2514.89 229	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	20	2497.10 936	2514.89 236	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	30	2497.10 948	2514.89 248	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	40	2497.10 909	2514.89 209	2496-26 90	PASS
Band41	20MHz	QPSK	39750	100RB# 0	NV	50	2497.10 952	2514.89 252	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB#	NV	-30	2497.12	2514.87	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

				0			544	944	90	
Band41	20MHz	16QAM	39750	100RB# 0	NV	-20	2497.12 57	2514.87 87	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	-10	2497.12 547	2514.87 947	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	0	2497.12 568	2514.87 968	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	10	2497.12 59	2514.87 99	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	20	2497.12 639	2514.87 939	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	30	2497.12 644	2514.87 944	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	40	2497.12 639	2514.87 939	2496-26 90	PASS
Band41	20MHz	16QAM	39750	100RB# 0	NV	50	2497.12 547	2514.87 947	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	-30	2584.09 755	2601.89 055	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	-20	2584.09 724	2601.89 024	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	-10	2584.09 833	2601.88 933	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	0	2584.09 798	2601.88 998	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	10	2584.09 769	2601.88 969	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	20	2584.09 852	2601.88 952	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	30	2584.09 797	2601.88 997	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	40	2584.09 852	2601.88 952	2496-26 90	PASS
Band41	20MHz	QPSK	40620	100RB# 0	NV	50	2584.09 804	2601.89 004	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	-30	2584.08 117	2601.91 317	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	-20	2584.08 27	2601.91 27	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	-10	2584.08 147	2601.91 347	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB#	NV	0	2584.08	2601.91	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

				0			197	197	90	
Band41	20MHz	16QAM	40620	100RB# 0	NV	10	2584.08 119	2601.91 419	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	20	2584.08 174	2601.91 274	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	30	2584.08 183	2601.91 283	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	40	2584.08 163	2601.91 263	2496-26 90	PASS
Band41	20MHz	16QAM	40620	100RB# 0	NV	50	2584.08 176	2601.91 176	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	-30	2671.10 08	2688.90 88	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	-20	2671.09 938	2688.90 938	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	-10	2671.10 095	2688.90 895	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	0	2671.10 05	2688.90 95	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	10	2671.10 153	2688.91 053	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	20	2671.10 147	2688.90 947	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	30	2671.10 189	2688.90 989	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	40	2671.10 124	2688.91 024	2496-26 90	PASS
Band41	20MHz	QPSK	41490	100RB# 0	NV	50	2671.10 12	2688.90 92	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	-30	2671.09 048	2688.92 948	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	-20	2671.09 065	2688.92 965	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	-10	2671.08 982	2688.92 982	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	0	2671.09 041	2688.92 941	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	10	2671.09 056	2688.92 956	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	20	2671.09 053	2688.92 953	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB#	NV	30	2671.09	2688.92	2496-26	PASS

Shenzhen Anbotech Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotech.com

 Hotline
400-003-0500
www.anbotech.com

				0			076	976	90	
Band41	20MHz	16QAM	41490	100RB# 0	NV	40	2671.09 079	2688.92 979	2496-26 90	PASS
Band41	20MHz	16QAM	41490	100RB# 0	NV	50	2671.09 051	2688.92 951	2496-26 90	PASS

---END---

Shenzhen Anbotek Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotek.com



Hotline
400-003-0500
www.anbotek.com