



User Manual

Before use this product, please read this instruction
carefully and keep it for future use

Contents

Important Safety Notes-----	1
Ports and Buttons Introduction-----	4
Ports Function-----	5
Installation and Ajustment-----	6
Remote Control-----	8
Homepage Introduction-----	9
Input Signal Source-----	9
Install Software And Uninstall-----	10
Software download and installation method-----	10
Keystone correction-----	11
Mirroring -----	12

Important Safety Note

For the best viewing effect, it is recommended that you use the machine in a dark room.

- Do not install in a place where the air-conditioning is directly blown by the cold air, otherwise it may be condensed by water vapor.
- Make sure that there is sufficient ventilation and the ventilation is not blocked to prevent heat from accumulating in the machine.
- Prevent external objects such as nails or paper scraps from falling into the machine and do not insert any metal external objects such as iron wires or screwdrivers into the cooling holes.
If external objects fall into the machine accidentally, please turn off the power immediately and let professional maintenance personnel take it out.
- Do not place any liquid on the machine to avoid internal short circuit and fire.
- When carrying the machine, please use soft packaging materials. If the lens is stained with oil or fingerprints, please wipe it with cotton cloth and 75% medical alcohol.
At the same time, avoid the machine being subjected to violent impact or severe vibration.
- After the machine is used, the vent accessory will be hot, if you touch it with your hands at this time, it may cause burns.
- There is strong light output during the working of this machine, please do not peep into the lens to avoid burning your eyes.

- There is a risk of explosion if use wrong type of batteries for the remote control and be sure to dispose of the used dry battery according to the instructions.

 **Notice**

To prevent electric shock, do not open the case. Please entrust qualified professional maintenance technician to carry out maintenance matters.

 **Notice**

To prevent fire or electric shock, do not expose this projector in a humid environment.

Caution:


In a domestic environment, this product may cause radio interference. In this case, the user may be required to take practical measures for the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.


Precautions for Safe Use



Do not install in places with poor ventilation



Do not install in hot and humid places




Do not block air intake vent or air outlet vent !




Do not install in dusty and smoky places


Ports and Buttons Introduction




Remarks: The function of the buttons may be different due to the software of this projector or different regions and please refer to the actual product



Caution: The air outlet is the cooling outlet of the machine and its temperature is higher, but it does not affect the use of the machine




Ports Function



When using HD port or AV port, you need to switch to the corresponding signal source operation mode in the program.

Remove Dust




After the machine is used for a period of time, it is necessary to remove the dust-proof plate and remove the dust on it in time. Please use a soft brush to remove the dust gently. Do not wash with water ! !



Installation and Adjustment

1. Projector installation

place the device horizontally




2. Adjust focus



Focus: When the image is blurry (as shown in the above picture), adjust the focus ring of the projector until it becomes the best clarity.

(Tips: Some models have different focusing methods.)

3. Adjust focus after changing projection distance




Note: The projection size and projection distance are calculated according to the projection ratio. During actual debugging, there may be deviations and please refer to the actual product.


4. Installation mode

This projector supports 4 installation methods:


Desktop Front Projection, Desktop Rear Projection,
Ceiling Front Projection, Ceiling Rear Projection Path:




Desktop Front Projection



Ceiling Front Projection




Desktop Rear Projection



Ceiling Rear Projection

Remote control


- 1.Power button
- 2.Signal source
- 3.Music key
- 4.Direction key + ok
- 5.Homepage
- 6.Volume
- 7.Mute
- 8.Settings
- 9.Return
10. Menu



Caution

- Do not submerge the remote control in water.
- Do not place the remote control in a humid or hot environment.
- Do not use old and new batteries together in the remote control.
- Please take the batteries out if not using the remote control for a long time to avoid battery leakage.
- When using remote control, must let the remote control point to the projector's IR remote sensor to work correctly.

Homepage Introduction



Interface varies by version or region


Input Source

When you want to use the input source, please select the corresponding signal channel.

AV / HD1 / HD2 / USB



Press Up Key



please select the corresponding signal source channel.

Install Software And Uninstall APPS/apk


1. Install Software

Method 1: Select APPS in the Navigation Bar

Select favorite application category


Method 2: Select SEARCH in the Navigation Bar

Search for the App Name you need



2. Uninstall Software

On the APPS interface, in My Apps, press the MENU button and select Delete





Keystone correction

More than horizontal and vertical keystone correction, this projector supports four-point trapezoidal adjustment.


When the machine cannot be perpendicular to the screen, and the projection effect cannot become a regular rectangle, you can use "four-point keystone correction" or "horizontal and vertical keystone correction". to make the screen be rectangle.

1. Four-point keystone correction



- “OK” Switch the corner that needs to be adjusted
- “” Adjust the parameters of the selected corner
- “” Save and exit
- “” Reset

2. Vertical keystone correction




Screen Mirroring

1. Android Device

(Miracast-Display the content of mobile phone screen ,)

- Click on the Android device to enter the Miracast connection interface
- Find same screen or cast screen buttons on the Android phone (the miracast name of each phone is different)
- Search for the projector device name
- Click to connect

Note: When use for the first time, the connection time is long and please be patient



2. IOS Device

- Swipe up from the bottom edge of iPhone / iPad screen.
- The Control center appears and click Screen Mirroring icon.
- Select the projector's name for mirroring





:

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.