

材 质：80g书写纸 黑白单色 单面印刷 风琴折
成品尺寸：95 * 95 mm


USER
MANUAL

MAGNETIC WIRELESS POWER

WHAT'S INCLUDED

- Magnetic Wireless Power Bank
- USB Charging Cable
- User Manual

LOCATION OF CONTROLS




CHARGING A MOBILE DEVICE

CHARGING WITH A CABLE

To charge your mobile device using the power bank connect your mobile device's Charge/Sync cable to your mobile device, then connect the USB end (Standard size) of the cable to the power bank. For best results use the charge/sync cable that was included with your mobile device when purchased.

WIRELESS CHARGING


Press the On button for the power bank and quickly place your mobile device on the power bank. If your mobile device supports MagSafe, align the magnet on the back of your device with the magnet on the power bank. Your mobile device should indicate charging in the first few seconds, if not make sure the charging coil of your mobile device is aligned with the charging coil of the power bank.



CHARGING THE POWER BANK

To charge the power bank, connect it via the included Type-C USB to USB cable. Connect the Type-C USB end of the cable to the power bank and the USB end (standard size) to your Computer, AC charger or car charger. Charging time varies between 4-7 hours (when totally depleted).

When the power bank is fully charged, all four battery indicator lights will emit steadily.



95 mm

95 mm

95 mm

285 mm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction