

H601C 英文说明书

版本:1.0

料号:

成型尺寸:75x105mm

材质:80G书页纸

工艺:单色印刷

折叠方式:风琴页

页数:14页

## At a Glance

### Safety Instructions

Read and follow all the safety instructions:

- The downlight is not waterproof. Avoid exposing it to splashes or water drops.
- The operating temperature should be within -10° to 40°C (14° to 104°F).
- The downlight internal light source is unfixable. If it breaks, the entire downlight must be replaced.
- Do not allow children to install the downlight.
- External dimmers cannot be used with this product.
- Installation and maintenance should be operated by a professional.
- Avoid installing the downlight near heat sources or in damp locations.
- Avoid installing the downlight near potentially dangerous sources (e.g., candles, liquid-filled objects).

01

02


For FAQs and more information, please visit: [www.govee.com](http://www.govee.com)



### Specifications


Working Voltage	AC 120V
Power	13W
Lumen	1000lm
Color Temperature	2700K-6500K
Color	RGBWW

## Installing Your Device




### Installation Steps:

- Disconnect the main power switch of the device before installation.
- Screw the E26 adapter into the E26 base.



- Plug the orange connector into the downlight.
- Push the downlight into the metal housing.



- After completing the above steps, power on and enjoy the light.

Note: If there is an orange connector inside the metal housing, plug it into the downlight and push the downlight into the housing to complete installation.

03

04

05

06

## Pairing Your Downlight with Govee Home App

### What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).

01

02

03

04

05

06

07

08

09

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

## Troubleshooting

- ① Cannot connect the downlight to Govee Home.
  - Check whether the downlight is powered on.
  - Check whether your smartphone Wi-Fi is enabled. Please make sure Wi-Fi connected to your phone is 2.4GHz (5GHz brand is not supported).
  - Make sure your smartphone is close to the device when connecting for the first time.
  - Check if you have entered the correct Wi-Fi password during Wi-Fi setup.
  - Make sure the distance between the bulb and router is less than 50ft.
  - Check whether the home network is stable by connecting downlight to another phone's hotspot.
- ② The downlight lost connection.
  - Check whether the device is powered on.
  - Check whether your home network is stable.
  - Check if there are too many devices connected to the router by connecting downlight to another phone's hotspot.
  - Ensure the distance between the smartphone and the device does not exceed 50ft.

- Delete downlight connected in "My Devices" and reconnect the downlight to Wi-Fi following on-screen instructions.

- ③ Can I group multiple Govee devices together?

- Yes, you can group multiple downlights and other govee devices by Schemes, Same model, General (Wi-Fi or Bluetooth devices). It depends on the function of different devices.

- ④ Can I use group control with voice assistance?

- Please make sure your device is connected to Wi-Fi before using voice assistance.
- Please set voice group control in Alexa/Google Assistant App.

- ⑤ What is the maximum number of devices I can connect via Bluetooth?

- Typically, up to 6 devices can be connected. Devices may vary based on your smartphone brand.

- ⑥ How many downlights can be connected to one phone?

- Up to 50 downlights can be connected to one phone if the network is normal.

## Customer Service

● Warranty: 12-Month Limited Warranty

● Support: Lifetime Technical Support

● Email: support@govee.com

● Official Website: www.govee.com

● @Govee

● @govee\_official

● @govee.official

● @Goveeofficial

● @Govee.smarthome

## FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-005. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

Responsible party (this contact information is only for FCC matters):

Name: GOVEE MOMENTS(US) TRADING LIMITED

Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: certification@govee.com

Contact information: <https://www.govee.com/support>

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.

2. Increase the separation between the equipment and receiver.

3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

4. Consult the dealer or an experienced radio/TV technician for help.

SUITABLE FOR AMPLIFIED LOCATIONS  
CONVENIENT AU EXEMPLAIRES EN HAUT DE JUMEAUX

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXIT  
NE CONVENT PAS AU SORTIE DE SECOURS

SUITABLE FOR TYPE IC OR TYPE NON-IC  
CONVENIENT AU TYPE IC OU TYPE NON-IC

USE ONLY RECESSED UMBRELLA WITH LAMP COMPARTMENT  
DIMENSIONS 5.5 Inch/3.9 MM DIAMETER, 7.5 Inch/190.5 MM  
DEPTH

UTILISER UNIQUEMENT APPAREIL À ENCASTRER AVEC LAMPE  
DIMENSIONS DU COMPARTIMENT 5.5 Inch/3.9 MM  
DIAMÈTRE, 7.5 Inch/190.5 MM PROFONDEUR

SUITABLE FOR OPERATING IN AMBIENT TEMPERATURE  
40°C

PEUT ÊTRE UTILISÉ À UNE TEMPERATURE AMBIANTE

EXÉCUTANT À 40°C

This luminaire has been modified to operate LED lamps. Do not attempt to install or operate the originally intended lamps in this luminaire.

Ce luminaire a été modifié pour fonctionner des lampes LED. Ne essayez pas d'installer ou d'utiliser les lampes prévues à l'origine dans ce luminaire.

Model: H601C  
Wi-Fi+Bluetooth RGBWW Downlight

Govee

## User Manual