

H607C英语说明书

版本:1.0

料号:

折叠尺寸:105×145 (mm)

材质:80G书页纸

工艺:单色印刷

折叠方式:风琴页

页数:10页

Safety Instructions

Read and follow the safety instructions below:

- Use the product with the provided power adapter only.
- The product is not waterproof. Do not expose it to areas susceptible to water splashes or water drops.
- The internal light sources cannot be replaced. If it breaks, the product should be replaced. Do not allow children to install the floor lamp alone. Do not disassemble or modify the device and its accessories.
- Avoid installing the device near potentially dangerous sources or heat sources (e.g.candles, liquid-filled objects.)
- The working temperature should be between 14 to 104°F (-10 to 40°C).
- Store the product in places where the temperature is within -4 to 140°F (-20 to 60°C) if you do not plan to use it for a long time.
- Do not install the product with a dimming driver.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.



Introduction

Thanks for choosing the Govee Floor Lamp 2. Its modernized appearance makes it a perfect fit for your living room, bedroom, office, and other spaces. The expanded illumination area and the delicate lamp base will bring you a more surprising lighting experience.


What You Get

Item	Quantity
Floor Lamp (Lamp Base*1, Lamp Slot*3, Connecting Parts*3, Silicone Strip Light*1)	1
Accessory Kit (Short Screw*12+Extra Screw*4, Screwdriver*1)	1
Power Adapter	1
Remote Controller	1
Remote Controller Holder	1
Quick Start Guide	1
User Manual	1
Service Card	1

At a Glance



Buttons	Instructions
On/Off Button	Press to power the lamp on/off.
Brightness+	Press to increase the brightness of the lamp.
Brightness-	Press to decrease the brightness of the lamp.
Color Button	Press to change colors. Tips: Enter the Device Settings page in Govee Home App. Tap "Preset Features" to manage the colors.
Warm Button	Press to make colors warmer.
Cool Button	Press to make colors cooler.
Music Button	Press to switch between different music modes.



Pairing Your Device with Govee Home App

What You Need:

- A Wi-Fi router supporting the 2.4GHz and 802.11b/g/n bands. 5GHz is not supported.
- ❶ Download Govee Home App from the App Store (iOS) or Google Play (Android). Log in with your account. New users need to create an account.
- ❷ Turn on the Bluetooth on your smartphone.

- ❸ Open the app, tap the "+" icon in the top right corner and search for "H607C."
- ❹ Tap the device icon and follow the on-screen instructions to complete pairing.



Controlling the Light with Your Voice

- ❶ Open the app, then tap the device icon to enter the details page.
- ❷ Tap the settings icon in the top right corner.
- ❸ Select User Guide and follow the on-screen instructions to control the device using your voice.

Specifications

Model	H607C
Adapter Input	AC 100-240V 50/60Hz
Lamp Input	24VDC 2A
Lumens	1725lm(6500k)
Light Displaying Technology	RGBICWW
Control Methods	Remote Controller, Govee Home App, Voice
Working Temperature	-10°C to -40°C /14°F to -104°F



Govee Home App

For FAQs and more information,
please visit: www.govee.com

Troubleshooting

- ❶

Cannot connect to Govee Home App.

a. Check if the light has been powered on.

b. Check if your smartphone's Bluetooth has been turned on or try connecting the light to another smartphone.

c. Ensure that your smartphone is near the light when connecting for the first time.

d. If the problem persists, go to the "Device" page to delete the device and follow the previous instructions to reconnect.
- ❷

Cannot connect to Wi-Fi.

a. Check if the light has been powered on.

b. Do not skip connecting to Wi-Fi during the pairing process.

c. Ensure that your Wi-Fi router is 2.4GHz capable (5GHz is not supported).

d. Ensure that you entered the correct Wi-Fi password during the Wi-Fi connection process.

e. Shorten the distance between the device and the Wi-Fi router to less than 50ft, then try reconnecting.

f. Use another smartphone to pair with the device to check if your Wi-Fi network is working.
- ❸

Cannot pair or connect with Alexa or Google Assistant.

a. Ensure that the Wi-Fi connection is stable.

b. Go to the app's Settings page and follow the instructions under "User Guide" to pair the device again.
- ❹

The light does not display the selected color fully or some LED beads do not light up.

Please contact the Govee support team for a rapid product replacement.

Customer Service

-  Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @govee_official  @govee.official

 @Goveeofficial  @Govee.smarthome

FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil nedit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélec trique subi, même si le brouillage est susceptible d'en comprom ettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.

2. Increase the separation between the equipment and receiver.

3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

4. Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-005.
Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

FCC and IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

Responsible party (this contact information is only for FCC matters) :
Name: GOVEE MOMENTS(US) TRADING LIMITED
Address: 2501 Chatham Rd Suite R Springfield IL 62704
Email: certification@govee.com
Contact information: https://www.govee.com/support

The trademark Govee have been authorised to Shenzhen Qianyan Technology LTD.
Copyright ©2021 Shenzhen Qianyan Technology LTD.
All Rights Reserved.

Warning: contains coin battery

1. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

2. Even used batteries may cause severe injury or death.

3. Compatible battery types: CR2025

4. Nominal battery voltage: 3V

5. Call a local poison control center for treatment information.

6. Non-rechargeable batteries are not to be recharged.

7. Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

8. Ensure the batteries are installed correctly according to polarity (+ and -).

9. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

10. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

11. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

User Manual

Model: H607C
Govee Floor Lamp 2

05

06