

4. Not satisfied with the brightness sensor.

Auto on too early	Decrease the original value of ambient brightness
Auto on too late	Increase the original value of ambient brightness
Original brightness too low/high	Decrease/Increase the first device brightness
Ultimate brightness too low/high	Decrease/Increase the second device brightness

5. For other issues.

a. Please contact the Govee support team.

Customer Service

⌚ Warranty: 12-Month Limited Warranty

🔧 Support: Lifetime Technical Support

✉ Email: support@govee.com

🌐 Official Website: www.govee.com

📺 @GOVEE

📷 @goveeofficial

🎵 @govee.official

𝕏 @GoveeOfficial

ƒ @GOVEE

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- (4) Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Responsible party (this contact information is only for FCC matters):

Name: GOVEE MOMENTS(US) TRADING LIMITED
Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: certification@govee.com

Contact information: <https://www.govee.com/support>

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Qianyan Technology LTD is under license.

The trademark Govee have been authorised to Shenzhen Qianyan Technology LTD.

Copyright ©2021 Shenzhen Qianyan Technology LTD.

All Rights Reserved.

Govee

User Manual

Model: H702

Govee Outdoor Lamp Post Lights

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:


- This light is rated as IP66. It can be used outdoors but cannot be immersed in water.
- Tighten up the waterproof cap before using the light.
- Do not allow children to assemble and install this product.
- Avoid installing this product near major heat sources or other dangerous sources.
- Avoid using other non-standard adapters for this product.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.
- To reduce the risk of strangulation, the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Risk of Electric Shock. The adapter install only to a covered Class A GFCI receptacle that has an enclosure that is weatherproof with the attachment plug cap inserted or removed.
- Any open ends must be sealed-off before use.
- This product includes a built-in mic that can recognize sound information to synchronize lights and music.
- This product includes three motion sensors that can recognize movement to change light effect.
- This product includes three brightness sensors that can recognize environment illumination to change the brightness of light.
- FOR USE WITH LANDSCAPE LIGHTING SYSTEMS ONLY.
- LANDSCAPE LIGHTING SYSTEMS ARE FOR OUTDOOR USE ONLY.
- POWER SUPPLIES ARE FOR OUTDOOR USE ONLY.

SAVE THESE INSTRUCTIONS

What You Get

Item	Quantity
Lamp Head	1
Power Adapter	1
Lamp Post	3
Power Cord	3
Cross Bracket	1
U-Shaped Floor Nail	4
Expansion Bolt	4
Water Bag	1
Outer Hexagon Screw	4
Inner Hexagon Screw	6
Wrench	1
Hex Key	1

At a Glance



Pairing Your Light with Govee Home App

What You Need

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 and above or Android 4.3 and above.



1. Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
2. Turn on your smartphone's Bluetooth.
3. Open the app, tap the "+" icon in the top right corner and search for "H7072."
4. Tap the device icon and follow the on-screen instructions to complete pairing.

Controlling the Light with Your Voice

1. Open the app, then tap the device icon to enter the details page.
2. Tap the settings icon in the top right corner.
3. Select User Guide and follow the on-screen instructions to control the device using your voice.

1. Open the app, then tap the device icon to enter the details page.
2. What if the motion sensor can't detect movements or the unintended activation is too frequent?
 - a. Adjust the sensor distance of the motion sensor on the "Device Settings" page of Govee Home App.
3. What should I do if I want to restore the original light effect or turn it off after motion sensing is triggered?
 - a. Add a "Delayed Execution" command after the action, and change the effect to other lighting effects or off.

Specifications

Power Input (Adapter)	100-240VAC 50/60Hz
Power Input (Light)	24VDC 1.5A
Height	97.6"
Waterproof	Light: IP66
Light Color	RGBICWW

Troubleshooting

1. Cannot connect to Wi-Fi.
 - a. Do not skip the Wi-Fi connection steps in the app.
 - b. Make sure your home Wi-Fi is 2.4Ghz and your smartphone's Bluetooth is on.
- c. Long press the control box for more than 5s to reset the whole light. Unbind and then rebind the light.
- d. Connect your smartphone to Wi-Fi and check whether the network works well.
- e. Make sure you have entered the correct Wi-Fi name and password.
- f. If the light is too far away from the Wi-Fi, bring the control box closer to the Wi-Fi, and then reconnect to the network.
- g. Check if there are too many devices connected to the network. If so, change to another network.

2. What if the motion sensor can't detect movements or the unintended activation is too frequent?
 - a. Adjust the sensor distance of the motion sensor on the "Device Settings" page of Govee Home App.
3. What should I do if I want to restore the original light effect or turn it off after motion sensing is triggered?
 - a. Add a "Delayed Execution" command after the action, and change the effect to other lighting effects or off.



Govee Home App

For FAQs and more information, please visit: www.govee.com