

REMOTE CONTROL CAR MANUAL


CAUTION

- Please take the batteries off the remote control and the car when not playing.
- When using the toy car, please keep it away from heat sources and avoid exposing the car to direct sunlight for a long time.
- Keep hands, hair, and loose clothing away from tires while the car is in motion.
- Do not pick up the moving car directly from the ground.


BATTERY SAFETY

- Do NOT mix alkaline, standard, and rechargeable batteries.
- Do NOT mix old and new batteries.
- Non-rechargeable batteries should not be recharged.
- Rechargeable batteries should be removed from the appliance before being charged.
- Rechargeable batteries should be charged under adult supervision only.
- Exhausted batteries should be removed from the appliance.
- The supply terminals should not be short-circuited.
- Only batteries of the same or equivalent type are recommended to be used.
- Batteries should be inserted with the correct polarity.


REMOTE CONTROL



BATTERIES AND CHARGING



USE 2X 1.5V AA BATTERIES
(NOT INCLUDED)



USE 2X 1.5V AA BATTERIES
(NOT INCLUDED)

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.