




## Remote controller



Camera adjustment (Left scroll to "down" position, Right scroll to "up" position)


Speed adjustment (Left scroll to "+" position, Right scroll to "-" position)



Pull out the phone holder outward as shown. Slip the phone into the bottom slot of the phone holder. Pull the holder lever up until the phone slip in.

After taking out the mobile phone, the stretching part of the mobile phone clip will automatically retract the mobile phone clip, and then put the mobile phone clip into the remote control.


3\*AAA batteries for transmitter (batteries sold separately)



- The Transmitter uses 3\*AAA non-rechargeable batteries, or AAA rechargeable batteries (sold separately).
- Make sure that the battery is correctly installed when installing or replacing the batteries.
- Non-rechargeable batteries should not be recharged. You can only use the recommended batteries or identical ones.
- Do not use batteries which are different types or ages.
- Take out drained batteries in a timely manner and dispose them as your local government demands.
- Please take out the batteries if it will not be used for a long period of time to avoid any damage to the product in case of battery leakage.

## CAMERA FUNCTIONS






ICON ON APP



Take Photo



Take Video

- Tap the button on the right side of the back of the Transmitter, or tap the  button in the application, and the blue signal light on camera will blink once, indicating that the camera took a picture.
- Press the left  button on the back of the Transmitter once or tap  the button in the application, the blue signal light on the camera will start to blink, indicating that the camera is now recording.
- Hold once  or press shortly  to stop video recording, and save the video into APP and TF card (DO NOT take photo during taking video.)



## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.