





Test Graphs

Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1






Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant1






Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1






Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant1






Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1






Duty Cycle NVNT ac20 5240MHz Ant1




Duty Cycle NVNT ac40 5190MHz Ant1






Duty Cycle NVNT ac40 5230MHz Ant1



Duty Cycle NVNT ac80 5210MHz Ant1





Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant2	100	0	0
NVNT	a	5200	Ant2	100	0	0
NVNT	a	5240	Ant2	100	0	0
NVNT	n20	5180	Ant2	100	0	0
NVNT	n20	5200	Ant2	100	0	0
NVNT	n20	5240	Ant2	100	0	0
NVNT	n40	5190	Ant2	100	0	0
NVNT	n40	5230	Ant2	100	0	0
NVNT	ac20	5180	Ant2	100	0	0
NVNT	ac20	5200	Ant2	100	0	0
NVNT	ac20	5240	Ant2	100	0	0
NVNT	ac40	5190	Ant2	100	0	0
NVNT	ac40	5230	Ant2	100	0	0
NVNT	ac80	5210	Ant2	100	0	0




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5180MHz Ant2




Duty Cycle NVNT a 5200MHz Ant2






Duty Cycle NVNT a 5240MHz Ant2




Duty Cycle NVNT n20 5180MHz Ant2






Duty Cycle NVNT n20 5200MHz Ant2




Duty Cycle NVNT n20 5240MHz Ant2






Duty Cycle NVNT n40 5190MHz Ant2




Duty Cycle NVNT n40 5230MHz Ant2






Duty Cycle NVNT ac20 5180MHz Ant2




Duty Cycle NVNT ac20 5200MHz Ant2






Duty Cycle NVNT ac20 5240MHz Ant2




Duty Cycle NVNT ac40 5190MHz Ant2





Duty Cycle NVNT ac40 5230MHz Ant2



Duty Cycle NVNT ac80 5210MHz Ant2

