





Test Graphs

Duty Cycle NVNT a 5745MHz Ant1



Duty Cycle NVNT a 5785MHz Ant1



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



Duty Cycle NVNT a 5825MHz Ant1




Duty Cycle NVNT n20 5745MHz Ant1






Duty Cycle NVNT n20 5785MHz Ant1




Duty Cycle NVNT n20 5825MHz Ant1






Duty Cycle NVNT n40 5755MHz Ant1




Duty Cycle NVNT n40 5795MHz Ant1






Duty Cycle NVNT ac20 5745MHz Ant1




Duty Cycle NVNT ac20 5785MHz Ant1






Duty Cycle NVNT ac20 5825MHz Ant1




Duty Cycle NVNT ac40 5755MHz Ant1






Duty Cycle NVNT ac40 5795MHz Ant1



Duty Cycle NVNT ac80 5775MHz Ant1





Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant2	100	0	0
NVNT	a	5785	Ant2	100	0	0
NVNT	a	5825	Ant2	100	0	0
NVNT	n20	5745	Ant2	100	0	0
NVNT	n20	5785	Ant2	100	0	0
NVNT	n20	5825	Ant2	100	0	0
NVNT	n40	5755	Ant2	100	0	0
NVNT	n40	5795	Ant2	100	0	0
NVNT	ac20	5745	Ant2	100	0	0
NVNT	ac20	5785	Ant2	100	0	0
NVNT	ac20	5825	Ant2	100	0	0
NVNT	ac40	5755	Ant2	100	0	0
NVNT	ac40	5795	Ant2	100	0	0
NVNT	ac80	5775	Ant2	100	0	0




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5745MHz Ant2




Duty Cycle NVNT a 5785MHz Ant2






Duty Cycle NVNT a 5825MHz Ant2




Duty Cycle NVNT n20 5745MHz Ant2






Duty Cycle NVNT n20 5785MHz Ant2




Duty Cycle NVNT n20 5825MHz Ant2






Duty Cycle NVNT n40 5755MHz Ant2




Duty Cycle NVNT n40 5795MHz Ant2






Duty Cycle NVNT ac20 5745MHz Ant2




Duty Cycle NVNT ac20 5785MHz Ant2






Duty Cycle NVNT ac20 5825MHz Ant2




Duty Cycle NVNT ac40 5755MHz Ant2





Duty Cycle NVNT ac40 5795MHz Ant2



Duty Cycle NVNT ac80 5775MHz Ant2

