

# X38 Camera

## Quick Start Guide

# 1. ABOUT PHONE

## ↳ Overview



1. Camera	6. Volume key	11. USB
2. LED	7. Function key	
3. Speaker	8. Reset	
4. Power key	9. Mic	
5. Volume key	10. Memory Card	

## 2. BEFORE USING

The device needs to be plugged into an SD card.

## 3. GETTING STARTED

### Basic Function

- Turn on the phone

Connect the Charger and the device will start automatically.

- Turn off the phone

Long press the power key until a menu shows. Choose “Power off” to turn off .

- Restart the phone

Long press the power key until a menu shows. Choose “Restart” to restart.

## 4. Working condition of equipment

Voice prompt :“camera is power on”



Quick Menu

- Volume Control 

Adjust media volume, ring tone, and notification volume

- Bluetooth switch 

When turned on, you can search for nearby Bluetooth devices

- BLAN switch 

Once Open, you can search for nearby networks

- Settings Menu 

You can change time, language, restore factory settings, view device information, and so on

## 5. LED light flicker status

Blue Light : The blue light flashes when the machine is turned on

Red Light : Flashing red lights while the equipment is working

## 6. WARNING

The power output is 5V/2A .

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.